COM SCI M151B Week 1


Aidan Jan

October 1, 2024

Using Abstraction

- We see a computer as a box with multiple layers of abstraction.
- Depending on which layer we want ot work on, we abstract away the irrelevant layers.
 - The main benefit is that we don't need to know the unnecessary details of the other layers in order to be able to work on our layer.

Computer Abstractions (simplified)



- Application software
 - Translation from algorithm to code
 - Written in high-level language (e.g., C, Java)
- ullet System software
 - Compiler: translates high level language code to machine code
 - Operating system: service code
 - * Handling input/output
 - * Managing memory and storage
 - * Scheduling tasks and sharing resources

- Hardware
 - Processor memory
 - I/O controllers

https://www.youtube.com/watch?v=_y-5nZAbgt4

How do computers work?

- Theoretical and Historical Points of View
 - Turing machines and history of electronics and computers.

Level of Program Code

- High level language
 - Level of abstraction closer to problem domain
 - Provides for productivity and portability
- Assembly language
 - Textual representation of instructions
 - Architecture-dependent
- Hardware representation
 - Binary digits (bits)
 - Encoded instructions and data

How to maintain compatibility?

There are many different types of computer architecture, and many different languages applications are written in. How do we maintain compatibility?

- System software (OS) and software makes a contract to always give a program with **only a set of known instructions**, and the hardware promises to be able to run that.
- The **ISA** is the *interface* between hardware and software. This allows the HW and SW to change/evolve **independently**.
- Software sees:
 - Function description of hardware:
 - 1. Storage locations (e.g., memory)
 - 2. Operations (e.g., add)
- Hardware sees:
 - List of instructions and their order
- In this course, we will use RISC-V ISA.


Goals when designing computers

They must be efficient. What is efficient?

- Performance (often most important)
- Power consumption
- Cost
- Reliable and Secure

Past, Present, and Future

- Moore's Law:
 - We started with the ENIAC after World War II, and that computer had a size of 1000 cubic feet,
 used 125kW of power, only does 2000 additions per second, and had 48 kB of memory.
 - Now, we have computers taking up 1 cubic foot, consumes 250W of power, capable of 20B operations per second, with multiple GB of memory, for only less than 0.01% of the cost of the ENIAC.
 - Moore's Law states that every two years, the number of transistors (and therefore computational power) doubles. This suggests that the cost per transistor reduces each year.



- From 1986 to 2003, Moore's Law was theorized
- At 2003 to 2011, transistors grew so close together that it became near-impossible to make them smaller; refer to Power Wall below.
- From 2011 to 2015, Amdahl's Law started taking effect. (Refer below).

• Dennard's Scaling Law:

According to Moore's law, the number of transistors on a chip doubles every two years, thus each transistor's area is reduced by 50%, or every dimension by 0.7x.

3

- As a result, voltage is reduced by -30% (0.7x) to keep the electric field constant. V = EL
- L is reduced, thus delays are reduced by -30%. (x = Vt)
- Frequency is increased by +40% (f = 1/t)
- Capacitance is reduced by -30% (C = kA/L)
- Scaling Power and Energy

$$P = CV^2 f$$

- Power consumption per transistor is decreased by -50%.
- Power consumption of the entire chip stays the same! Except now it has more transistors.
- Where are these improvements coming from?
 - 1. Advancements in microelectronics and fabrication technologies.
 - 2. Advancements in architectural techniques
 - What this course is about!
 - This lead to an improvement by a factor of 25 versus if we had only relied on (1.)
- Power Wall
 - Up to 2005, manufacturers could double the processor performance while keeping the power constant.
 - Since 2005, due to smaller transistor sizes, **static power leakage** becomes so dominant that the power consumption did not stay constant. (Moore's Law slowed down.)
 - However, the rate still grew since multicore systems began to emerge.
- Amdahl's Law
 - Performance improvement (speedup) is limited by the part you cannot improve (called "sequential part").

speed up =
$$\frac{1}{(1-p) + \frac{p}{s}}$$

- * P is the part that can be improved (e.g., **parallelized**)
- * S is the factor for improvement (e.g., more cores for parallelization)
- Dark Silicon
 - Where we are right now
 - Due to thermal management limitations, some parts of a chip cannot be turned on.
 - This is the end of the multi-core era.
 - New technologies and techniques are being used to continue the scaling. We need cross-stack approaches!

Instruction Set Architecture (ISA)

What is an ISA

- The contract between software and hardware is the ISA. Typically described by giving all the programmer-visible state (register + memory) plus the semantics of the instructions that operate on that state.
- IBM 360 was the first line of machines to separate ISA from implementation (aka. microarchitecture)
- There are many implementations possible for a given ISA

- AMD, Intel, VIA processors run the AMD64 ISA
- Many cell phones use the ARM ISA with implementations from many different ompanies including Apple, Qualcomm, Samsung, Huawei, etc.
- We use RISC-V as the standard ISA in class.

Design Methodology

- ISA often designed with particular microarchitectural style in mind, e.g.,
 - Accumulator \rightarrow hardwired, unpipelined
 - CISC \rightarrow microcoded
 - RISC \rightarrow hardwired, pipelined
 - VLIW \rightarrow fixed-latency in-order parallel pipelines
 - JVM \rightarrow software interpretation
- But can be implemented with any microarchitectural style
 - Intel Ivy Bridge: hardwired pipelined CISC (x86) machine (with some microcode support)
 - Spike: Software-interpreted RISC-V machine
 - ARM Jazelle: A hardware JVM processor

RISC-V

What is RISC-V?

- An open-source "RISC"-based ISA (royalty-free)
- Developed in the 2010s at Berkeley
- Mostly maintained by the open-source community.
- Different extensions and models. We will focus on the 32-bit "base" mode (i.e., "RV321").
- RISC = "Reduced Instruction Set Computers". Unlike "CISC", every instruction in RISC is the same size.

RISC vs. CISC

- Instruction size of RISC is fixed, CISC is variable
- RISC has simple (one-by-one) operations, rather than packed operations
- RISC is less complex than CISC in terms of instruction set.

Widely-Used ISAs

- All "RISC" except x86 (Intel's ISA)
- Most popular RISC ISAs:
 - MIPS, ARM, PowerPC, and RISC-V

Stored Program Computer (von Neumann)

- Computer hardware is a machine that reads instructions one-by-one and executes them sequentially. It continues this until the program finishes.
- Memory holds both program and data
 - Instructions and data in a linear memory array
 - Instructions can be modified as data
- Sequential instruction processing
 - 1. Program Counter (PC) identifies current instruction.
 - 2. Fetch instruction from memory.
 - 3. Update state (e.g., PC and memory) as a function of current state according to instruction
 - 4. Repeat.

How to build an ISA?

- Transition from HLL to assmebly
- Take CS132 (Compiler Construction)

What do instructions look like?

There are two main parts: commands and operands.

- In 32-bit RISC-V, each instruction is fixed-size and is 32-bit.
- Possible Types of Operands:
 - 1. Registers
 - A small storage unit *inside* the processor to quickly access data.
 - Faster than memory, but much smaller (smaller is faster!)
 - Can be seen by Software*! (This is something that we will clarify later.)
 - Typically between 16 and 64 registers in modern ISAs.
 - * Larger width means easier data transfer but more power.
 - * More registers means less access to the main memory, but requires more area and more power.
 - * Low-end processors use smaller registers. High-Performance processors use wider and more registers.
 - See section on RISC-V Registers

2. Immediate

- Constant numbers to be used in an instruction
- Example: addi x2, x1, 5
- Registers are 32-bits but immediates may not. (This is because they must fit into the instruction. Use pointer instead if it doesn't fit!)
- See section on RISC-V Immediates.

3. Memory

- Values are stored in a memory and could be accessed.
- Memory should be byte-addressable
- See section on Memory.

RISC-V Registers

- RISC-V (RV32) uses 32 registers, 32-bit each (called "word").
- RV64 uses 32 registers, 64-bit each (called double-word)
- Each register shown as xi.
- x0 is hardwired to zero.
- Registers are stored in a data structure called the **Register File** (this is a hardware unit that will be discussed later.)
- For more high-end processors, there is a separate set of registers for floating point operations.

RISC-V Immediates

- RISC-V does Sign-Extension and Padding
- Sign-Extension
 - Two's Complement for signed values
- Padding
 - For LSBs (least significant bit), padding zeros is sufficient.

Memory

Format and addressing

- Byte-addressability vs. 32-bit data (little endian vs. big endian)
- Alignment:

MSB	byte-3	byte-2	byte-1	byte-0	LSB
	byte-7	byte-6	byte-5	byte-4	

- Load and Store Variants
 - LW, LB, LH (load different amounts of bits word, byte, high) (this one does sign extension, e.g., adding 1's instead of 0's if number is negative)
 - LBU, LHU (byte unsigned, high unsigned) (this one does not do sign extension, which means higher bits are unaltered)
 - SW, SB, SH (store word, byte, high doesn't care about the sign)

Instruction Types

- 1. Arithmetic/ALU
 - Do an arithmetic operation on two registers or one register and an immediate
 - Result is saved in another register
 - Example: ADDI x5, x1, 10 adds x1 and 10, stores in x5
- 2. Memory

- Load and Store
- Addressing modes:
 - Base (register) + Offset (immediate)
 - Base could be zero or it could be a value stored in a register.
- Data Size and format
 - Word, half-word, byte
 - Signed and unsigned
- 3. Control-Flow

RISC-V Arithmetic operators

ADDI	addi rd, rs1, constant	Add Immediate	reg[rd] <= reg[rs1] + constant
SLTI	slti rd, rs1, constant	Compare < Immediate (Signed)	$reg[rd] \leftarrow (reg[rs1] \leftarrow constant) ? 1 : 0$
SLTIU	sltiu rd, rs1, constant	Compare < Immediate (Unsigned)	reg[rd] \leftarrow (reg[rs1] \leftarrow constant) ? 1 : 0
XORI	xori rd, rs1, constant	Xor Immediate	reg[rd] <= reg[rs1] ^ constant
ORI	ori rd, rs1, constant	Or Immediate	reg[rd] <= reg[rs1] constant
ANDI	andi rd, rs1, constant	And Immediate	reg[rd] <= reg[rs1] & constant
SLLI	slli rd, rs1, constant	Shift Left Logical Immediate	reg[rd] <= reg[rs1] « constant
SRLI	srli rd, rs1, constant	Shift Right Logical Immediate	$reg[rd] \leftarrow reg[rs1] *_u constant$
SRAI	srai rd, rs1, constant	Shift Right Arithmetic Immediate	$reg[rd] \leftarrow reg[rs1] *_s constant$
ADD	add rd, rs1, rs2	Add	reg[rd] <= reg[rs1] + reg[rs2]
SUB	sub rd, rs1, rs2	Subtract	reg[rd] <= reg[rs1] - reg[rs2]
SLL	sll rd, rs1, rs2	Shift Left Logical	reg[rd] <= reg[rs1] « reg[rs2]
SLT	slt rd, rs1, rs2	Compare < (Signed)	$reg[rd] \leftarrow (reg[rs1] \leftarrow reg[rs2]) ? 1 : 0$
SLTU	sltu rd, rs1, rs2	Compare < (Unsigned)	reg[rd] \leftarrow (reg[rs1] \leftarrow reg[rs2]) ? 1 : 0
XOR	xor rd, rs1, rs2	Xor	reg[rd] <= reg[rs1] ^ reg[rs2]
SRL	srl rd, rs1, rs2	Shift Right Logical	reg[rd] <= reg[rs1] » _u reg[rs2]
SRA	sra rd, rs1, rs2	Shift Right Arithmetic	$reg[rd] \leftarrow reg[rs1] \times_s reg[rs2]$
OR	or rd, rs1, rs2	Or	reg[rd] <= reg[rs1] reg[rs2]
AND	and rd, rs1, rs2	And	reg[rd] <= reg[rs1] & reg[rs2]

Memory-Type Instructions

			4
LB	<pre>lb rd, offset(rs1)</pre>	Load Byte	<pre>reg[rd] <= signExtend(mem[addr])</pre>
LH	lh rd, offset(rs1)	Load Half Word	reg[rd] <= signExtend(mem[addr + 1: addr])
LW	lw rd, offset(rs1)	Load Word	reg[rd] <= mem[addr + 3: addr]
LBU	lbu rd, offset(rs1)	Load Byte (Unsigned)	reg[rd] <= zeroExtend(mem[addr])
LHU	lhu rd, offset(rs1)	Load Half Word (Unsigned)	reg[rd] <= zeroExtend(mem[addr + 1: addr])
SB	sb rs2, offset(rs1)	Store Byte	mem[addr] <= reg[rs2][7:0]
SH	sh rs2, offset(rs1)	Store Half Word	mem[addr + 1: addr] <= reg[rs2][15:0]
SW	sw rs2, offset(rs1)	Store Word	<pre>mem[addr + 3: addr] <= reg[rs2]</pre>