

! Important

Available in: **Nightly builds** or Releases greater than **2.4.2**.

- ## Open the Plugins Window


-
- The screenshot displays the Orca IDE interface. The top menu bar includes 'File', 'Edit', 'View', 'Preferences', 'Preset Bundle', 'Sync Presets', 'Plugins', and 'Help'. The main workspace area is titled 'Untitled' and features two prominent buttons: 'New Project' (Create new project) and 'Open Project' (Jml). The bottom status bar shows 'Recently opened' and 'OrcaCloud'.

1/3

The details section includes these tabs:


- **Plugin Info** — source, author, version, capabilities, and status.
- **Description** — information supplied by the plugin author.
- **Config** — configuration for the selected plugin's capabilities.
- **Changelog** — available version history.
- **Diagnostics** — loading and error information.

Every capability has a configuration. OrcaSlicer provides a JSON editor by default; a plugin can provide a custom configuration page instead. See [Plugin configuration](#) for the plugin-author API.



Use the split **Browse plugins** button to choose how you want to add plugins:

- **Browse plugins** opens the cloud plugin browser.
- **Install local plugin** installs a plugin file from your computer.



Note

Only install plugins from sources you trust. Plugins can interact with your files and print workflow.