CALM

- 1. Make sure everything is turned ON and connect properly by moving with a stylus.
- 2. Install ROS. Link
- 3. Check the USB devices by running <u>this</u> script and you should see /dev/ttyACMO Teensyduino_USB_Serial_6311670
- 4. source devel/setup.bash
- 5. roscore
- 6. rosrun rosserial_python serial_node.py /dev/ttyACM0 _baud:=115200
- 7. rostopic pub /ralp_msgs/teensy_input ralp_msgs/teensy_input "buttons: 1 deltax: 0.001 deltay: 0.001"