

Handheld Scanner Setup

KGPL Scan Suite · Zebra MC2200 and UROVO DT50S (Android)

First, the important thing

The **camera button** on each screen opens the **phone camera** only. It cannot switch on the laser — a web app has no way to fire the hardware scanner. The **laser is fired by the physical trigger key** on the device. When set up correctly, the scanned barcode is typed straight into the field the cursor is in, and the app submits it automatically. So the operator just **taps the scan field and pulls the trigger** — the camera is only a backup for damaged labels.

Set the scanner to “Keyboard / Keystroke” output. If it is set to “Intent” the laser fires but the barcode never reaches the browser — it looks like nothing happens.

Zebra MC2200 — DataWedge

DataWedge is already installed on Zebra devices.

1. Open the **DataWedge** app.
2. Open **Profile0** (it applies to every app) — or create a profile and, under **Associated apps**, add the browser (e.g. `com.android.chrome`) with activity `*`.
3. **Profile enabled**: ON.
4. **Barcode input**: Enabled — this powers the laser.
5. **Keystroke output**: Enabled.
6. **Intent output**: OFF (if this is on, nothing types into the field).
7. Keystroke output → Basic data formatting → **Send ENTER key**: **ON** (each scan submits cleanly).
8. Leave DataWedge, open the Scan Suite, tap a scan field, pull the trigger.

UROVO DT50S — Scan settings

1. Open the **Scan / ScanSetting** app (or Settings → Scan).
2. **Scanner / Scan engine**: ON.
3. **Output mode**: set to **Keyboard** (also called “Simulate keystroke” / “HID”). Do **not** use “Intent broadcast” or “Fill EditText via API”.
4. **Suffix**: add **Enter (0x0D)** / line-feed.
5. Keep the default trigger key assigned to scan.
6. Open the app, tap a scan field, pull the trigger.

If it still does not type

Symptom	Fix
Laser fires, but nothing appears in the field	Output mode is on Intent . Switch it to Keyboard / Keystroke .

Barcode types in but the screen does not react

Add an **Enter** suffix in the scanner settings.

Sometimes works, sometimes not

The **cursor must be in the scan field** — tap the field first. The app auto-focuses it when a screen opens; if focus is lost, tap it again.

Operator keeps tapping the camera icon

Remind them: camera = backup only. The **trigger key** is the scanner.

One-line rule for the floor: **tap the field, pull the trigger**. The camera button is only for a damaged or unreadable label.