Course: Summer Industrial Training 2015

Lab Report: EXTRA CREDIT LAB - Home Automation Using PSoC BLE

Report By: Ajinkya Padwad

Abhijit Gokhale

Executive Summary:

The main aim of this project was to implement a basic home automation project using the PSoC BLE to control different types of devices (LEDs in this case) and employ intensity control.

Project Description:

The first step was creating the schematic of the system at the 'Top Design' layout at PSoC Creator. The PWM and BLE modules were added along with the suitable input and output pins from the components menu. Next step was the component configuration after which, the ports were mapped to physical pins. The program code was then compiled into the 'main.c' file and lastly, the interface of the CY8CKIT-042-BLE Bluetooth® Low Energy (BLE) Pioneer Kit was carried out.

Components used:

Digital Output Pins (LEDs) -

The digital output pins are basically the three LED pins which are software connected to the microcontroller onboard.


PWM Module -

PWM module is responsible for the duty cycle variation and in turn the intensity control of the LEDs.

Bluetooth Low Energy (BLE) module-

BLE module gives a GUI for the configuration of the GAP and GATT profiles for Bluetooth connectivity.

Project Schematic




Pin Component Configuration and Pin map:

Digital Output pin -

Drive Mode This parameter configures the pin to provide one of the eight available pin drive modes.


HW Connection parameter determines whether the digital input terminal for an input pin is displayed in the schematic. It may or may not be API controlled depending upon the option being selected.



PWM Module -

PWM Mode parameter defines the overall functionality of the PWM. It can be- One Output – Only a single PWM output or Two Output – Two individually configurable PWM outputs.

CMP Type 1 / CMP Type 2 parameters define the two period counter comparisons that make up the PWM outputs.




Bluetooth Low Energy (BLE) module-


The *Profile role* parameter configuration depends on the chosen Profile, and the Profile role selection affects the GAP role parameter.

The *toolbars* contain navigation options and a means to add or delete Services, Characteristics, and Descriptors.

The *GAP parameters* define the general connection settings required when connecting Bluetooth devices



CYDWR -



API Description:

Bluetooth API functions -

CyBle_Start

This function initializes the BLE Stack, which consists of the BLE Stack Manager, BLE Controller, and BLE Host modules.

CyBle_Stop

This function stops any ongoing operation in the BLE Stack and forces the BLE Stack to shut down

CyBle_ProcessEvents

This function checks the internal task queue in the BLE Stack, and pending operation of the BLE Stack, if any.

- The GAP APIs allow access to the Generic Access Profile (GAP) layer of the BLE stack.
- The GATT APIs allow access to the Generic Attribute Profile (GATT) layer of the BLE stack.

Output Observed:

The CySmart app for PSoC BLE sends data bits for options selection which is then converted into appropriate signal and the ON/OFF or intensity control of the onboard LEDs is observed.

Test and Debug:

- ✓ Encountered a major problem while configuring the 'custom' profile for this project.
- ✓ Initial drive state of LEDs debugged.

Learning Outcomes:

- ➤ Learnt the various BLE APIs and the process handling.
- > Importance of Bluetooth events and the role of stack handler.

APPENDIX A

Code:

```
#include project.h>
CYBLE CONN HANDLE T connectionHandle;
CYBLE GATTS WRITE REQ PARAM T *wrReqParam;
uint8 DevType, DevCode, DevParam, Reserve;
void HandleDevice()
{
    if(DevType==0x01) //If ON/OFF Control type
    {
        switch (DevCode)
        {
            case 0x01:RLED Write(DevParam);break;
            case 0x02:GLED Write(DevParam);break;
            case 0x03:BLED Write(DevParam);break;
            default:break;
        }
    }
     else if(DevType==0x02) // If intensity control type
        switch (DevCode)
        {
        case 0x01:PWM1 WriteCompare1(DevParam);
                  break;
        case 0x02:PWM1 WriteCompare2(DevParam);
                  break;
        case 0x03:PWM2 WriteCompare(DevParam);
                  break;
        default:break;
    }
}
void CustomEventHandler(uint32 event, void*eventParam)
{
   switch (event)
    case CYBLE EVT STACK ON:
    CyBle_GappStartAdvertisement(CYBLE ADVERTISING FAST);
    break;
    case CYBLE EVT GAP DEVICE DISCONNECTED:
    CyBle GappStartAdvertisement (CYBLE ADVERTISING FAST);
    break;
```

```
case CYBLE EVT GATT CONNECT IND:
    connectionHandle=*(CYBLE CONN HANDLE T *)eventParam;
   break;
   case CYBLE EVT GATTS WRITE REQ:
    wrRegParam=(CYBLE GATTS WRITE CMD REQ PARAM T*)eventParam;
    if (CYBLE HOME CONTROL DEVICE CONTROL CHAR HANDLE == wrReqParam-
>handleValPair.attrHandle)
        DevType=(uint8) wrReqParam->handleValPair.value.val[0]; // ON/OFF or
intensity control
        DevCode=(uint8)wrReqParam->handleValPair.value.val[1]; //LED Color
        DevParam=(uint8) wrReqParam->handleValPair.value.val[2];// Control bit
        Reserve=(uint8)wrReqParam->handleValPair.value.val[3]; //Reserved
        HandleDevice();
        CyBle GattsWriteRsp(connectionHandle);
   break;
   default:break;
}
int main()
   CLK_Start();
PWM1_Start();
                       //Clock started
                       // PWM1 Started
                       // PWM2 Started
    PWM2 Start();
                    // LEDS off initially
    RLED Write(0);
    GLED_Write(0);
    BLED Write(0);
    CyGlobalIntEnable; // Enable global interrupts.
    CyBle Start(CustomEventHandler);
    for(;;)
        CyBle ProcessEvents();
}
```