



APLUS outputs scaled Voltage and Power analog values. There is a linear function that converts voltage to mA.

Need to determine PF and WH. Is it calculated?

Modbus registers not setup in APLUS





## PROPRIETARY NOTICE:

This document and the technical data hereon disclosed are proprietary to Hooks & Associates, Inc. and shall not, without express written permission of Hooks and Associates, Inc. be used in part, or used to solicit quotations from a competitive source or used for manufacture by anyone other than Hooks & Associates, Inc. The information hereon has been developed o private expence and may only be used for purposes of engineering evaluation and for incorporation into technical specifications and other documents which specify procurement of products from Hooks & Associates, Inc.

REV BY DESCRIPTION DATE

HAIER EVANSVILLE, IN

THERMODYNAMIC LAB
POWER SUPPLY UNIT
ANALOG SLOT 14-18

SCALE NONE PROJECT HE1

DESIGNED T. CUTSINGER DRAWING
DRAWN T. CUTSINGER
E012 08

SHEET X OF X