

Wireless Air Remote Mouse User Manual Table of Contents Remote Mouse WeChip W1 2.4 GHz
Technical Specification Wireless Technology Compatibility Getting Started Connecting the Air Mouse
to your device Basic Function Adjusting Mouse Cursor Speed Reducing the Speed of Mouse Cursor
IR learning Function Key Board Functionality Troubleshooting Air Mouse Not Responding Cursor
Movement Issue Connection Problem FAQ How do I adjust the speed of the mouse cursor What
is the Auto Sleep and Wake up Feature

Wireless Air Remote Mouse User Manual Remote Mouse Step 1 Plug-in the USB inside the USB
port of Smart TV or Joy Box. The system will automatically install the driver's software. Step 2
Control the remote mouse cursor on the device by moving it in the air. The movement of the
remote mouse controls the direction of the pointer. Turn the mouse pointer off by pressing the
"CURSOR LOCK" button. Press it again to turn the mouse pointer on. Step 3 After 20 seconds,
the remote will go in to standby mode. To use the device, press any key. Blinking green light
indicates low power of the remote mouse. You can charge it with micro-USB cable. Step 4 The
remote mouse's default mode is Bluetooth. Short press the "OK" + "MENU" button to switch to
Infrared mode. Press it again to switch to Bluetooth mode. Note: Infrared mode can be used to
replace the buttons of TV Remote with Remote Mouse buttons. Bluetooth Mode: Green
Light INFRARED MODE: Red Light

Replacing TV Remote buttons with Remote Mouse Example: Step 1 Power Key Short press
"OK" + "Menu" button of the remote mouse to switch to infrared mode. Step 2 Now, long press
"OK" + "MENU" button for 3 seconds till the red LED of the remote mouse becomes stable. Step
3 Keep the remote mouse and TV remote head-to-head within 2cm. Step 4 Press the Power key
of the remote mouse and the red light will start blinking Step 5 Then press the power key of the
TV remote for 3 seconds. Step 6 Now you can use the power button of the remote mouse to
turn your TV on and off. You can replace any button of your TV remote with any button of the
remote mouse in the similar manner described above. WeChip W1 2.4 GHz Technical
Specifications Wireless Technology 2.4GHz wireless technology. Compatibility Compatible with
Windows, Mac OS, Android, and Linux devices Getting Started Ensure that the package includes
the following items: We Chip W1 Air Mouse USB receiver Connecting the Air Mouse to your
device Plug the USB receiver into a USB port on your device (e.g., smart TV, PC) Turn on the We
Chip W1 Air Mouse using the power switch The air mouse will automatically connect to the USB
receiver. Basic Functions Adjusting Mouse Cursor Speed Mouse Cursor has 4 adjustment levels.
Press and hold the [OK] button and volume [+] button at the same time for 3 seconds The blue
indicator led light will flash twice This will speed up the cursor 1 level up Repeating this step will
increase the cursor speed up to 4 levels. Reducing the Speed of Mouse Cursor Press and hold
the [OK] button and volume [-] button at the same time for 3 seconds The blue indicator led
light will flash twice This will speed down the cursor to 1 level Repeat the 1st step to reduce the
speed to a lower level. IR learning Function Press and hold [OK] and [Power] button on the air

mouse at the same time for 3 seconds to keep the blue indicator light on all the time , then press Power] button once, and the blue indicator flashes , the air mouse enters the IR learning mode Place your TV remote and the air mouse on the desk, head-to-head (the distance between them should not exceed 3 cm) Press one of the buttons on the air mouse first and press the button (the function you want the air mouse to learn) on your TV remote, then the blue indicator light on the air mouse will flash three times and until it stays bright all the time Repeat the 3rd step to make the air mouse learn more functions, otherwise you can go to the 5th step Press the button to exit the IR learning mode, the IR Learning function is completed now.

Key Board Functionality In the normal mode, the keyboard will type alphabets. To use numeric keypad, press the Fn button, the remote will be working on the function buttons (written in blue) While using Fn button, a small blue LED light will be turned on the top of remote.

Troubleshooting Air Mouse Not Responding Ensure the batteries are inserted correctly and have sufficient charge Re-pair the air mouse with the USB receiver Check for interference from other wireless devices.

Cursor Movement Issues Ensure the air mouse is on a flat surface for accurate movement.

Connection Problems Try using a different USB port on your device or replace the USB receiver if it is damaged.

FAQs How do I adjust the speed of the mouse cursor? To increase the speed of the cursor, press and hold the [OK] button and [volume + button at the same time for 3 seconds, the blue indicator flashes twice and then release, the speed up one level. To reduce the speed of the cursor, press and hold the [OK] button and [volume –] button at the same time for 3 seconds, the blue indicator flashes twice and then release, the speed down one level. Repeat the 1st step to reduce the speed to a lower level.

What is the Auto Sleep and Wake up Feature? When you do not use the air mouse remote for 15 seconds, the remote will enter automatic sleep state, the blue indicator lights off. You can press any button to wake up the remote.