

UPS Manual Nayatel 50W UPS Nayatel Provides its own manufactured UPS with load capacity of 50W and output voltage of 12.5V DC to home and corporate customers. It is a metallic body UPS. Charging And Backup Time After continuous charging of 4 hours, UPS will give backup time of 1 hour Backup time may vary depending upon load shedding, charging time and life of battery. Note: This device is design for only for Nayatel routers and ONTs. You can connect only single device with this UPS LED Status of Nayatel 50W UPS Nayatel 50W UPS has six LEDs on its side panel. 1. PSU FALL LED This LED indicates the fault in UPS. If it blinks red it means, there some fault in the UPS (circuitry fault etc. If it is OFF, it means that it working in normal condition. 2. PO LED If it is ON, it shows UPS is ON If it is ON, it shows UPS is OFF. 3. ST LED If green blinking, UPS is ON If OFF, UPS is OFF. 4. BO LED If blinking red, it shows UPS is working on battery If OFF, it shows UPS is working on WAPDA. 5. BC LED If yellow light is ON, it shows UPS is charging IF OFF, its shows UPS has been charged. 6. BF LED If red light is ON, battery is disconnected or faulty If OFF, UPS is normal operation. Nayatel 55W UPS Nayatel Provides its own manufactured UPS with load capacity of 55W and output voltage of 13.8V DC to home and corporate customers. It is a plastic body UPS. Charging And Backup Time After continuous charging of 4 hours, UPS will give backup time of 1 hour. Backup time may vary depending upon load shedding, charging time and life of battery. Note: This device is design for only for Nayatel routers and ONTs. You can connect only single device with this UPS. i. LED Status of Nayatel 55W UPS Nayatel 55W UPS has two LEDs on its side panel. 1. RED LED If red light is ON, it shows WADA power is ON If red light is OFF, it shows WADA power is OFF. 2. GREEN LED UPS is turned ON UPS is OFF. LEDs on side panel of Nayatel 55W UPS ii. 55W UPS LED's Summary:

|                |                                                                                                  |                                                                                |
|----------------|--------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------|
| identification | wapda                                                                                            | Power                                                                          |
| colour         | red                                                                                              | Green                                                                          |
| state          | On   off                                                                                         | On   off                                                                       |
| indication     | For on It shows that wapda(grid power) is on.<br>For off It shows that wapda(grid power) is off. | For on it shows ups is on.<br>for off it shows that ups is off and not working |

APC UPS Nayatel Provides its own manufactured UPS with load capacity of 24W and output voltage of 12V DC to home and corporate customers. It is a white colour, plastic body UPS

Charging And Backup Time After continuous charging of 4 hours, UPS will give backup time of 1 hour Backup time may vary depending upon load shedding, charging time and life of battery. Note: This device is design for only for Nayatel routers and ONTs. You can connect only single device with this UPS.

- i. LED Status of Nayatel APC UPS Nayatel UPS has three LEDs on its side panel. 1. Dual Colour LED If it keeps on blinking green, it means UPS is in charging state, WAPDA is

- ON If green light is stable, it means UPS is completely charged, WAPDA is ON If it is blinking yellow, it means Power supply from WAPDA is OFF. 2. RED LED If red light is ON, battery of UPS is disconnected or faulty If red light is OFF, it means UPS is normal
- ii. 3. GREEN LED If green light blinks, UPS is turned ON If green light is OFF, UPS is OFF

iii. APS UPS LED's Summary

| Led name   | Dual color led                                                                                                  | Green led   red led                                                                                                             |
|------------|-----------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| indication | Green (green keep blinking: ups charging and wapda on)<br>red(keep blinking yellow power supply frtom wapda off | Green is on ups is on<br>Green is off ups is off<br>Red is on battery of ups disconnected or faulty<br>Red is off ups is normal |

Cyber Power UPS Nayatel Provides its own manufactured UPS with load capacity of 24W and output voltage of 12V DC to home and corporate customers. It is a white colour, plastic body UPS. Charging And Backup Time After continuous charging of 4 hours, UPS will give backup time of 1 hour Backup time may vary depending upon load shedding, charging time and life of battery.

LED Status of Nayatel Cyber power UPS Nayatel cyberpower UPS has three LEDs on its side panel. Dual Colour LED If light green, WAPDA is ON If it is blinking yellow, it means Power supply from WAPDA is OFF. 2. RED LED If red light is ON, battery of UPS is disconnected or faulty If red light is OFF, it means UPS is normal. 3. GREEN LED If green light blinks, UPS is turned ON If green light is OFF, UPS is OFF.

Huawei UPS Nayatel Provides its own manufactured UPS with load capacity of 44W and output voltage of 11.2V DC to home and corporate customers. It is a black plastic body UPS with specific input adapter that supplies input of 13.8 V to UPS. Charging And Backup Time After continuous charging of 2 hours, UPS will give backup time of 1 hour Backup time may vary depending upon load shedding, charging time and life of battery. Note: This device is design for only for Nayatel routers and ONTs. You can connect only single device with this UPS

Connection Of Huawei UPS With ONT UPS is connected to ONT with power cord for providing backup power to ONT UPS may also be connected to ONT via management port, if connected; then by logging into ONT, status and remaining battery of UPS can be viewed.

ii. LED Status of Nayatel Huawei UPS Huawei UPS has three LEDs on its side panel.

1. ALARM LED If red on, it means there is battery or internal fault If red is off, it means UPS

is working fine. 2. DIS LED If green light is ON, it means ONT/router is working on battery If green light is off, it means ONT/router is working on WAPDA. 3. CHG LED If green ON/green blinking, it means Charging/Incompatible adaptor connected Green OFF means, UPS is completely charged

Huawei UPS LED's Summary Precautionary Measures: Never change the power socket on which UPS is installed because new power socket may not be compatible or support the type of plug fitted with the UPS Do not try to repair or open cover of the UPS by yourself. You may damage the equipment permanently Please prevent contact of any type of liquid on and around the UPS as well as cleaning of UPS with any liquid. This may cause short circuit or electrical shock In order to avoid any loose connections, please do not change the position/ orientation of the UPS as installed by Nayatel team Please do not cover the UPS as this may cause overheating/burning of the device. Please contact Nayatel technical staff for any related query at 1441 or reach us at My Nayatel App or [customer.nayatel.com](http://customer.nayatel.com)