INTRO TO MATERIAL BEHAVIORS

ME 210: MECHANICS OF MATERIALS

SAPPINANDANA AKAMPHON

DEPARTMENT OF MECHANICAL ENGINEERING, TSE

A LITTLE INTRO

■ Name: Sappinandana Akamphon

■ Room: ENG 421/4

■ mail: sup@engr.tu.ac.th

CHILDHOOD

■ Born and raised in Khon Kaen, Thailand



BACHELOR'S DEGREE

■ Sc.B. Brown University, 2002




MASTER AND DOCTORAL

■ M.S. 2005, Ph.D. 2008, MIT



RESEARCH INTERESTS

- Solar energy utilization
- Water generation




MATERIAL BEHAVIORS

- The study of material response to
 - ► Mechanical Changes: external loads
 - ► Thermal changes: temperature


COORDINATE SYSTEM

- Most quanitities in this class are vectors
- Coordinate systems make it clear on orientation and direction of anything
- Three main systems
 - Cartesian
 - Cylindrical
 - ► Spherical


CARTESIAN



CYLINDRICAL



SPHERICAL COORDINATES




EXTERNAL LOADS

- Force(s) or Moment(s)
- Results in deformation, depending on *direction* and *surface*
- How do we define direction and surface

SURFACE DIRECTION

■ Direction of vector *normal* to the surface



FORCES

- Normal forces → same direction as surface
- Shear forces → perpendicular to surface direction

MOMENTS

- Follow right-hand rule.
- Torsional moments: same direction as surface
- Bending moments: perpendicular to surface direction

THE SINGULARITY EQUATION (FOR THIS CLASS)

■ Equilibrium equation

$$\sum F = 0$$

$$\sum M = 0$$

ENGINEERING STATICS

- We will be trying to determine stresses and deformation of things
- Need to find internal load at any point/surface
- Method of sections

METHOD OF SECTIONS

- Use free body diagram to determine internal forces/moments on surface at any point
- What if there are too loads/chages all at once
- Principle of Superposition


PRINCIPLE OF SUPERPOSITION

- Split the loads/changes
- Determine individual response
- Add the responses up


REVIEW OF HIGH SCHOOL PHYSICS

- Normal Stresses: same direction as surface
- Shear stresses: perpendicular to surface direction

NORMAL STRESSES



SHEAR STRESSES



ALLOWABLE STRESSES

- Real design needs to take care of uncertainties: materials, conditions, loads, ...
- Use σ_{allow} and τ_{allow} instead

$$\sigma_{allow} = \frac{\sigma_f}{N_s}$$

$$\tau_{allow} = \frac{\tau_f}{N_s}$$

SAFETY FACTORS, N_s

- \blacksquare N_s is called the safety factor
- $N_s \ge 1$ always
- Why? Is there an upper limit to N_s ?

EXAMPLE: DESIGN WITH SAFETY FACTOR

We need a steel rod that will take the load of 20 kN with a safety factor of 2. The steel rod has the maximum yield strength of 300 MPa. Determine the required diameter of the rod.


$$\sigma_{allow} = \frac{F}{\pi r^2} = \frac{\sigma_f}{N_s}$$

$$\frac{20000}{\pi r^2} = \frac{300 \times 10^6}{2}$$

$$r^2 = 4.24 \times 10^{-5}$$

$$r = 7.98 \times 10^{-3} \text{ m}$$

St. Venant's Principle




■ Far enough away from load, stresses follow theoretical values

NORMAL STRAIN


■ Strain from lengthening or shortening of material

$$\varepsilon = \frac{\delta}{L}$$



EXAMPLE: BALLOOON


■ Air filled balloon with original radius r_1 is pressurized until its radius becomes r_2 . What is its strain?



SHEAR STRAIN

■ Change in angular orientation of material

$$\gamma = \frac{\pi}{2} - \theta_f$$



HOOKE'S LAW

- How are stresses and strains related?
- Normal stress-strain

$$\sigma = E\varepsilon$$

■ Shear stress-strain

$$\tau = G\gamma$$

- E is Young's modulus or modulus of elasticity
- G is shear modulus

MATERIAL BEHAVIOR


- Most engineering materials have two regions
 - ► Elastic behavior: deformation is reversible
 - ▶ Plastic behavior: deformation is permanent

MATERIAL PROPERTY TESTING


■ Tensile Test: testing for material response



MATERIAL TYPES



STRESS - STRAIN DIAGRAM: DUCTILE



ELASTIC REGION

- Deformation is reversible → object returns to original shape once load is removed
- Most designed parts are meant to operate in this region


YIELD

- Transition from elastic to plastic deformation ~ material failure
- Difficult to specify exact location
- Definition can vary
 - 1. proportionality limit
 - 2. elastic limit
 - 3. offset yield point (0.2% rule)

STRAIN HARDENING

- Deformation in materials cause temperary hardness increases
- Material can take additional stress because of this

NECKING



- Final phase of plastic deformation before failure
- Cross-sectional area decreases → increased stress


STRAIN ENERGY

- Energy stored in deformed body
- Assumed equal to work done by external loadings

$$u = \frac{1}{2}\sigma\varepsilon$$
$$= \frac{1}{2}\frac{\sigma^2}{E}$$


- Area under $\sigma \varepsilon$ curve
- Important to material strength under impact loading

MODULUS OF RESILIENCE




■ Amount of energy to permanently deform body

MODULUS OF TOUGHNESS



■ Amount of energy to fracture body

SHEAR STRESS-STRAIN RELATIONSHIP



THERMAL STRAIN

- Change in temperature causes material deformation
 - material normally expands when heated and contracts when cooled
- Definition in 1-D

$$\alpha = \frac{1}{L} \frac{dL}{dT}$$

 \blacksquare α is called the coefficient of thermal expansion (CTE)

Properties of α

- \blacksquare α is typically a function of T
- For many engineering materials (solids), $\alpha \sim \text{constant}$

$$\delta = \int_0^L \alpha \Delta T dx$$


■ For uniform temperature change

$$\delta = \alpha \Delta T L$$

EXAMPLE: HEATED BAR

- If a beam has an original length of 2 m and initial T = 20 C
- The beam is heated, after which the temperature along the beam is $T(x) = 20x^2 + 10x + 30$ C. Beam has $\alpha = 2.5 \times 10^{-6}$
 - ▶ What is the deformation of the middle point of the beam?
 - ▶ What is the final length of the beam?

Poisson's Effect



 Material's lateral contraction (extension) under longitudinal tensile (compressive) load

$$v = -\frac{\varepsilon_{lat}}{\varepsilon_{long}}$$

■ v is called Poisson's ratio

₅5


Poisson's Ratio Range

Material	Poisson's ratio
rubber	0.4999
gold	0.42-0.44
saturated clay	0.40-0.49
magnesium	0.252-0.289
titanium	0.265-0.34
copper	0.33
aluminium-alloy	0.32
clay	0.30-0.45
stainless steel	0.30-0.31
steel	0.27-0.30
cast iron	0.21-0.26
sand	0.20-0.45
concrete	0.1-0.2
glass	0.18-0.3
foam	0.10-0.50
cork	0

■ Usual engineering materials have $0 \le v \le 0.5$

AUXETIC MATERIAL

- Materials that exhibit negative Poisson's ratios
- How is that possible?
- Rely on material microstructure
- Useful in many design situations



MECHANICAL STRAINS VS THERMAL STRAINS

- Strains caused by load vs temperature change
- Mechanical strains: normal strains + lateral strains from Poisson's effect
- Thermal strains: strains in all direction, no Poisson's effect.
- \bullet $\varepsilon_{\text{total}} = \varepsilon_{\text{mech}} + \varepsilon_{\text{therm}}$ (mind the signs)

MECH VS THERM STRAINS EXAMPLE

A circular cross-sectioned steel bar with radius r=1 cm and length L=2 m is stretched along its length by a stress of 100 MPa. If the steel has E=210 GPa, v=0.3, and $\alpha=16\times10^{-6}$ /° C, how much temperature change does it need to return to its original volume?

SOLUTION: MECH VS THERM STRAINS

Match before and after volumes before:

$$V_0 = \pi r^2 l$$

after:

$$l_1 = l\left(1 + \frac{\sigma}{E} + \alpha \Delta T\right)$$

$$r_1 = r\left(1 - v\frac{\sigma}{E} + \alpha \Delta T\right)$$

SOLUTION: MECH VS THERM STRAINS

$$Set V_0 = V_1$$

$$\pi r^2 l = \pi r^2 \left(1 - v \frac{\sigma}{E} + \alpha \Delta T \right)^2 l \left(1 + \frac{\sigma}{E} + \alpha \Delta T \right)$$

Keep only first-order terms:

$$0 = \frac{\sigma}{E} - v\frac{\sigma}{E} - v\frac{\sigma}{E} + 2\alpha\Delta T + \alpha\Delta T$$
$$\Delta T = \frac{-\sigma(1 - 2v)}{3\alpha E}$$
$$= -3.97 \text{ C}$$

THERMAL STRESS

■ Stress in a cooled/heated material constrained from deforming freely

EXAMPLE: HOT BAR / COOL BAR

- A metal bar is constrained between two walls the same distance as the beam's length, how would you change the temperature so that the beam is ...
 - ▶ in tension?
 - ▶ in compression?
- We can intuit the *direction* of temperature change (up or down), but not yet its magnitude (how much)
- We will learn that soon enough ...