For biaxial stresses (i.e., $\sigma_3 = 0$), σ_1 and σ_2 must plot within this area to avoid failure