# Introduction to Engineering Design

ME 310: Mechanical Design

Sappinandana Akamphon December 19, 2022

Department of Mechanical Engineering, TSE

### Outline

#### Overview of Bolted Joints

**Bolt Geometry and Properties** 

**Bolt Stress Analysis** 

Bolted Joint for Fatigue Loading

### **Bolted Joints**

Bolted joints are held by threaded fasteners


- Bolts
- Screws
- Nuts

What's the difference between a bolt and a screw?


### How Bolted Joints Work

- Clamped members are held together by compressive load from a bolt or screw
- · Bolt itself is under tensile load

# Applications of Bolted Joints



# Application of Bolted Joints 2



### Outline


Overview of Bolted Joints

**Bolt Geometry and Properties** 


**Bolt Stress Analysis** 

Bolted Joint for Fatigue Loading

# Thread Geometry




### **Thread Forms**




## Standard ISO Bolt Sizes

Nominal Diameter d	Coarse Threads				Fine Threads	
	Pitch	Minor ø	Stress Area	Pitch	Minor ø	Stress Area
3	0.5	2.39	5.03	-	-	-
3.5	0.6	2.76	6.78	-	-	-
4	0.7	3.14	8.78	-	-	-
5	0.8	4.02	14.2	-	-	-
6	1	4.77	20.1	-	-	-
7	1	5.77	28.9	-	-	-
8	1.25	6.47	36.6	1	6.77	39.2
10	1.5	8.16	58.0	1.25	8.47	61.2
12	1.75	9.85	84.3	1.25	10.5	92.1
14	2	11.6	115	1.5	12.2	125
16	2	13.6	157	1.5	14.2	167
18	2.5	14.9	192	1.5	16.2	216
20	2.5	16.9	245	1.5	18.2	272
22	2.5	18.9	303	1.5	20.2	333
24	3	20.3	353	2	21.6	384
27	3	23.3	459	2	24.6	496
30	3.5	25.7	561	2	27.6	621
33	3.5	28.7	694	2	30.6	761
36	4	31.1	817	3	32.3	865
39	4	34.1	976	3	35.3	1030
42	4.5	36.9	1121	-	-	-
48	5	42.7	1473	-	-	-


## How are Screw Threads Made?: Thread Rolling



## How are Screw Threads Made?: Thread Cutting



## Advantage of Rolled vs Cut Threads



### Strength of Bolts

- Because of threads and how they are formed, bolts are not loaded to their yield or ultimate tensile strength.
- Instead, bolt strength is measured by a proof strength,  $S_p$ .
- For approximation,  $S_p = 0.9S_y$

# **Bolt Material Strength**

SAE Class	Diameter d (mm)	Proof Strength S <sub>p</sub> (MPa)	Yield Strength S <sub>y</sub> (MPa)	Tensile Strength S <sub>ut</sub> (MPa)	Elongation (%)	Reduction of Area (%)
4.6	5 – 36	225	240	400	22	35
4.8	1.6 - 16	310	-	420	-	-
5.8	5 – 24	380	-	520	-	-
8.8	17 - 36	600	660	830	12	12
9.8	1.6 - 16	650	-	900	-	-
10.9	6 – 36	830	940	1040	9	9
12.9	1.6 – 36	970	1100	1220	8	8

# Head Markings Example



### Outline

Overview of Bolted Joints

**Bolt Geometry and Properties** 

**Bolt Stress Analysis** 

Bolted Joint for Fatigue Loading

## **Bolted Joint Stress Analysis**

- · Two modes of failure
- Thread failure  $\rightarrow$  shear stress in thread
- Tensile faiure  $\rightarrow$  tensile stress in bolt

#### Shear Stress in Threads

· Thread surface area is


$$A_{shear} = \pi d(0.75t)$$

 Allowable shear stress on bolt (MDET)

$$\tau_{allow} = \frac{S_y}{\sqrt{3}} = 0.577S_y$$

· Force to cause thread failure

$$F_{thread} = 0.577 S_y \pi d(0.75) t$$



#### **Bolt Tensile Stress**

· Bolt tensile area

$$A_t \approx \frac{\pi}{4} \left( 0.9d \right)^2$$

· Tensile load to yield the bolt threads

$$F_{bolt} = A_t S_y \approx \frac{\pi}{4} (0.9d)^2 S_y$$

## Preventing Thread Failure

- To prevent thread failure, make sure tensile failure happens first (or at the same time)
- Setting  $F_{bolt} = F_{nut}$

$$t = 0.47d$$

- The thickness nut or depth of threaded hole should be at least half major diameter.
- · Now we can worry only about tensile failure

## Torque - Tensile Load Relationship

• Setting  $\mu = 0.15$ 

$$T = 0.2F_i d$$

• Metal on metal friction is 0.15?

## **Proper Bolted Joints**

Correct bolt length and proper nut/threaded hole thickness

$$t \ge 0.47d$$


- Proper tightening with calculated torque  $\rightarrow$  torque wrench is vour friend
- Locking mechanism: locknuts, slotted nuts, two nuts, toothed lock washers.








## **Bolt-Joint Interaction**




# Types of Bolted Joints

- Tension Joints
- Friction Joints



## Load Distribution in Tension Joints



#### Load Distribution in Tension Joints with External Tensile Load

From previous diagram


$$F_b = P_b + F_i = CP + F_i$$

$$F_j = (1 - C)P - F_i$$

where  $C = k_b/(k_b + k_i)$ .

Load carried by bolt and clamped members depend on stiffness ratio

## **Bolted Joint Stiffness**



$$k_{total} = k_b + k_j$$

#### **Bolt Size Selection for Tension Joints**

The only job we have is to keep the clamped part together


$$F_j = 0 = (1 - C)P - F_i$$
$$P = \frac{F_i}{1 - C}$$

For non-permanent joints,  $F_i = 0.75S_pA_t$  and  $C \approx 0.25$ 

For the bolted joint to have a safety factor of  $N_s$ 

$$A_t = \frac{N_s P}{N S_p}$$

## **Friction Joints**



- Prevent members from sliding by friction not interference
- P<sub>shear</sub> · Compressive load exerted by bolt generate friction

#### **Bolt Size Selection for Friction Joints**

$$P_{shear} = -\mu F_j$$

Again assuming \$  $F_i$  = 0.75  $S_p$   $A_t$ \$ and C = 0.25

$$P_{shear} = -\mu F_{j} = -\mu (P(1 - C) - F_{i})$$

$$= \mu (0.75S_{p}A_{t} - 0.75P)$$

$$A_{t} = \frac{1}{S_{p}} \left( \frac{P_{shear}}{0.75\mu} + P \right)$$

For safety factor  $N_s$  with N bolts

$$A_t = \frac{N_s}{NS_p} \left( \frac{P_{shear}}{0.75\mu} + P \right)$$

## Flange Joints

- · Circular bolt arrays for sealing purpose.
- · Mainly used for pipe connections and pressure vessels






## Gasketed Flange Joints



- soft materials: rubber, plastic, or soft metals between clamped member
- How does that help?
- · How does it effect the joint strength?


# Equation for Flange Joints



$$3 \leqslant \frac{\pi D_b}{Nd} \leqslant 6$$

## Flange Joint on Pressure Vessel Example

A cylindrical pressure vessel is pressurized to 10 MPa. The cross section of the vessel is shown below. The flange joint to keep the cover on the vessel is made up of 12 grade 12.9 M8 coarse thread bolts. Is this joint safe? If not, determine the proper bolt size.



#### Solution

• Assume constant pressure,  $N_s = 2$ 

$$A_t = \frac{PN_s}{S_p}$$

· The vertical load comes from the pressure force, which is

$$P_{total} = p\pi r^2 = 10 \times 10^6 \times \pi \times 0.5^2 = 7.85 \text{ MN}$$

 We will assume that the load is distributed evenly on all 12 bolts, so that

$$P = \frac{P_{total}}{N} = \frac{7.85 \text{ MN}}{12} = 6.54 \times 10^5 \text{ N}$$

 Assume that we use the bolt material grade 12.9 whose proof strength is 970 MPa, the required tensile area is

$$A_{\rm t} = \frac{(2)(6.54 \times 10^5)}{970 \times 10^6} = 1.35 \times 10^{-3} \text{ m}^2 = 1350 \text{ mm}^2$$

- The calculated required tensile area, even with the strongest material (grade 12.9), is larger than M8 coarse thread (36.6 mm<sup>2</sup>) and therefore the given design is unsafe!
- Redesigning the flange joint, it must satisfy the sizing equation above and the bolt distance equation, namely

$$3 \leqslant \frac{\pi D_b}{Nd} \leqslant 6$$

• Since  $D_b$  = 150 cm, set the inequality to 4.5 to solve.

$$\frac{\pi D_b}{Nd} = 4.5$$

$$Nd = 1.05$$

 Reapply the tension joint equation to determine the total required tensile area, we have

$$NA_t = \frac{N_s P}{S_p} = \frac{2(7.85 \times 10^6)}{970 \times 10^6}$$
$$= 1.62 \times 10^{-2} \text{ m}^2$$

- · 2 equations, 3 unknowns
- · Are the unknowns all independent?

$$A_t \approx \frac{\pi}{4} (0.9d)^2$$
 $NA_t \approx N(0.81) \frac{\pi}{4} d^2 = 1.62 \times 10^{-2}$ 
 $Nd^2 = 2.58 \times 10^{-2}$ 

· Solving the system of equations, we have

$$\frac{Nd^2}{Nd} = \frac{2.58 \times 10^{-2}}{1.05} = 0.0245 \text{ m} = 24.5 \text{ mm}$$

- Since there is no standard bolts with that size, we pick the next larger bolt, M27  $\times$  2 (fine thread)
- Finally,  $A_t = 496 \text{ mm}^2$  (from M27) is used to solve for the number of required bolts

$$N = \frac{1.62 \times 10^{-2}}{496 \times 10^{-6}} = 25.4$$

• Therefore, we need 26 M27  $\times$  2 for this flange joint.

## Outline

Overview of Bolted Joints

**Bolt Geometry and Properties** 

**Bolt Stress Analysis** 

Bolted Joint for Fatigue Loading

# **Bolt Sizing for Fatigue Loading**

 If properly tightened, endurance limit of bolt is constant regardless of average stress

$$N_{\rm S} = rac{S_e}{\sigma_a}$$
 
$$\sigma_a = rac{{\it CK_f}(P_{
m max} - P_{
m min})}{2{\it NA}_t}$$

# Bolt Strength under Fatigue


Material Grade	Endurance Limit (S <sub>e</sub> )
8.8	129 MPa
9.8	140 MPa
10.9	162 MPa
12.9	190 MPa

## Stress Concentration Factor of Bolts

Hardness	SAE Class (ISO Threads)	<i>K<sub>f</sub></i> Rolled threads	<i>K<sub>f</sub></i> Cut threads
Below 200 Bhn (annealed)	5.8 and below	2.2	2.8
Above 200 Bhn (hardened)	8.8 and above	3.0	3.8

# Bolted Joint Design under Fatigue Example

A cylindrical pressure vessel is pressurized and depressurized repeatedly between 0 and 10 MPa during its operation. The cross section of the vessel is shown below. Design a proper flange joint with a safety factor of 2.



- · Definitely fatigue related
- Max load = 7.85 MN, from previous example
- Min load = ?

$$\sigma_{\text{max}} = \frac{CK_f P_{\text{max}}}{NA_t} = \frac{0.25(3)(7.85 \times 10^6)}{NA_t} = \frac{5.89 \times 10^6}{NA_t}$$

$$\sigma_{\text{min}} = 0$$

$$\sigma_a = \frac{2.94 \times 10^6}{NA_t}$$

• Grade 12.9  $\rightarrow$   $S_e$  = 190 MPa

$$N_{s} = 2 = \frac{S_{e}}{\sigma_{a}} = \frac{190 \times 10^{6}}{\frac{2.94 \times 10^{6}}{NA_{t}}}$$

$$NA_{t} = 3.10 \times 10^{-2} \text{ m}^{2}$$

· Check for yield under tensile load.

$$NA_t = \frac{N_s P}{S_p} = \frac{2(7.85 \times 10^6)}{970 \times 10^6} = 1.62 \times 10^{-2} \text{ m}^2$$

- Fatigue requires larger area ightarrow deciding factor

$$\frac{\pi D_b}{Nd} = 4.5$$

$$Nd = 1.05$$

· We can then solve for the required diameter.

$$\begin{split} NA_t &= N(0.8) \frac{\pi}{4} d^2 = 3.10 \times 10^{-2} \\ Nd^2 &= 4.93 \times 10^{-2} \\ \frac{Nd^2}{Nd} &= \frac{4.93 \times 10^{-2}}{1.05} = 0.047 \text{ m} \end{split}$$

• The required bolts are then M48  $\times$  5, and the required number of bolts is

$$N = \frac{3.10 \times 10^{-2}}{1473 \times 10^{-6}} = 21$$

 $\cdot$  So we would need 21 M48 imes 5 bolts.

# Final Notes on Bolted Joint Design for Fatigue Loading

- Properly tighten bolt
- · Choose rolled threads whenever possible

Any Questions?