Flexible Mechanical Elements

ME 313: Mechanical Design Week 8



What are Flexible Mechanical Elements?

- Elastic elements used in conveying and transmission of power
 - ▶ Belts, ropes, chains, etc..
- Used to transmit power over long distance
- ▶ Replace gears, shafts, and/or bearings



Advantages of Using Flexible Elements

- Absorb shock loads and isolate vibrations
- Simplify design
- Save cost



Dr. Sappinandana Akamphon

Belts

- Usually coupled with pulleys
- Cheapest method of power transmission
- Shafts do not have to align
- Very little noise
- No lubrication and small maintenance required





Types of Belts

- Flat belts
 - Simple, flat rectangular cross section



- Round belts
 - Circular cross section





Trapezoidal cross section



- ▶ Timing Belts
 - Have teeth to match toothed pulley






Dr. Sappinandana Akamphon

Flat and Round Belt Drives

 Belts usually consists of elastic core surrounded by an elastomer



Contact angles

$$\theta_d = \pi - 2\sin^{-1}\frac{D - d}{2C}$$

$$\theta_D = \pi + 2\sin^{-1}\frac{D - d}{2C}$$



Length of Belt

$$L = \left[4C^2 - (D - d)^2\right]^{1/2} + \frac{1}{2}(D\theta_D + d\theta_d)$$

When the belts are crossed, contact angles are the same

$$\theta = \pi + 2\sin^{-1}\frac{D+d}{2C}$$

And length is


$$L = [4C^2 - (D-d)^2]^{1/2} + \frac{\theta}{2}(D+d)$$



Dr. Sappinandana Akamphon

Belt Tension

• Assume belt mass is very small, pulley and belt has coefficient of friction μ and angle of contact θ



F₂: 100se side

$$F_2 = F_1 e^{-\mu\theta}$$



Torque Transmission

 Torque transmission is related to the difference in belt tensions

$$F_{1} - F_{2} = \frac{T}{D/2} = \frac{2T}{D}$$

$$F_{1}(1 - e^{-\mu\theta}) = \frac{2T}{D}$$

$$F_{1} = \frac{2T}{D(1 - e^{-\mu\theta})}$$



Dr. Sappinandana Akamphon

Power Transmission

ightharpoonup If belt is moving at speed ν , then

$$P = (F_1 - F_2)v$$



V Belts



- Standard V belt cross section is usually 40 degree trapezoid
- The pulleys also have grooves for belts to fit into
- This allows the belt to fit further into the groove as belt tension increases



Dr. Sappinandana Akamphon

Torque Transmission

Belt friction depends on the angle on the grooves

Groove Angles	Coefficient of Friction
30	0.5
34	0.45
38	0.4

$$F_1 - F_2 = \frac{T}{D/2} = \frac{2T}{D}$$

$$F_1 = \frac{2T}{D(1 - e^{-\mu\theta})}$$



Timing Belts




- Belt teeth to fit into grooves of pulley
 - Prevent slipping and eliminate need for initial belt tension
 - Transmits power at constant velocity
- Require no lubrication, quiet operation
- Attractive solution for precisiondrive



Dr. Sappinandana Akamphon

Roller Chains






 Chains of constant pitch, coupled with a sprocket, for power transmission




Roller Chain Geometry



▶ Pitch, *p*

Distance between adjacent chains



 Angle between adjacent teeth

$$\sin\frac{\gamma}{2} = \frac{p/2}{D/2}$$

$$D = \frac{p}{\sin(\gamma/2)}$$

Dr. Sappinandana Akamphon



▶ If there are N teeth on the sprocket, and roller chain has pitch p

$$D = \frac{p}{\sin(180/N)}$$



Chain Velocity

$$v = Np\omega$$

- ν = chain velocity
- ▶ *N* = number of sprocket teeth
- p = chain pitch
- $\omega = \text{angular velocity}$
- However, chain velocity is not constant, due to sprocket uneven radius

$$v_{\text{max}} = \frac{\omega p}{2\sin(\gamma/2)}$$
$$v_{\text{min}} = \frac{\omega p \cos(\gamma/2)}{2\sin(\gamma/2)}$$



Dr. Sappinandana Akamphon

Chordal Speed Variation

▶ The variation in speed is

$$\frac{\Delta v}{v} = \frac{v_{\text{max}} - v_{\text{min}}}{v} = \frac{\pi}{N} \left[\frac{1}{\sin(180/N)} - \frac{1}{\tan(180/N)} \right]$$

This is called the *chordal speed variation*



Chain Failure

- ▶ Chains seldom fail because they lack tensile stress
- There mode of failure is usually from long hours of service due to wear on the rollers or pins and fatigue of rollers



Dr. Sappinandana Akamphon

Wire Rope

- Made up of windings of wire into strands, and of strands into rope
- Many uses especially in very long and heavy load carriers
 - Elevators
 - Mineshafts





Stress in Wire Rope

From beam bending

$$M = \kappa EI = \frac{EI}{R}$$
 and $M = \frac{\sigma I}{c}$

- ► *M* = bending moment
- κ = curvature
- ► *E* = Young's modulus
- I = moment of inertia

$$ightharpoonup R$$
 = radius of curvature

c = furthest distance from neutral axis

$$\sigma = E_r \frac{d_w}{D}$$

- E_r = Young's modulus of rope
- $d_w =$ wire diameter

D = sheave diameter (radius of curvature of wire rope)



Dr. Sappinandana Akamphon

Importance of Pulley Diameter vs Rope Diameter

- The smaller the pulley diameter, the higher the bending stress
- When analyze stress in the rope, must consider both tensile and bending stress
- General rule:

$$\frac{D}{d_w} \ge 400$$

e.g. mine shafts and elevators, the ratio goes from 800-1000



Elevator Problem

 Assume rope is massless, rope tension due to load acceleration-deceleration is

$$F_t = \frac{W}{n} \left(1 + \frac{a}{g} \right)$$

- ₩ is weight at the end of the rope
- n is the number of wire ropes supporting the load
- ▶ Therefore the total stress in the rope is

$$\sigma_{total} = \sigma_{bending} + \sigma_{t}$$

$$= E_{r} \frac{d_{w}}{D} + \frac{W}{nA} \left(1 + \frac{a}{g} \right)$$



Dr. Sappinandana Akamphon

Questions?

