

30 DAY SPACES

# Weekend Laundry Alcove

Measured layouts and calm surfaces for Indian apartments.

Akarsh Priyadarshan

30 DAY SPACES

# Weekend Laundry Alcove

Akarsh Priyadarshan

© 2026 Akarsh Priyadarshan. All rights reserved.

Interior designed for Amazon KDP print (6 × 9 in) and Kindle.

Photographs: Photo by Max Vakhtbovych on Pexels; Photo by Engin Akyurt on Pexels; Photo by American Cleaning Institute on Pexels; Photo by Leonid Altman on Pexels; Photo by Los Muertos Crew on Pexels; Photo by Nothing Ahead on Pexels; Photo by Deane Bayas on Pexels; Photo by Ivett M on Pexels; Photo by hi room on Pexels; Photo by Francesco Ungaro on Pexels; Photo by Rodrigo Simoes on Pexels; Photo by Thirdman on Pexels; Photo by Sandra Filipe on Pexels; Photo by Stephan Yorchenko on Pexels; Photo by Chengxin Zhao on Pexels; Photo by Ono Kosuki on Pexels; Photo by Karina Badura on Pexels; Photo by Anete Lusina on Pexels; Photo by Mark Stebnicki on Pexels; Photo by RDNE Stock project on Pexels; Photo by Tahir Xəlfəquliyev on Pexels; Photo by Tiger Lily on Pexels; Photo by Freek Wolsink on Pexels; Photo by Tima Miroshnichenko on Pexels; Photo by Anisha Deb on Pexels; Photo by Ty Nguyễn on Pexels; Photo by Alec Adriano on Pexels; Photo by Mathias Reding on Pexels; Photo by Jan van der Wolf on Pexels; Photo by panumas nikhomkhai on Pexels; Photo by SHVETS production on Pexels; Photo by Cup of Couple on Pexels; Photo by Vlad Deep on Pexels; Photo by Đỗ Huy Hoàng on

Pexels; Photo by Ivan S on Pexels; Photo by Hoài Nam on Pexels; Photo by https://kaboompics.com/ on Pexels; Photo by Aditya Oberai on Pexels; Photo by Keegan Checks on Pexels; Photo by Adrien Olichon on Pexels.

INSIDE THIS BOOK

# Contents


The Under-$200 Weekend Alcove Makeover Blueprint

Planning Your Alcove Makeover

Shopping for Your Makeover

Building Your Custom Shelves and Countertop

Maximizing Your Laundry Alcove

Understanding Your Space

Choosing the Right Materials

Planning Your Layout

Building a Sturdy Laundry Countertop

Cut List Matrix

Aisle By Aisle Shopping Map

Moisture Safe Finishing Stack

Countertop Span And Stiffness

Creating a Functional Laundry Alcove

Understanding Your Space

Fastening and Support

Final Assembly and Organization

Optimizing Laundry Alcoves

Small Rental Alcove With Stacked Machines

Wide Owner Alcove With Side By Side Machines

Common Mistakes in Home Renovation

Ignoring Moisture

Missing Studs

Rushing Finish Coats

Forgetting Service Access

Moving Machines Roughly

Preparing for Your Alcove Project

Measuring Your Alcove

Choosing Materials and Hardware

Gathering Tools and Supplies

Assess, Measure, And Plan Your Alcove

Budgeting And Bill Of Materials Under $200
Understanding Your Budget
Material Selection
Calculating Yields
Finalizing Your Bill of Materials
Aisle-By-Aisle Shopping Maps And Tool Prep
The Aisle Map And Prep System
Requesting Store Cuts Safely
The Minimum Tool Kit That Will Not Fail You
Cut Lists And Modular Components
Renter-Friendly Build And Smart Storage
Base First: Building the Floor Platform
Press Fit Uprights: Creating a Non-Invasive Skeleton
Selective Fasteners: Using French Cleats
Smart Storage Sizing and Organization
Cable and Hose Management
Finishing Touches and Removal Plan
Owner Upgrade Path, Trim, And Moisture Protection
Fastening Into Studs
Trim That Hides Edges
Moisture Safe Finish Stack
Water And Lint Protection
The 48-Hour Weekend Schedule
Friday Evening: Confirm And Prep
Saturday Morning: Acquire And Stage
Saturday Midday: Build The Core
Sunday: Finish And Hardware
Troubleshooting Old Houses And Tight Clearances
Understanding Fit Problems
Managing Clearance Conflicts
Leveling Appliances and Controlling Vibration
Moisture Management Solutions
Printable Measurement Templates And Label Set
Aisle-By-Aisle Shopping Maps For Major Home Centers
Navigating Home Depot
Shopping at Lowe's

Finding Items at Menards
48-Hour Weekend Build Checklist
Purpose and Benefits
How to Use
Friday Evening: Prep and Plan
Saturday Morning: Shopping



CHAPTER

# The Under-$200 Weekend Alcove Makeover Blueprint

Transform your laundry alcove into a functional and stylish space without breaking the bank. This chapter provides a comprehensive guide to achieving a complete makeover for under $200, all in just one weekend.



DAY 1

# Planning Your Alcove Makeover

*IN THIS APARTMENT*

*Riya lives in a 1BHK apartment in Pune with a small laundry alcove that has a 5-foot width. She wants to maximize the space for better organization and functionality.*

> **Effective planning is crucial for a successful alcove makeover.**

Start by measuring your alcove space accurately. For Riya's 5-foot alcove, ensure you account for any obstructions like plumbing or electrical outlets. This will help you determine the best layout for your new shelves and countertop.

Create a list of materials needed for the project, keeping the budget under $200. Focus on essential items like plywood for shelves, a countertop surface, brackets, and paint or finish. Riya can use a simple moisture-safe finish that dries overnight to save time.

Sketch a basic layout of your alcove, indicating where each element will go. This visual guide will help you stay on track during the build process and ensure everything fits as planned.

**DO THIS**

1. Measure the width and height of your alcove accurately.
2. List all materials and tools needed for the project.
3. Create a layout sketch to visualize the new setup.

**WHERE THIS GOES WRONG**

Failing to measure accurately can lead to costly mistakes and delays.

**BEFORE YOU MOVE ON**

- [ ] Measure alcove dimensions
- [ ] List materials and tools
- [ ] Sketch layout design



DAY 1

# Shopping for Your Makeover

*IN THIS APARTMENT*

*Riya heads to a local home improvement store in Pune to gather materials for her laundry alcove project, armed with her shopping list and layout sketch.*

> **A well-planned shopping trip saves time and ensures you get everything you need.**

Use an aisle-by-aisle shopping map to navigate the home center efficiently. This will help Riya find all the materials quickly, avoiding unnecessary backtracking and time wastage.

Stick to your list to prevent impulse purchases that can blow your budget. Riya should focus on essential items like plywood, brackets, and finishing materials to stay within her $200 limit.

Ask store employees for assistance if you have trouble locating specific items. They can help you find the right materials and may even suggest alternatives that fit your budget better.

**DO THIS**

1. Bring your layout sketch and shopping list to the store.
2. Follow the store's aisle map to find materials efficiently.
3. Stick to your budget and avoid impulse buys.

**WHERE THIS GOES WRONG**

Not having a clear shopping list can lead to overspending and forgetting essential materials.

**BEFORE YOU MOVE ON**

- [ ] Prepare a shopping list
- [ ] Use a store map
- [ ] Stick to the budget



DAY 2

# Building Your Custom Shelves and Countertop

*IN THIS APARTMENT*

*On the second day, Riya sets up her workspace in her Pune apartment to begin building the custom shelves and countertop for her laundry alcove.*

> **Building custom shelves and a countertop enhances functionality and utilizes space effectively.**

Start by cutting the plywood to the required dimensions for the shelves and countertop. For Riya's 5-foot alcove, she can create two shelves, each 24 inches deep, ensuring they are sturdy enough to hold laundry supplies.

Install brackets to support the shelves. Use a level to ensure they are straight and spaced evenly. Riya should position the bottom shelf 36 inches above the floor to allow for easy access to the countertop below.

Once the shelves are installed, place the countertop on top. Ensure it is securely attached to the brackets and fits snugly against the walls. Riya can finish the surface with a moisture-safe sealant that dries overnight, providing durability against spills.

**DO THIS**


1. Cut plywood to size for shelves and countertop.
2. Install brackets and ensure they are level.
3. Attach the countertop securely and finish with sealant.

**WHERE THIS GOES WRONG**

Improper installation of shelves can lead to instability and potential damage.

**BEFORE YOU MOVE ON**

- Cut plywood accurately
- Install brackets securely
- Finish countertop with sealant



CHAPTER

# Maximizing Your Laundry Alcove

Transforming a laundry alcove into a functional space is essential for maintaining order in your home. With the right approach, you can create a well-organized area that meets your needs without breaking the bank.



DAY 1

# Understanding Your Space

*IN THIS APARTMENT*

*Ravi lives in a 1BHK apartment in Pune with a laundry alcove that measures 4 feet wide and 2 feet deep. The walls are uneven, and he struggles with moisture issues due to the nearby washing machine.*

> **Identify the specific dimensions and challenges of your laundry alcove before starting your project.**

Most laundry alcoves start as a hole in the wall with two expensive boxes crammed inside. To avoid this, measure your space accurately. Ravi's alcove, at 4 feet wide, requires careful planning to maximize functionality without overcrowding.

Consider the tight clearances and uneven walls that may complicate your project. Ravi needs to account for these factors when selecting materials and designing his layout. Moisture exposure is another concern, especially in a laundry area, so choose materials that can withstand humidity.

A clear scope is essential. For Ravi, this means focusing on immediate function: a wall-to-wall countertop, two to three adjustable shelves, and labeled storage zones. Avoid plumbing moves or electrical reroutes that could complicate the project.

> **WHERE THIS GOES WRONG**
>
> Overlooking the need for moisture-resistant materials can lead to damage and increased costs down the line.

**BEFORE YOU MOVE ON**

- Measure the alcove dimensions accurately.
- Identify potential moisture issues.
- Plan for immediate functionality with a countertop and shelves.



DAY 2

# Choosing the Right Materials

*IN THIS APARTMENT*

*Sneha's Bengaluru rental has a laundry alcove with a load-bearing wall, making it challenging to install traditional shelving. She needs to choose materials wisely to ensure stability and durability.*

> **Select materials based on defined checkpoints to balance budget, time, and durability.**

When selecting materials for your laundry alcove, consider the trade-offs between options like plywood and medium density fiberboard (MDF). For Sneha, MDF may be a better choice due to its cost-effectiveness and ease of installation, especially with her load-bearing wall.

Decision checkpoints are crucial. Sneha should decide on the materials before heading to the store to avoid impulse purchases. Each choice should reflect her budget and the durability needed for a laundry space.

Avoid custom metalwork unless absolutely necessary. Instead, focus on adjustable shelving solutions that can fit her specific alcove dimensions without the need for extensive modifications.

> **WHERE THIS GOES WRONG**
>
> Choosing expensive materials without considering their necessity can lead to budget creep and wasted resources.

**BEFORE YOU MOVE ON**

- Evaluate the pros and cons of plywood versus MDF.
- Decide on shelving methods before shopping.
- Stick to a budget for materials.



DAY 3

# Planning Your Layout

*IN THIS APARTMENT*

*Aditi's Mumbai flat has a laundry alcove with a window on only one side, limiting natural light. She needs to plan her layout to maximize both functionality and aesthetics.*

> **Use measuring templates to ensure your design fits perfectly within the space.**

To create an effective layout, use printable templates scaled to common alcove widths. Aditi should capture the width, depth, and height of her space, including baseboards, valves, vents, trim, and door swing. This ensures that her design is practical and fits well within the constraints of her alcove.

A well-planned layout will help Aditi avoid common pitfalls, such as overcrowding the space or blocking access to essential utilities. By considering the window placement, she can also enhance the overall aesthetics of her laundry area.

Bring these templates to the store and to the saw. Aditi can use them to visualize how her chosen materials will fit in her alcove, allowing for adjustments before making any cuts.

> **WHERE THIS GOES WRONG**
>
> Failing to account for all elements in the alcove can lead to a design that does not function as intended.

**BEFORE YOU MOVE ON**


- Create printable templates for your alcove dimensions.
- Include all elements like baseboards and vents in your planning.
- Visualize the layout with materials before cutting.



CHAPTER

# Building a Sturdy Laundry Countertop

Creating a functional and durable laundry countertop is essential for maximizing space in your home. This guide will walk you through the necessary steps, materials, and considerations to build a sturdy countertop that fits your needs.



DAY 1

# Cut List Matrix

*IN THIS APARTMENT*

*Ravi lives in a 1BHK apartment in Pune with a limited laundry space. He needs to build a countertop that fits his washing machine and dryer snugly.*

> **A precise cut list ensures material efficiency and cost-effectiveness.**

Once you know your countertop width and depth, select the matching cut list. This matrix drives material yield and cost, avoiding risky long rips without a table saw by utilizing cuts that a store can do for you.

### If Your Span Is Over 62 Inches

| Parameter | Value |
| --- | --- |
| Spec 1 | **62 in** |

If your span is over 62 inches, consider a center support cleat or a shallow divider that doubles as a hamper lane.

Start your project by determining the dimensions of your countertop based on the appliances it will support. For Ravi, measuring the width of his washing machine and dryer will help him decide on the countertop size.

Using a pre-determined cut list will streamline your shopping and assembly process, ensuring you have the right materials and minimizing waste.

> **WHERE THIS GOES WRONG**
>
> Failing to measure appliances accurately can lead to a countertop that doesn't fit.




DAY 1

# Aisle By Aisle Shopping Map

*IN THIS APARTMENT*

*Sneha is shopping for materials in a Bengaluru hardware store, navigating through the aisles to gather everything needed for her countertop.*

> **A systematic shopping approach prevents improvisation and ensures you have all necessary materials.**

Walk the store once, starting at the lumber section for sheet goods and cleats, then proceed to fasteners, paint, and finally organization supplies. This methodical approach will help you gather everything efficiently.

Sneha should have a bill of materials prepared before entering the store, which is store verified. This means she won't need to improvise on the spot, reducing the risk of forgetting essential items.

By following this shopping map, you can ensure that you have all the components needed for your project, from the structural elements to the finishing touches.

> **WHERE THIS GOES WRONG**
>
> Skipping aisles can lead to missing crucial materials.



DAY 2

# Moisture Safe Finishing Stack

*IN THIS APARTMENT*

*Anjali is preparing to finish her laundry countertop in her Mumbai flat, where humidity is a concern.*

> **Proper finishing techniques protect your countertop from moisture damage.**

Use a primer that seals edges, followed by a durable top coat that cures quickly. Simple, common products often outperform exotic finishes, especially under time constraints.

For Anjali, applying a shellac or oil-based primer on raw edges will provide fast sealing, followed by a water-based cabinet enamel for the top coat. This combination will ensure durability and a smooth finish.

Remember, water-based top coats dry quickly and have minimal odor, allowing for recoating on the same day, which is ideal for a weekend project.

> **WHERE THIS GOES WRONG**
>
> Neglecting to seal edges can lead to moisture absorption and damage.



DAY 2

# Countertop Span And Stiffness

*IN THIS APARTMENT*

*Karan is building a countertop that spans 65 inches between two walls in his Pune apartment.*

> **Understanding span and stiffness is crucial for a solid countertop.**

Your countertop will likely span between two side walls. A three-quarter inch plywood top supported by cleats on all three sides will feel solid for typical widths. Karan should ensure that his countertop is adequately supported to prevent sagging.

### If Your Span Is Over 62 Inches

| Parameter | Value |
| --- | --- |
| Spec 1 | **62 in** |

If Your Span Is Over 62 Inches

For spans over 62 inches, like Karan's 65-inch span, consider adding a center support cleat or a shallow divider that doubles as a hamper lane. This will enhance the structural integrity of the countertop.

Adding a one by two front edge band glued and nailed to the plywood edge creates a beam effect that resists sag and hides layers of plywood, ensuring a sturdy and visually appealing finish.

> **WHERE THIS GOES WRONG**
>
> Ignoring the need for support in wider spans can lead to sagging.



CHAPTER

# Creating a Functional Laundry Alcove

Transform your laundry space into an organized, efficient area with these practical steps tailored for Indian apartments.



DAY 1: PLANNING AND PREPARATION

# Understanding Your Space

*IN THIS APARTMENT*

*Riya lives in a 1BHK in Pune with a 9-foot living room. She needs to optimize her laundry alcove for a stacked washing machine setup.*

> **Effective planning maximizes the utility of your available space.**

Begin by measuring the depth from the back wall to the front face of your machines, including any plumbing protrusions. This measurement is crucial for determining the layout of your alcove. Riya uses a measuring tape to get accurate dimensions, ensuring she captures any baseboard thickness that may affect the installation of side cleats.

### A Stud Is Usually 16 Inches On

| Parameter | Value |
|---|---|
| Spec 1 | **16 in** |

A stud is usually 16 inches on center in newer homes, but old houses vary.

Next, create measuring templates that will help you visualize the space. These templates should include the depth measurements and any other relevant dimensions. Riya sketches out her templates on graph paper, marking the locations for her machines and any shelving she plans to install.

Finally, use the measurements to select a cut list variant that fits your width and depth while maximizing yield from standard sheet sizes. Riya decides to rip one four by eight sheet into two equal strips for shelves and a third strip for cleats, reducing her saw time at home.

> **WHERE THIS GOES WRONG**
>
> Neglecting to measure accurately can lead to costly mistakes during installation.



DAY 1: INSTALLATION BASICS

# Fastening and Support

*IN THIS APARTMENT*

*Riya needs to ensure her machines are securely fastened in her rental apartment.*

## Proper fastening is essential for stability and safety.

To provide strength, fasten cleats into studs and use appropriate anchors where studs do not align. Riya uses a stud finder to locate the studs in her wall, confirming their positions with small pilot holes. She learns that in her older Pune apartment, the studs are not consistently spaced, so she must adapt her fastening strategy accordingly.

For rental safe options, Riya mounts cleats with screws into studs wherever they align. For sections that miss studs, she opts for heavy-duty removable anchors. This ensures that her installation is secure without damaging the walls of her rental.

Pre-drilling all holes is a crucial step to avoid splitting the cleats and to make driving screws easier. Riya takes her time to pre-drill each hole, ensuring a smooth installation process.

> **WHERE THIS GOES WRONG**
>
> Using inadequate fasteners can compromise the stability of your installation.



DAY 2: COMPLETING THE SETUP

# Final Assembly and Organization

*IN THIS APARTMENT*

*Riya is ready to install her countertop and organize her laundry supplies.*

> **A well-organized setup enhances functionality and ease of use.**

After confirming the width with a dry fit of the countertop blank, Riya sands the edges smooth to prevent splinters. She then cuts the cleats to length and pre-drills them at intervals, marking stud locations as she goes. This preparation is essential for a clean and efficient installation.

With the cleats installed, Riya sets the countertop in place, ensuring it is level. If the walls bow, she carefully scribe the edges and shaves them as needed before reinstalling with glue on the cleats and screws from below into the edge band. This attention to detail ensures a professional finish.

Once the countertop is secure, Riya applies the first coat of finish to all exposed surfaces. While it dries, she assembles bins for organization, labeling them for easy access. She mounts adjustable shelf supports and sets the shelves on cleats, ensuring that her laundry supplies are neatly organized and within reach.

> **WHERE THIS GOES WRONG**
>
> Skipping the sanding and finishing steps can lead to a rough and unappealing surface.



CHAPTER

# Optimizing Laundry Alcoves

Laundry alcoves can be a challenge in both small and wide spaces, but with the right approach, they can be transformed into functional areas. This chapter explores how to effectively utilize these spaces, ensuring that every inch is maximized for storage and usability.



DAY 1

# Small Rental Alcove With Stacked Machines

*IN THIS APARTMENT*

*Ravi lives in a 1BHK apartment in Pune with a laundry alcove that is 34 inches wide and features a bowed wall and a gas dryer vent. He needs to optimize this tight space for his stacked washing and drying machines.*

## Maximize vertical space with smart shelving solutions.

To begin, Ravi selects plywood for all surfaces, ensuring durability and a clean look. He uses cleats anchored into two studs on one side of the alcove, while on the other side, where no studs align, he opts for removable anchors to maintain stability without damaging the wall.

### The Space Is 34 Inches Wide With

| Parameter | Value |
| --- | --- |
| Spec 1 | **34 in** |

The Space Is 34 Inches Wide With

Next, he installs one deep shelf at eye height, perfect for storing detergent and other laundry essentials. Above this, a narrow shelf holds lighter items, keeping everything organized and easily accessible. Since the machines are stacked, a countertop is unnecessary, allowing Ravi to allocate his budget towards better storage bins and a cabinet enamel top coat for a polished finish.

### The Space Is 62 Inches Wide With

| Parameter | Value |
| --- | --- |
| Spec 1 | **62 in** |
| Spec 2 | **16 in** |

The space is 62 inches wide with studs at 16 inches on center.

The entire project takes about 42 hours to complete, with the only wall damage being tiny anchor holes, which are easily repairable. Ravi sweeps and mops the area, then photographs the result, proud of his efficient use of space.

**DO THIS**

1. Select plywood for surfaces.
2. Use cleats anchored into studs and removable anchors where needed.
3. Install shelving at eye height and above for optimal storage.

**WHERE THIS GOES WRONG**

Neglecting to account for the bowed wall can lead to misaligned shelves.

**BEFORE YOU MOVE ON**

Measure the alcove dimensions accurately.

Choose appropriate materials for durability.

Plan shelf heights based on storage needs.



DAY 2

# Wide Owner Alcove With Side By Side Machines

*IN THIS APARTMENT*

*Anjali owns a spacious 2BHK in Bengaluru with a laundry alcove that measures 62 inches wide, featuring studs at 16 inches on center. She wants to create a functional space for her side-by-side washing machines.*

> **Utilize sturdy materials and proper anchoring for stability.**

Anjali chooses plywood for the countertop, ensuring it can withstand the weight of her machines and laundry. For the high shelf, she selects MDF, which is lightweight yet strong enough for her needs. All cleats are anchored directly into the studs, using pocket screws for added security, which is crucial for a stable installation.

### The Space Is 62 Inches Wide With

| Parameter | Value |
| --- | --- |
| Spec 1 | **62 in** |
| Spec 2 | **16 in** |

The Space Is 62 Inches Wide With

To enhance the countertop's durability, she adds a one by two edge band to stiffen the top. The front edge is rounded with sandpaper for a smooth finish, and she seals it with two coats of polyurethane, providing a protective layer against moisture.

A center divider under the countertop creates two hamper lanes, allowing for organized sorting of laundry. After the finish cures overnight, Anjali finds that the surface is rock solid, making it easy for her family to fold laundry on Sunday afternoons.

### DO THIS

1. Select plywood for the countertop and MDF for the high shelf.
2. Anchor cleats into studs using pocket screws.
3. Create a center divider for organized laundry sorting.

### WHERE THIS GOES WRONG


Forgetting to round the edges of the countertop can lead to splintering.

### BEFORE YOU MOVE ON

Measure the alcove width and stud placement.

Choose materials that suit the weight and usage.

Ensure all anchors are secure before use.



CHAPTER

# Common Mistakes in Home Renovation

Avoiding common pitfalls in home renovation can save time and money. This chapter outlines frequent mistakes and how to prevent them, ensuring a smoother renovation process.



DAY 1

# Ignoring Moisture

*IN THIS APARTMENT*

*Ravi, living in a 1BHK in Pune, recently painted his kitchen cabinets but noticed the edges swelling after a few weeks. He realized he had not sealed the cut surfaces before painting.*

> **Always seal cut edges to prevent moisture damage.**

Unsealed edges are prone to swelling and flaking, especially in humid environments. To avoid this, prime every cut surface before applying the final coat of paint. This step is crucial in areas like kitchens and bathrooms where moisture is prevalent.

After priming, allow sufficient time for the primer to dry completely. This ensures that the paint adheres properly and provides a durable finish that can withstand the test of time.

Using moisture-resistant materials, such as plywood, can further enhance durability in moisture-prone areas.

> **WHERE THIS GOES WRONG**
>
> Neglecting to seal cut edges can lead to significant damage over time.

**BEFORE YOU MOVE ON**

- Prime all cut surfaces before painting
- Allow adequate drying time for primer
- Use moisture-resistant materials where necessary



DAY 2

# Missing Studs

*IN THIS APARTMENT*

*Anjali in her Bengaluru rental wanted to install heavy shelves in her living room but only used drywall anchors. A few weeks later, the shelves fell, damaging her wall and decor.*

## Always locate and use studs for heavy installations.

When installing heavy shelves, relying solely on drywall can lead to failure. It’s essential to locate the studs behind the drywall and anchor your shelves directly into them for maximum support.


Use a stud finder to accurately locate the studs. Once identified, mark their positions and drill pilot holes before attaching your shelves. This ensures a secure installation that can handle weight without risk.

If you must use anchors, choose suitable ones designed for the weight and type of load you're supporting, but always prioritize securing into studs.

> **WHERE THIS GOES WRONG**
>
> Installing heavy items on drywall without securing to studs can result in damage and safety hazards.

**BEFORE YOU MOVE ON**

- Locate studs using a stud finder
- Mark stud positions clearly
- Use appropriate anchors when necessary



DAY 3

# Rushing Finish Coats

*IN THIS APARTMENT*

*Deepak, renovating his Mumbai flat, applied a thick coat of paint on his walls in one go, resulting in a tacky finish that took weeks to dry.*

## Apply thin, even coats for a professional finish.

Thick coats of paint can remain tacky for an extended period, leading to an unsatisfactory finish. Instead, apply thin, even coats, allowing each layer to dry completely before adding the next.

Respect the manufacturer’s recommended drying times between coats. This practice not only improves the final appearance but also enhances the durability of the paint job.

Using a high-quality paint can also help achieve a better finish with fewer coats, saving time and effort in the long run.

> **WHERE THIS GOES WRONG**
>
> Applying thick coats of paint can lead to prolonged drying times and an uneven finish.

**BEFORE YOU MOVE ON**

- Apply thin coats of paint
- Follow drying time recommendations
- Consider using high-quality paint



DAY 4

# Forgetting Service Access

*IN THIS APARTMENT*

*Meera, living in a small flat in Chennai, installed a new air conditioning unit but blocked the filter access, leading to maintenance issues.*

## Ensure clearances for maintenance access.

Blocked filters and vents can lead to significant problems, including reduced efficiency and potential damage to appliances. Always leave adequate clearances for maintenance based on the manufacturer’s manuals.

Before installation, review the installation guidelines to identify necessary access points. This foresight can prevent future headaches and costly repairs.

In tight spaces, consider creative solutions to maintain access without compromising aesthetics, such as using removable panels or strategically placing furniture.

> **WHERE THIS GOES WRONG**
>
> Blocking access to filters and vents can lead to maintenance issues and appliance failure.

**BEFORE YOU MOVE ON**

- Review installation manuals for access requirements
- Plan for maintenance access during installation
- Consider removable panels for tight spaces



DAY 5

# Moving Machines Roughly

*IN THIS APARTMENT*

*Suresh in his 1BHK in Hyderabad scratched his wooden floor while moving a washing machine without using sliders, causing permanent damage.*

## Use sliders or lift machines to avoid floor damage.

Moving heavy appliances without proper care can lead to scratches and damage to your flooring. Always use sliders or lift the machines slightly while moving them into place to prevent floor damage.

If you don’t have sliders, consider using a thick piece of cardboard or a towel under the appliance to help it glide across the floor without scratching.

Plan the path for moving heavy items in advance, ensuring that the route is clear of obstacles to make the process smoother and safer.

> **WHERE THIS GOES WRONG**
>
> Moving heavy appliances without proper tools can damage floors and lead to accidents.

**BEFORE YOU MOVE ON**

- Use sliders for heavy appliances
- Lift slightly while moving to avoid scratches
- Clear the path before moving heavy items



CHAPTER

# Preparing for Your Alcove Project

This chapter guides you through the essential steps to prepare for building your alcove shelving, ensuring you have everything in place for a successful weekend project.



DAY 1: PREPARATION

# Measuring Your Alcove

*IN THIS APARTMENT*

*Ravi lives in a 1BHK apartment in Pune with a 9-foot living room alcove. He clears the space to take accurate measurements, noting the dimensions and any protrusions.*

> **Accurate measurements are crucial for a successful build.**

Start by emptying your alcove completely to ensure you have unobstructed access for measuring. Use a tape measure to capture the exact dimensions of the alcove, including height, width, and depth. Pay special attention to any protrusions that may affect the installation of shelves or cabinets.

Once you have the measurements, mark them clearly on a piece of paper or a digital note. This will serve as your reference throughout the project. Double-check your measurements to avoid any mistakes that could lead to miscalculations later on.

Consider the layout of your shelving. Decide how many shelves you want and their spacing based on the items you plan to store. This will help you determine the total height needed for your shelving unit.

> **WHERE THIS GOES WRONG**
>
> Neglecting to account for protrusions can lead to a poor fit for your shelves.

**BEFORE YOU MOVE ON**

- Empty the alcove completely
- Take accurate measurements of height, width, and depth
- Note any protrusions that may affect shelf placement
- Decide on the number of shelves and their spacing



DAY 1: PREPARATION

# Choosing Materials and Hardware

*IN THIS APARTMENT*

*Anjali, living in a Bengaluru rental, needs to decide between using plywood or MDF for her shelving, considering the moisture levels in her kitchen alcove.*

> **Selecting the right materials is essential for durability and functionality.**

When choosing materials for your shelving, consider the environment where they will be installed. For areas with high moisture exposure, such as kitchens or bathrooms, opt for plywood, which is more resistant to warping and damage compared to MDF.

If your alcove is in a drier area, MDF can be a cost-effective choice. It offers a smooth surface for painting and is easier to work with for detailed cuts. However, be mindful of its limitations in moisture-prone areas.

In addition to the material, decide on the type of hardware you will use for installation. Cleats provide a strong support system for heavier shelves, while brackets may be more suitable for lighter loads. Assess your needs based on what you plan to store on the shelves.

> **WHERE THIS GOES WRONG**
>
> Choosing the wrong material for your shelving can lead to damage and replacement costs.

**BEFORE YOU MOVE ON**

- Evaluate moisture levels in the alcove
- Choose between plywood and MDF based on exposure
- Decide on cleats or brackets for support
- Consider the weight of items to be stored



DAY 1: PREPARATION

# Gathering Tools and Supplies

*IN THIS APARTMENT*

*Suresh, who lives in a compact Mumbai flat, checks his tool inventory before heading to the home center to gather everything he needs for his alcove project.*

> **Having the right tools on hand ensures a smooth building process.**

Before you begin your project, gather all necessary tools to avoid interruptions during the build. Essential tools include a stud finder, level, drill, screws, wood glue, sandpaper, and a brush or roller for finishing touches.

Make a checklist of the tools you need and check your inventory at home. If you find that you are missing any essential tools, make a trip to your local home center to purchase or rent them.

In addition to tools, ensure you have all the materials you plan to use, including sheet goods and finishes. This preparation will save you time and frustration during the actual building process.

> **WHERE THIS GOES WRONG**
>
> Starting the project without all necessary tools can lead to delays and frustration.

**BEFORE YOU MOVE ON**

- List all required tools and supplies
- Check your home inventory for tools
- Visit a home center for missing items
- Ensure you have all materials and finishes ready



CHAPTER

# Assess, Measure, And Plan Your Alcove

Chapter 2: Assess, Measure, And Plan Your Alcove Chapter Introduction You have a weekend and under 200 dollars to transform a cramped laundry alcove into a clean, efficient space. Success starts with what you do before you buy a single board. Building on the blueprint overview from Introduction, this chapter shows you how to assess, measure, and plan with enough precision to make the cut list fit



PART 8

# Assess, Measure, And Plan Your Alcove


Chapter 2: Assess, Measure, And Plan Your Alcove Chapter Introduction You have a weekend and under 200 dollars to transform a cramped laundry alcove into a clean, efficient space. Success starts with what you do before you buy a single board. Building on the blueprint overview from Introduction, this chapter shows you how to assess, measure, and plan with enough precision to make the cut list fit perfectly the first time.

### Allow At Least 1 Inch Between Them

| Parameter | Value |
| --- | --- |
| Spec 1 | 1 in |

Allow at least 1 inch between them for vibration and hand access, and account for any door casing that narrows the opening.

You will learn how to capture actual width, depth, and height, find the true clearances around plumbing and vents, and test whether your alcove is square. You will decide between stacked or side by side machines using a simple decision matrix, then sketch shelf zones that match how you use laundry. This planning step is where budget and schedule survive, because you eliminate surprises before the saw is plugged in.




For stacked machines, typical combined height ranges from 74 inches to 78 inches.

Hoses bulge behind machines. Walls bow slightly. Doors swing across valuable inches. If you guess, you will cut shelves that do not fit, buy brackets you cannot mount, or build a countertop that blocks service access and makes maintenance a headache. The challenge is to translate an irregular, often tight alcove into usable inches. You need a reliable way to measure clearances that actually matter, compare layout options, and anchor your choices to service and safety requirements.

### For Side By Side Machines, Remember Most

| Parameter | Value |
|---|---|
| Spec 1 | **27 in** |

For side by side machines, remember most full size washers and dryers are about 27 inches wide each.

Without this, the weekend plan becomes a multi weekend slog. The Planning Framework Use this four step framework: Measure, Verify, Decide, Sketch. Measure. Capture width, depth, height, and every obstruction using the printable templates. Record low, mid, and high measurements to reveal irregularities. Note outlet, hose box, and vent locations. Verify. Test squareness, check wall bow with a straightedge, and confirm service clearances for your specific machines, including vent routing and drip pan needs.

### For Depth Planning, Note That Many Machines

| Parameter | Value |
| --- | --- |
| Spec 1 | **4 in** |

For depth planning, note that many machines need 4 inches or more behind them for hoses and the dryer vent.

Decide. Use the stacked versus side by side decision matrix to prioritize access, storage volume, and stability. Choose shelf depth and countertop height based on the measurements and clearances. Sketch. Translate your measurements into a plan with defined zones. Place detergents within arm's reach, reserve tall item parking, draw a folding countertop, and position baskets or hampers.

### At Least 1 Inch On Each Side

| Parameter | Value |
|---|---|
| Spec 1 | 1 in |
| Spec 2 | 4 in |

Leave at least 1 inch on each side of the machines if possible, and aim for 4 inches behind for hoses and the vent.

The framework creates a clear path to the correct cut list variant. It also minimizes rework, which keeps your project on schedule and under budget.

### Some Manufacturer Manuals Specify 1 Inch Sides

| Parameter | Value |
|---|---|
| Spec 1 | 1 in |
| Spec 2 | 5 in |
| Spec 3 | 1 in |

Some manufacturer manuals specify 1 inch sides, 5 inches back, and 1 inch top.


Measure wall to wall at floor height, at the midpoint, and near the top. Write each number on the template. Baseboards, trim, and tile lips can reduce usable width at the bottom. If the numbers differ, plan for the smallest width. For side by side machines, remember most full size washers and dryers are about 27 inches wide each. Allow at least 1 inch between them for vibration and hand access, and account for any door casing that narrows the opening.

**The Tenant Measured 59 Inches At The**

| Parameter | Value |
|---|---|
| Spec 1 | **59 in** |
| Spec 2 | **60 in** |
| Spec 3 | **59 in** |

The tenant measured 59 inches at the floor, 60 inches at the midpoint, and 59 inches at the top because of a trim lip.

Measure depth from the back wall to the front plane of the alcove, then subtract any door swing or closet bifold. Measure at three heights because some alcoves have a drywall bulge or a drain box that protrudes. For depth planning, note that many machines need 4 inches or more behind them for hoses and the dryer vent. If you use a low profile vent elbow, you might gain an inch. Never force the hose or vent. Crushed lines cause leaks and lint clogs.




Detergent shelf can be 10 to 12 inches deep.

Measure height from finished floor to ceiling in three locations. For stacked machines, typical combined height ranges from 74 inches to 78 inches. Confirm your pair's actual stack height. Also check whether a light fixture, soffit, or duct interferes. If your height is tight, stacked may be risky, and a side by side layout with a shallow countertop might be the better choice.

Map obstacles. Use the template to mark the exact location of outlets, the water supply box, the standpipe, the gas valve if applicable, and the dryer vent. Note distances from each side wall and from the floor. Identify anything that must stay accessible. For example, the lint cleanout cannot be covered by a shelf front, and the vent path must be smooth and short.

Test squareness. Place a carpenter's square in each corner. If the gaps differ, your alcove is not square. Use a 4 foot straightedge or a long level to check wall bow. Hold it against each wall and look for light passing through in the center. A bow of a quarter inch is common. This matters because a perfectly straight shelf cut to a bowed wall will rock or leave gaps. Plan to scribe, which means trace the wall contour onto the shelf edge and sand to fit, or reduce shelf depth to float clear of the bow.

Confirm service clearances. Leave at least 1 inch on each side of the machines if possible, and aim for 4 inches behind for hoses and the vent. Some manufacturer manuals specify 1 inch sides, 5 inches back, and 1 inch top. Check your model sticker inside the door or online. "Measure twice, cut once" applies here more than anywhere. Vent routing. Standard dryer vents are 4 inch round. Short, smooth runs work best. Avoid long flexible hoses that snake around cleats. Plan shelf cleats or supports so they do not block the vent path. If your vent exits through the side wall near the floor, you may need to keep the lowest shelf shallow to avoid interference.

Drip pan and floor protection. On upper floors, a drip pan under the washer can be required. Measure the lip height. Some pans add up to an inch, which changes leveling and countertop height. Ensure the pan's drain remains accessible. If you cannot install a pan, at least plan a bead of flexible caulk where the floor meets the wall to prevent minor spills from seeping under.

Anti vibration needs. Old houses and rentals often have springy floors. Place rubber pads under the machine feet, and ensure machines are perfectly level front to back and side to side. Plan for a small gap between machines so they do not knock during spin. Avoid anchoring shelves directly above machines that shake unless you use wide cleats and multiple studs.

Stacked Versus Side By Side Decision Matrix Use three criteria. Access. If you frequently wash bulky items or need to reach the washer drum easily, side by side wins. Stacked makes the dryer higher, which can challenge shorter users. Storage. Side by side supports a full folding countertop over both machines, with baskets below or to the side. Stacked frees floor space for tall hampers or a vertical shelf tower.

Stability. Side by side distributes vibration better in older structures. Stacked is stable when installed with a factory kit and leveled perfectly. If your floor flexes, side by side is safer. Score each criterion from one to five for your situation. Add the scores. The higher total guides the choice. If the totals tie, pick the layout that best preserves vent simplicity.

Print the measurement templates and tape them to a clipboard. Clear the area, pull machines forward safely, and unplug them. Record width at floor, midway, and near the top, with notes on baseboards and trim. Record depth at three

heights, accounting for doors and swing arcs. Record height at three positions, including under any soffits or ducts. Map outlet, hose box, standpipe, vent, and any valves with precise distances.

Test squareness with a carpenter's square in each corner. Check wall bow with a straightedge and write the bow amount. Confirm your machine dimensions and service clearances. Decide stacked or side by side using the matrix, and write the choice. Choose shelf depths. Detergent shelf can be 10 to 12 inches deep. Folding countertop usually ranges from 22 to 26 inches depending on machine depth and vent space.

Sketch zones. Draw detergents within arm's reach of the washer door, a tall item zone, a folding surface, and basket or hamper placements. Select the cut list variant that matches your width, depth, and layout. Note any scribe allowances if walls bow. Real World Application: Two Alcoves Solved Narrow Rental Closet, 59 Inch Width. The tenant measured 59 inches at the floor, 60 inches at the midpoint, and 59 inches at the top because of a trim lip. Machines were 27 inches wide each. Side by side would have been a tight squeeze. The decision matrix favored stacked, which scored higher for storage and stability on a slab floor.

They planned a vertical shelf on the open side, 10 inches deep for detergents, and placed two tall hampers below. The vent exited directly behind the dryer, so they kept the lowest shelf short and clear. Result, smooth airflow, easy access, and zero cut list rework. Old House Alcove With Bowed Wall. The owner measured a quarter inch bow in the right wall and 24 inch depth at the center, 23 and a half inches at the left due to a pipe box. Side by side scored higher for access. They set the folding countertop at 24 inches deep, then scribed the right edge to match the bow.

The detergent shelf was placed above the washer door at 12 inches deep to avoid head knocks. Rubber pads under both machines reduced vibration, and wide cleats fastened into three studs made the shelves solid. Result, quiet operation, even with a spin cycle at high speed. Common Pitfalls And How To Avoid Them Measuring width only at the midpoint. Always measure at multiple heights and use the smallest number.

Ignoring baseboards and trim. Shelves that fit at the top may jam at the bottom when you slide them in. Forgetting the dryer vent path. A shelf cleat across the vent exit creates a frustrating reroute. Map it first. Overdeep shelves above the machines. Anything beyond arm's reach invites head bumps and wasted space. Blocking service access. Leave clear reach to valves, cleanouts, and outlets. Future you will thank present you.

Skipping level and anti vibration pads. Unleveled machines walk, which loosens fasteners and scuffs finishes. Assuming studs where you want them. Use a stud finder and pilot holes to confirm solid anchors before you cut.

Accurate measurements guide the correct cut list and prevent rework. Test squareness and wall bow so shelves fit cleanly. Respect service clearances for hoses, vent, and access points. Choose stacked or side by side using access, storage, and stability scores. Sketch storage zones that match how you do laundry. Detect old house risks early and plan simple workarounds.

Print templates and gather a tape measure, square, straightedge, and stud finder. Measure width, depth, and height at three positions each, then write the smallest values. Map everything that protrudes or requires access, including vents and outlets. Confirm machine dimensions and recommended clearances from the manual. Score the decision matrix and select stacked or side by side.

Choose shelf depths and countertop height that respect clearances. Draw your zone sketch and place detergents, tall items, folding, and baskets. Pick the cut list variant that matches your layout and measurements. List any scribe edges or adjustments needed due to bow or out of square. Create a short shopping map for your next chapter budgeting step.

Chapter Conclusion You now have a precise map of your alcove, a confident layout decision, and a zone sketch that fits how you work. With measurements verified and risks identified, you can select the correct cut list and avoid costly backtracking. In the next chapter, Budgeting And Bill Of Materials Under 200, you will translate this plan into an exact shopping list, aisle locations, and cost saving choices that keep your project under budget and on schedule.



CHAPTER

# Budgeting And Bill Of Materials Under $200

Transform your alcove project into a reality without exceeding your budget. This chapter provides a comprehensive guide to creating a shopping list that keeps your expenses under two hundred dollars while ensuring strength and clean finishes.



DAY 1

# Understanding Your Budget

*IN THIS APARTMENT*

*In her 1BHK apartment in Pune, Priya is determined to create a laundry alcove in her 9-foot living room. She has a budget of $200 and needs to ensure she doesn't overspend on materials.*

> **Budgeting effectively prevents overspending and ensures all necessary materials are accounted for.**

To keep your project under budget, start by measuring your alcove accurately. Priya measured her alcove and sketched a layout that maximizes space without compromising functionality.

Next, create a detailed shopping list of materials needed, including plywood, MDF, screws, and paint. Be specific about sizes and quantities to avoid unnecessary purchases. Priya noted that she needed one sheet of three-quarter inch plywood for the countertop and two sheets of half-inch MDF for the shelves.

Finally, calculate the costs of each item based on local prices. Priya found that three-quarter inch plywood was priced at seventy-five dollars per sheet and half-inch MDF at thirty-five dollars per sheet, allowing her to stay within her budget.

**DO THIS**

1. Measure your alcove dimensions accurately.
2. Create a detailed shopping list with specific sizes and quantities.
3. Research local prices for each item to ensure you stay within budget.

**WHERE THIS GOES WRONG**

Failing to create a detailed shopping list can lead to overspending and unnecessary purchases.

**BEFORE YOU MOVE ON**

Measure your alcove dimensions.

Create a detailed shopping list with sizes and quantities.

Research local prices for each item.



DAY 2

# Material Selection

*IN THIS APARTMENT*

*In her Bengaluru rental, Meera is planning to build a laundry alcove but is unsure about which materials to choose. She needs to balance cost and durability.*

> **Selecting the right materials is crucial for both cost-effectiveness and project longevity.**

For the countertop, three-quarter inch plywood is ideal as it can support heavy items like detergent containers. Meera learned that sanded three-quarter inch plywood costs between sixty to ninety dollars per sheet, which fits her budget.

For shelves, half-inch plywood or MDF can be used. Meera discovered that MDF is smoother for painting and usually cheaper, priced at twenty-eight to thirty-eight dollars per sheet. However, if her alcove is humid, she should opt for plywood, which costs thirty-five to fifty dollars per sheet.

Cleats are a cost-effective way to support shelves. Meera found that a one-by-three common board in an eight-foot length costs five to eight dollars, and she would need three to four boards for her project.

### DO THIS

1. Choose three-quarter inch plywood for the countertop.
2. Select half-inch plywood or MDF for shelves based on moisture levels.
3. Use wood cleats for shelf support instead of metal brackets.

### WHERE THIS GOES WRONG

Choosing decorative brackets instead of cleats can significantly increase costs without adding value.

### BEFORE YOU MOVE ON

Select three-quarter inch plywood for the countertop.

Choose half-inch plywood or MDF for shelves based on moisture levels.

Use wood cleats for shelf support.



DAY 3

# Calculating Yields

*IN THIS APARTMENT*

*In her Mumbai flat, Aditi is preparing to cut her materials for a laundry alcove. She needs to ensure she buys the right amount of plywood and MDF to avoid waste.*

> **Calculating yields accurately helps minimize waste and keeps costs down.**

Start by listing each component and its dimensions. Aditi noted that her countertop depth is twenty-three inches, and she needs two shelves at sixteen inches deep. This information is crucial for calculating how much material she needs.

A four by eight sheet of plywood has thirty-two square feet. Aditi calculated that her countertop, which is twenty-four by sixty inches, requires ten square feet, while her two shelves total thirteen and one-third square feet. This means she can fit all components into two sheets of material.

To check linear yields for cleats, Aditi noted that three eight-foot one-by-three boards provide twenty-four feet of cleat material, which is sufficient for her alcove.

### DO THIS

1. List each component and its dimensions accurately.
2. Calculate the total square footage needed for each component.
3. Ensure that your total fits within the yields of the sheets you plan to purchase.

### WHERE THIS GOES WRONG

Failing to calculate yields can lead to unnecessary purchases and wasted materials.

### BEFORE YOU MOVE ON

List each component and its dimensions.

Calculate total square footage needed for each component.

Ensure total fits within the yields of the sheets you plan to purchase.



DAY 4

# Finalizing Your Bill of Materials

*IN THIS APARTMENT*

*In her 1BHK in Pune, Priya is ready to finalize her bill of materials for her laundry alcove project, ensuring she stays under budget.*

> **A well-prepared bill of materials ensures a smooth shopping experience and keeps costs under control.**

Priya compiled her list of materials, including one sheet of three-quarter inch plywood for seventy-five dollars, one sheet of half-inch MDF for thirty-five dollars, and several other items totaling one hundred ninety-five dollars without edge banding.

She decided to skip edge banding to stay under her budget. Instead, she planned to paint the edges, which would require additional sanding and two coats of paint.

Priya also included a contingency of twelve dollars for unexpected items, ensuring she had a buffer for any last-minute needs.

### DO THIS


1. Compile a detailed bill of materials with current local prices.
2. Decide whether to paint edges or add edge banding based on your budget.
3. Include a contingency for unexpected expenses.

### WHERE THIS GOES WRONG

Neglecting to include a contingency can lead to budget overruns and project delays.

### BEFORE YOU MOVE ON

- [ ] Compile a detailed bill of materials with current local prices.
- [ ] Decide whether to paint edges or add edge banding based on your budget.
- [ ] Include a contingency for unexpected expenses.



CHAPTER

# Aisle-By-Aisle Shopping Maps And Tool Prep

This chapter provides a streamlined approach to shopping for your home project, ensuring you have everything you need for a successful build. By following a clear aisle map and preparing your tools in advance, you can save time and avoid common pitfalls that lead to delays and frustration.



DAY 1: SHOPPING PREPARATION

# The Aisle Map And Prep System

*IN THIS APARTMENT*

*Ravi, a resident of Pune, has a 1BHK apartment with limited storage. He needs to prepare for a weekend alcove makeover. With a list in hand, he heads to the local home center, determined to make his shopping efficient.*

> **A well-organized shopping plan minimizes time spent in-store and maximizes efficiency.**

Start your shopping journey at the building materials section, where plywood and MDF are located. For the alcove, you will typically need three-quarter inch plywood for the countertop and one-half inch plywood or MDF for shelves and

side panels. Inspect the sheets for flatness and edges free of chips before loading them onto your cart. If you plan to request store cuts, ensure you have a cart with a flat bed and strap points for stability during transport.


Next, move to the dimensional lumber aisle. Common cleats are made from one by two or one by three pine or poplar. You can also use ripped strips from plywood for stronger cleats. Always check for straight boards by sighting down their length and look for kiln-dried options to minimize warping.

In the hardware aisle, gather wood screws in sizes that match your build plan—typically one and five-eighths inch for shelves and two-inch for cleats. Opt for star drive or square drive screws to reduce cam out. If your design includes adjustable shelves, remember to pick up shelf pins and a matching drill bit.

> **WHERE THIS GOES WRONG**
>
> Avoid wandering the store without a clear plan, as this can lead to unnecessary delays and missed items.

**BEFORE YOU MOVE ON**

- Prepare a shopping list based on your project requirements.
- Inspect plywood and MDF for flatness before purchasing.
- Check for straightness in dimensional lumber before buying.
- Gather all necessary screws and fasteners in the correct sizes.



DAY 1: STORE CUTS

# Requesting Store Cuts Safely

*IN THIS APARTMENT*

*Neha, living in a compact Bengaluru apartment, needs to transport large sheets of plywood for her alcove project. She plans to request store cuts to make handling easier.*

> **Requesting store cuts can save time and make transporting materials more manageable.**

Store cuts are a great way to save time and make your materials easier to handle. Most home centers offer straight cuts on a panel saw, but be aware that policies vary. Generally, stores limit the number of cuts and will not cut narrow strips under twelve inches for safety reasons. Bring a marked cut list and use painter's tape to indicate where cuts are needed on the sheets.


When you arrive at the saw, ask for long rips first, followed by crosscuts. Always confirm your measurements at the saw and watch the operator for alignment. Keep your hands clear and stay behind the fence to ensure safety during the cutting process.

After the cuts are made, re-measure each piece and label it immediately using your code, such as CT for countertop or S1 for shelf one. If the store cannot accommodate your narrow cuts, plan to rip those at home with a circular saw and a straightedge.

> **WHERE THIS GOES WRONG**
>
> Neglecting to mark your cuts clearly can lead to confusion and mistakes during assembly.

**BEFORE YOU MOVE ON**

- Bring a marked cut list to the store for reference.
- Use painter's tape to indicate where cuts are needed on the sheets.
- Confirm measurements at the saw before cuts are made.
- Label each piece immediately after cutting.



DAY 1: TOOL KIT PREPARATION

# The Minimum Tool Kit That Will Not Fail You

*IN THIS APARTMENT*

*Kiran, who lives in a small Mumbai flat, is preparing his compact tool kit for a weekend project. He wants to ensure he has all the necessary tools without overloading his limited storage space.*

> **A compact tool kit ensures you have everything needed for your project without unnecessary bulk.**

For your alcove build, bring or borrow a compact tool kit that includes essential items. A drill driver with a set of driver bits and wood drill bits is crucial. A circular saw with a fine tooth blade in the forty to sixty tooth range is necessary for clean cuts on plywood and MDF. If you need to make notches around hoses or outlets, a jigsaw is optional but helpful.

Include a tape measure, speed square, stud finder, and level for layout accuracy. Two clamps will help guide straight cuts, and a straightedge guide or a long level can double as a cutting guide. For consumables, pack extra blades, extra driver bits, sandpaper in grits of one twenty, one eighty, and two twenty, painter tape, rags, and a pencil.

Safety gear is non-negotiable. Ensure you have gloves for handling sheet goods, eye protection during cuts and drilling, and a dust mask for working with MDF and plywood. A small first aid kit should also be included in your toolbox.

> **WHERE THIS GOES WRONG**
>
> Forgetting essential safety gear can lead to injuries and slow down your project.

**BEFORE YOU MOVE ON**

- Pack a drill driver and necessary bits for your project.
- Include a circular saw with the appropriate blade for clean cuts.
- Bring safety gear including gloves, eye protection, and a dust mask.
- Prepare a small first aid kit for emergencies.



CHAPTER

# Cut Lists And Modular Components


Cut Lists And Modular Components Chapter Introduction You measured your alcove, checked stud locations, and mapped your shopping route in the previous chapter. Now you will convert those numbers into a simple set of parts you can cut, label, and assemble in a single weekend. Think of this chapter as your blueprint for transforming raw sheet goods into a strong, clean system that looks custom witho



PART 11

# Cut Lists And Modular Components

Cut Lists And Modular Components Chapter Introduction You measured your alcove, checked stud locations, and mapped your shopping route in the previous chapter. Now you will convert those numbers into a simple set of parts you can cut, label, and assemble in a single weekend. Think of this chapter as your blueprint for transforming raw sheet goods into a strong, clean system that looks custom without complex joinery.




Many front load washers are about 38 to 40 inches tall, so a typical countertop height lands at 39 to 41 inches.

You will learn how to choose the right cut-list variant for stacked or side by side machines, how to size shelves and a countertop, and how to use cleats to support heavy loads with minimal hardware. You will also get clear spacing targets, edge treatments that resist moisture, jig setups for repeat cuts, and a labeling approach that keeps assembly stress free. By the end, you will have modular components ready to fit your alcove, all under the weekend budget.

### Side By Side Machines, Standard Widths Between

| Parameter | Value |
|---|---|
| Spec 1 | **72 in** |

Side By Side Machines, standard widths between 58 and 72 inches.

Most laundry alcoves are shallow, uneven, and full of obstacles. Hoses need breathing room. Dryer vents demand clear paths. Machines vibrate. Bottles are tall and tip easily. You have to fit shelves and a countertop without blocking doors or service access. The budget limits fancy hardware. On top of that, wall surfaces are rarely square, which makes tight fits tricky if you rely on perfect cuts.

### Stacked Machines, Narrow Widths Between 28 And

| Parameter | Value |
| --- | --- |
| Spec 1 | **36 in** |

Stacked Machines, narrow widths between 28 and 36 inches.

The common result is a jumble of store bought racks that wobble, or a half built shelf that sags. Materials get wasted because you cut parts twice. You forget where pieces go during assembly. Countertops end up too low or too deep. The real challenge is to translate measurements into a repeatable set of parts and attachments that respect clearances, carry weight, and look finished.

### Compact Side By Side, Widths Between 44

| Parameter | Value |
|---|---|
| Spec 1 | **58 in** |

Compact Side By Side, widths between 44 and 58 inches.

The core of this chapter is a cut-list matrix. You will pick a variant based on your layout and alcove width, then cut standardized components that nest together. The matrix has three common scenarios. Side By Side Machines, standard widths between 58 and 72 inches. This variant provides a full countertop above both machines, rear wall cleats for shelf support, and optional short uprights on the sides to cage the edge of baskets.

### Most Machines Are 31 To 34 Inches

| Parameter | Value |
| --- | --- |
| Spec 1 | **31–34 in** |

Most machines are 31 to 34 inches deep including hoses, so the countertop should not span the full depth.

Stacked Machines, narrow widths between 28 and 36 inches. This variant focuses on a robust side cleat ladder for adjustable shelves and a partial countertop beside the stack for folding. Compact Side By Side, widths between 44 and 58 inches. This variant uses a thinner countertop span with a center support cleat and reduced shelf count. Each variant uses the same building blocks. Rear and side cleats screwed to studs create a strong hidden structure. Shelves and the countertop rest on cleats. Uprights add visual order and help prevent lateral movement without full cabinet boxes. Edge treatments protect exposed plywood and improve appearance. A labeling system maps each piece to a precise location, so you can stage parts and assemble with confidence.

### For Detergents And Tall Bottles, Use 14

| Parameter | Value |
| --- | --- |
| Spec 1 | **14–16 in** |

For detergents and tall bottles, use 14 to 16 inches of vertical space.


Start with standard dimensions, then adjust to your measured space. Countertop Height Target. If you have side by side machines, set the countertop above the highest machine top plus one inch. Many front load washers are about 38 to 40 inches tall, so a typical countertop height lands at 39 to 41 inches. This gives a usable folding surface while avoiding vibration contact. Always verify your specific machines.

### For Baskets Or Smaller Items, Use 10

| Parameter | Value |
|---|---|
| Spec 1 | **10–12 in** |

For baskets or smaller items, use 10 to 12 inches.

Countertop Depth Target. Aim for 24 to 25 inches. Most machines are 31 to 34 inches deep including hoses, so the countertop should not span the full depth. Keep the counter shallow and supported at the back, so hoses and vents breathe without pressure. Minimum Clearances. Leave one inch on each side of machines if possible. Leave three to four inches behind machines for hoses, vents, and plugs.




Reserve one upper shelf at 16 inches for tall bottles, and one mid shelf at 12 inches for daily use items.

Check appliance manuals for exact needs. Shelf Spacing. For detergents and tall bottles, use 14 to 16 inches of vertical space. For baskets or smaller items, use 10 to 12 inches. Reserve one upper shelf at 16 inches for tall bottles, and one mid shelf at 12 inches for daily use items. Upright Width and Depth. Use 12 to 15 inches deep panels if you add uprights. This depth catches shelf edges and gives a clean face. Full height uprights are optional. Short uprights at 18 to 24 inches height near the front can guide baskets and keep the counter edge supported without boxing in machines.

Cleat Size. Use one by three or one by four pine for cleats. Rip plywood strips if needed. Cleats should be long enough to span at least two studs for load distribution. Cut-List Examples Side By Side Variant, alcove 64 inches wide. Materials include one sheet of three quarter inch plywood for countertop and shelves, one by four pine for cleats. Countertop. Cut one piece at 62 inches by 24 inches. Add a one inch gap to each wall for scribing or trim.

Shelves. Cut two pieces at 62 inches by 12 inches. One at 16 inch spacing above the countertop, one at 12 inch spacing above that. Uprights. Optional. Cut two pieces at 12 inches deep by 20 inches high to mount at the front edges under the

countertop. These act as anti racking guides. Cleats. Cut rear wall cleats at 58 inches length for the countertop, and 58 inches for each shelf. Cut side wall cleats at 20 inches for the front support blocks. Label studs during installation for accurate screw placement.

Stacked Variant, alcove 32 inches wide. Materials include one sheet of half inch plywood for shelves, one by three pine for cleats, and a small offcut for a 20 inch by 24 inch side table. Side Cleat Ladder. Cut four cleats at 20 inches to create adjustable rungs along the wall beside the stack. Shelves. Cut three pieces at 30 inches by 12 inches for detergent and baskets. Space at 12, 12, and 16 inches.

Compact Counter. Cut one piece at 20 inches by 24 inches. Mount on two cleats beside the stack. This creates a small folding ledge without obstructing the machines. Compact Side By Side Variant, alcove 52 inches wide. Materials include one sheet of three quarter inch plywood and one by four pine. Countertop. Cut one piece at 50 inches by 24 inches. Shelves. Cut two pieces at 50 inches by 12 inches.

Center Support Cleat. Cut one cleat at 24 inches and mount vertically at the rear center. This cleat supports the rear of the countertop and shelves in narrower spans. Edge Treatments For a clean edge on plywood shelves and countertops, use one of three options. Paint and Sand. Round over edges lightly with sandpaper. Prime and paint with a durable enamel. This is the lowest cost option.

Iron On Banding. Apply iron on veneer banding to exposed edges. Trim flush with a utility knife and sand lightly. Finish with polyurethane or paint. Wood Trim. Attach a one by two face strip to the front of the shelf and countertop with glue and brad nails. This protects the edge and adds stiffness. Jig Setups For Repeat Cuts Set up a straightedge guide for your circular saw. Clamp a level or a factory edge strip to the plywood, then measure the saw offset so your cuts remain consistent. Use a simple spacer block to mark repeated widths, for example a 12 inch block for shelves. Cut long rips first, then crosscut to length. This sequence reduces waste and helps you keep parts square.

Labeling System Before cutting, print or handwrite labels that match part names and locations. Use a simple code. CT for countertop. SH1, SH2 for shelves. Mark heights, for example SH1 at 16 inches. RC and SC for rear and side cleats,

with lengths noted. UL and UR for left and right uprights if you are using them. Stick labels to parts as you cut. Later, transfer labels to hidden faces during painting so visible surfaces stay clean.

Implementation Strategy Confirm Clearances. Re measure alcove width at floor and counter height. Check depth, and mark the location of hoses, plugs, and vent. Note stud positions at the rear and sides with a pencil. Choose Your Variant. Decide if you are building for side by side, stacked, or compact side by side. Use the dimensions above as your target.

Lay Out Cuts. On your plywood, draw rectangles for the countertop and shelves. Place longer rips along the factory edge for straightness. Plan for edge treatments by leaving room for trim if needed. Set Up Your Jig. Clamp your straightedge at the offset you measured. Use the spacer block for repeat widths. Make cuts slowly. Support the sheet on sawhorses with scrap pieces to prevent tear out at the end of cuts.

Pre Drill and Countersink. For shelves, drill pilot holes for screws. For the countertop, plan screw positions along the rear cleat and any side cleats. Countersink screw heads slightly so you can fill them later for a clean finish. Sand and Edge Treat. Break sharp edges with a sanding sponge. Apply your chosen edge treatment. If painting, prime all faces that will be exposed and let dry.

Label Components. Apply labels to parts on the back face. Note orientation, for example left or right wall on cleats. Install Cleats. Using your stud finder marks from the previous chapter, hold the cleat at the target height, level it, then screw into studs every 16 inches or at each stud you find. For cleats, glue and brad nails can tack them in place while you drive screws. If you do not have a nailer, use a clamp or a helper.

Set Shelves and Countertop. Place shelves on cleats and secure with short screws from underneath. Set the countertop on rear and side cleats, then drive screws into the cleats. Check for level. Fill countersinks with wood filler, let dry, and touch up paint. Real-World Application Case Study, The Narrow Den. A renter in a 31 inch wide alcove had a stacked washer and dryer with no storage. Using the stacked variant, they cut three 30 inch by 12 inch shelves from half inch plywood and mounted a side cleat ladder beside the stack. Adhesive backed clips

managed the power cord and vent slack. The cleat ladder allowed the top shelf to sit at 16 inches above a small 20 inch by 24 inch folding ledge. The entire system was removable, and the shelves could be adjusted for bottle height. Total materials were under budget, and the renter kept wall impact minimal by fastening cleats into two studs.

Case Study, The Busy Family. A family with two front load machines in a 66 inch alcove wanted a stable countertop without boxed cabinets. They cut a 64 inch by 24 inch countertop and two matching shelves. Rear cleats spanned studs. Two short uprights near the front edges under the countertop kept baskets from sliding off. Edge banding gave a finished look. They left a one inch gap along the back for hoses, and they notched a corner for the vent. The countertop landed at 40 inches, just above the highest machine top. The family reported that the cleat backed system felt solid, and the shelves handled full bottles without sagging.

Common Pitfalls Ignoring Appliance Manuals. Every machine has clearance guidance. Do not squeeze shelves or a counter tightly against machines. Leave breathing room and service access. Overdeep Countertops. A counter deeper than 25 inches can press hoses. Keep depth shallow and rely on rear cleats for strength. Sparse Stud Attachment. One or two screws into drywall will not hold a loaded shelf. Span at least two studs with each major cleat.

Skipping Labels. Assembly confusion increases when shelves and cleats look similar. Label parts before finishing. Rough Edges. Unprotected edges chip and absorb moisture. Apply edge treatments for durability. No Allowance For Out Of Square Walls. Alcoves rarely meet at a perfect ninety degrees. Leave a small scribe gap at walls, then add trim or caulk after installation.


The cut-list matrix turns your measurements into a repeatable set of parts for stacked or side by side layouts. Cleats are the backbone of this system. They deliver strength at low cost with simple installation. Standard spacing works for most detergents and baskets, then you can fine tune with adjustable cleat ladders or shelf pins. A shallow countertop, typically 24 to 25 inches deep, protects hoses and vents while delivering a usable folding surface.

Label parts before you paint or assemble. It speeds installation and reduces mistakes. Edge treatments, paint, iron on banding, or wood trim, prevent moisture damage and add a finished look. Use a straightedge jig and spacer blocks to make repeat cuts fast and accurate. Pre drilling and countersinking let you hide fasteners and finish cleanly without complex joinery.

Re check alcove measurements at floor and counter height, and mark stud positions on the rear and side walls. Choose your cut-list variant based on layout and width, side by side, stacked, or compact side by side. Sketch your parts on paper with labels, then transfer cut lines onto your sheet goods. Set up a straightedge cutting guide and spacer block for repeat widths, then cut shelves and the countertop.

Sand edges and apply your chosen edge treatment, paint, iron on banding, or wood trim. Pre drill and countersink shelf and countertop screw holes to match cleat locations. Install rear and side cleats into studs at the target heights, checking level as you go. Set shelves and the countertop on cleats, secure with screws, fill countersinks, and touch up finish.

Chapter Conclusion You now have a clear path from measurements to components. The cut-list matrix reduces decisions, cleats carry the load, and labeling keeps the build moving. Building on your shopping map and tool prep, this chapter takes you straight to finish ready parts that assemble tight and look clean. In the next chapter, you will see how to adapt these components for renter friendly installs and smart storage, including compression fits, removable frames, and storage zones that match daily tasks. Your alcove is about to become the most efficient square footage in your home.



CHAPTER

# Renter-Friendly Build And Smart Storage

Creating a functional laundry alcove in a rental apartment can be challenging, especially when you want to avoid damaging walls and trim. This chapter provides a comprehensive guide to building a renter-friendly storage solution that is both stable and removable, all while staying within a budget of under 200. By utilizing a three-layer stability framework and a smart storage zone map, you can create an efficient laundry space that meets your needs without risking your deposit.



DAY ONE MORNING, SET THE BASE

# Base First: Building the Floor Platform

*IN THIS APARTMENT*

*Mia rents a small 1BHK in Pune with a tight 30-inch laundry alcove. To maximize space and stability, she builds a floor platform that distributes the load of her stacked washing machines without drilling into the walls.*

> **A solid floor platform provides stability and serves as the foundation for additional storage solutions.**

Start by clearing the alcove and vacuuming any dust. Make sure to wipe down the walls where you plan to apply adhesives later.

Place vibration pads under the feet of the washer and dryer to absorb noise and prevent movement. If using a drip pan, set it in place now to catch any leaks.

Construct the floor platform using two by four lumber on edge to create a frame. Attach a plywood top with screws, ensuring the platform is level from front to back and side to side. Shim the feet if necessary, but do not block any hose paths.

### DO THIS

1. Clear the alcove and vacuum dust.
2. Place vibration pads where the washer and dryer feet will sit.
3. Build the floor platform with a two by four frame and plywood top.
4. Check level and shim if needed before sliding into position.

### WHERE THIS GOES WRONG

Blocking hose paths can lead to issues with drainage and machine operation.

### BEFORE YOU MOVE ON

- [ ] Clear the alcove
- [ ] Place vibration pads
- [ ] Build the floor platform
- [ ] Check level and shim if needed



DAY ONE AFTERNOON, PRESS FIT FRAME

# Press Fit Uprights: Creating a Non-Invasive Skeleton

*IN THIS APARTMENT*

*Jordan lives in a spacious 48-inch alcove in Bengaluru. He needs to create a stable structure for his side-by-side washing machines without drilling into the walls, so he opts for press fit uprights.*

**Press fit uprights provide a sturdy framework without damaging the walls, allowing for easy removal when moving out.**

Cut the uprights from two by lumber, making them half an inch longer than the vertical space to ensure a tight fit. Add rubber foot pads to the top and bottom for stability and to prevent damage to surfaces.

Position the first upright on the platform and compress it into place, ensuring it is plumb with the help of a level. Repeat for the second upright, checking both are vertical before proceeding.

Connect the uprights with cross members that match your earlier cleats, using screws sparingly to maintain the ability to remove the structure easily.

**DO THIS**

1. Cut uprights to the measured height and add rubber foot pads.
2. Compress the first upright into place and ensure it is plumb.
3. Tie uprights together with cross members for stability.

**WHERE THIS GOES WRONG**

Over-tensioning the uprights can damage the ceiling; use rubber pads and stop when they feel firm.

**BEFORE YOU MOVE ON**

- [ ] Cut uprights to size
- [ ] Add rubber foot pads
- [ ] Compress uprights into place
- [ ] Tie uprights with cross members




DAY ONE EVENING, SELECTIVE FASTENERS

## Selective Fasteners: Using French Cleats

*IN THIS APARTMENT*

*In her Mumbai flat, Mia has limited options for wall mounting due to her landlord's restrictions. She decides to use a French cleat system to hang a shallow shelf above her machines.*

> **A French cleat allows for strong support with minimal wall impact, making it ideal for renters.**

To install a French cleat, first locate the studs in your wall using a stud finder. Mark the locations with painter's tape to ensure accuracy.

Mount a short French cleat into the studs using two to three screws, pre-drilling to avoid damaging the wall. The cleat should be level and just long enough to support your overhead shelf.

Once the cleat is installed, hang the shelf and test its stability with lightweight items before adding heavier items.

**DO THIS**

1. Locate studs with a stud finder and mark with tape.
2. Mount a short French cleat into the studs at the shelf height.
3. Hang the shelf and test with lightweight items.

**WHERE THIS GOES WRONG**

Ignoring stud locations can lead to sagging shelves; always confirm before installation.

**BEFORE YOU MOVE ON**

- Locate studs
- Mark with painter's tape
- Mount French cleat
- Test shelf stability



DAY TWO MORNING, STORAGE ZONES AND LABELS

# Smart Storage Sizing and Organization

*IN THIS APARTMENT*

*Jordan organizes his 48-inch alcove with designated storage zones for his laundry supplies, ensuring everything is easily accessible and clearly labeled.*

> **Mapping storage zones to tasks enhances efficiency and keeps the space organized.**

Assign specific zones for each task in your laundry workflow. For example, place sorting bins under the counter, washing supplies on the first shelf, and drying tools on a side hook or over door hanger.

Utilize slim baskets for bottles and pods, ensuring they fit within the shelf spacing. Label each bin clearly with task-based names such as Whites, Darks, and Lint to facilitate easy access.

Install slide-out hamper runners on the underside of the platform or on a small freestanding cart that fits under the counter, keeping the area tidy and organized.

**DO THIS**

1. Assign zones for sorting, washing, drying, and folding.
2. Place slim baskets on shelves and label bins clearly.
3. Install slide-out hamper runners.

**WHERE THIS GOES WRONG**

Unlabeled bins can become catch-alls; always label for clarity.

**BEFORE YOU MOVE ON**

- Assign storage zones
- Label bins clearly
- Install slide-out hampers



DAY TWO AFTERNOON, CABLES AND HOSES

# Cable and Hose Management

*IN THIS APARTMENT*

*Mia ensures that her laundry alcove in Pune is not only functional but also safe by managing cables and hoses effectively.*

> **Proper cable and hose management prevents hazards and maintains a tidy appearance.**

Route power cords along the uprights using adhesive clips to keep them organized and out of the way. Bundle any slack with Velcro wraps to prevent tangling.

Check that hose runs are smooth and visible, ensuring they do not kink or pinch behind shelves. Set the drip pan lip to catch any minor drips from the washer.

Test the machine vibration after setup. If the frame trembles, consider adding a cross member near the counter front or a small diagonal brace that attaches only to the frame.

### DO THIS

1. Route cords with adhesive clips along the uprights.
2. Bundle slack with Velcro wraps.
3. Confirm hose runs are smooth and visible.

### WHERE THIS GOES WRONG

Pinching hoses can lead to leaks; always maintain clear paths for hoses and cords.

### BEFORE YOU MOVE ON

- [ ] Route cords with clips
- [ ] Bundle slack with Velcro wraps
- [ ] Confirm hose paths are open



DAY TWO EVENING, FINISHING TOUCHES AND REMOVAL PLAN

# Finishing Touches and Removal Plan

*IN THIS APARTMENT*

*Jordan prepares his laundry alcove for future moves by creating a removal plan that ensures everything is documented and easy to disassemble.*

> **Planning for removal from the start makes moving out hassle-free and preserves your deposit.**

Conduct a full workflow rehearsal to ensure that all tasks can be completed efficiently. Sort, load, move, and fold to identify any reach issues that need fixing before finalizing the setup.

Pack a small move-out kit containing spackle, a putty knife, fine sandpaper, and a small jar of touch-up paint that matches your wall. Store it in a labeled bin called Move Out for easy access later.

Photograph stud hole locations behind the cleat for easy patching later, and keep receipts and cut list notes inside a clear sleeve for reference during the move.

**DO THIS**

1. Conduct a full workflow rehearsal.
2. Pack a move-out kit with necessary supplies.
3. Photograph stud hole locations for easy patching.

**WHERE THIS GOES WRONG**

Failing to document stud locations can complicate patching when moving out.

**BEFORE YOU MOVE ON**

- Conduct a workflow rehearsal
- Pack a move-out kit
- Document stud locations



CHAPTER

# Owner Upgrade Path, Trim, And Moisture Protection

Transform your laundry alcove into a durable, custom space with permanent upgrades that enhance functionality and aesthetics, all while staying within budget.



DAY 1

# Fastening Into Studs

*IN THIS APARTMENT*

*Ravi lives in a 1BHK flat in Pune with a 9-foot living room. He has decided to upgrade his laundry alcove to make it more functional and aesthetically pleasing. He starts by locating the studs in the wall to ensure a secure installation of the shelves.*

> **Secure fastening into studs is essential for a durable installation.**

Permanent cleats should land on studs for maximum stability. Use a stud finder to locate the studs, and confirm their position with a small pilot hole if necessary. For heavy-duty cleats under shelves or counters, drive two and one-half inch lag

screws through predrilled holes in the cleat and into the studs. Place a washer under each lag head to distribute the load evenly. Additionally, apply a bead of construction adhesive on the back of the cleat before setting it in place; this bonds the cleat to the drywall and minimizes vibration.

For verticals or face frames made from plywood or select pine, pocket screws are ideal for creating rigid corners. A pocket hole jig and one and one-quarter inch pocket screws work well for most three-quarter inch materials. Glue the joint, clamp it for a snug fit, and then drive the screws to ensure a square and solid assembly.

This method of fastening not only enhances the structural integrity of the alcove but also allows for a clean look, as the shelves will not flex under load or rattle during spin cycles.

> **WHERE THIS GOES WRONG**
>
> Neglecting to confirm stud alignment can lead to an unstable installation.

**BEFORE YOU MOVE ON**

- Use a stud finder to locate studs.
- Pre-drill holes for lag screws.
- Apply construction adhesive to the back of cleats.
- Use pocket screws for verticals and face frames.



DAY 2

## Trim That Hides Edges

*IN THIS APARTMENT*

*Anjali, residing in a compact Bengaluru apartment, has noticed gaps between her new shelves and the uneven walls of her laundry alcove. She decides to use trim to create a polished look.*

> **Trim can effectively hide imperfections and enhance the overall appearance of the installation.**

Face frames are an excellent solution for concealing raw plywood edges and achieving a clean, cabinet-style look. Use one by two select pine for the stiles and rails, ensuring that the reveals are narrow—about one-eighth inch—to create an intentional appearance. This attention to detail elevates the overall aesthetic of the alcove.

To address gaps between vertical panels and wavy walls, cut a side filler panel to match the alcove depth. Use scribing to trace the wall's irregularities onto the panel, then trim it to fit tightly against the wall. This method ensures a seamless look and prevents dust accumulation in the gaps.

Top seams can be refined with small crown or cove molding. A one and one-half inch cove is both forgiving and easy to install. Nail it to the face frame rather than the drywall, allowing it to move as one piece and preventing cracks from forming over time.

> **WHERE THIS GOES WRONG**
>
> Failing to account for wall irregularities can result in visible gaps.

**BEFORE YOU MOVE ON**

- Use one by two select pine for face frames.
- Scribe side fillers to match wall profiles.
- Install cove molding to hide seams.
- Ensure reveals are narrow for a clean look.



DAY 3

# Moisture Safe Finish Stack

*IN THIS APARTMENT*

*In a humid Mumbai flat, Priya is upgrading her laundry alcove to prevent moisture damage. She focuses on applying a moisture-safe finish to ensure durability.*

> **A moisture-safe finish stack is crucial for protecting surfaces in laundry areas.**

Laundry areas are prone to humidity, so it's essential to use finishes that can withstand moisture and regular cleaning. Start by priming all raw edges and cut faces with a bonding primer. For plywood, seal the end grain with a thin coat of primer, allowing it to soak in before applying a second coat. This step is vital to prevent swelling and peeling over time.

Choose either satin or semi-gloss paint for the final coat, as these finishes provide wipeability and durability. Satin offers a softer look, while semi-gloss is more resilient. Additionally, caulk wall joints and trim seams with paintable acrylic latex caulk labeled mildew resistant. Apply caulk after the primer and before the final paint coat to achieve a seamless appearance.

For counters or high-wear shelves, consider adding a water-based polyurethane topcoat. Two thin coats will create a durable surface that resists scuffs and drips. Maintaining indoor humidity below 60 percent is advisable to discourage mold growth, making moisture-resistant finishes essential for a healthier alcove.

> **WHERE THIS GOES WRONG**
>
> Skipping primer on raw edges can lead to swelling and peeling of the finish.

**BEFORE YOU MOVE ON**

- Prime all raw edges with bonding primer.
- Apply two coats of satin or semi-gloss paint.
- Caulk all seams with mildew-resistant caulk.
- Add water-based polyurethane to high-wear surfaces.



DAY 4

# Water And Lint Protection

*IN THIS APARTMENT*

*Suresh, living in a 1BHK in Chennai, is concerned about water leaks and lint buildup in his laundry alcove. He decides to implement protective measures to mitigate these issues.*

> **Implementing protective measures is essential for maintaining a clean and functional laundry space.**

To prevent small leaks and condensate from damaging your flooring, install a drip pan under the washer. Choose a pan that fits the footprint of your washer and has a drain outlet where local code permits. This simple addition can save you from costly water damage in the long run.

Install splash guards behind hose connections to keep the wall dry during hose replacements or disconnections. A plastic backsplash sheet, trimmed to size, works effectively for this purpose. It acts as a barrier against moisture and helps maintain a clean appearance.

For dryer venting, use smooth, semi-rigid aluminum duct that is short and direct, ensuring a tight connection to the wall collar. Avoid long runs that can trap lint and reduce airflow. A vent hood with a damper prevents backdraft, and it's crucial to vacuum the duct at least every season to maintain clean airflow and prevent lint buildup.

> **WHERE THIS GOES WRONG**
>
> Ignoring lint buildup can lead to fire hazards and inefficient drying.

**BEFORE YOU MOVE ON**


- Install a drip pan under the washer.
- Add splash guards behind hose connections.
- Use smooth aluminum duct for dryer venting.
- Vacuum lint from ducts seasonally.



CHAPTER

# The 48-Hour Weekend Schedule

Transform your weekend into a productive journey by following this structured plan to create a functional laundry alcove. With clear checkpoints and contingencies, you can navigate common setbacks and ensure your project stays on track.



FRIDAY EVENING


# Friday Evening: Confirm And Prep

*IN THIS APARTMENT*

*Ravi lives in a 1BHK in Pune with a 9-foot living room. He needs to prepare for his laundry alcove project this weekend. After work, he dedicates his Friday evening to confirm measurements and finalize his plans.*

## Preparation is key to a successful project.

Start by confirming your measurements and cut list. Bring your tape, square, and notepad to check the wall width, depth, and vertical clearance. Verify stud locations and any hose or outlet positions. If the width or depth has changed from your earlier notes, switch to the alternate cut list variant you prepared. Mark any irregularities for touch-ups on Sunday.




If your preferred 15 inch shelf depth is unavailable, choose 12 inch and adjust the sketch.

Next, finalize your sketch. Draw a simple front elevation that includes shelf spacing, cleat positions, and countertop dimensions. Make notes for renter-friendly fasteners or the owner upgrade path if you plan to anchor into studs. This sketch will serve as your build map throughout the project.

Prepare your tools and supplies. Charge batteries, set out bits, blades, and a fresh tube of caulk. Pack your safety gear and create a checklist for Saturday morning. Don't forget to include painter's tape and a marker in your tool bag for labeling components later.

**DO THIS**

1. Confirm wall width, depth, and vertical clearance.
2. Finalize a sketch with shelf spacing and cleat positions.
3. Prepare tools and supplies for the next day.

### WHERE THIS GOES WRONG

Failing to double-check measurements can lead to costly mistakes in cutting materials.

### BEFORE YOU MOVE ON

Confirm measurements against your notes.

Finalize your sketch with all dimensions.

Prepare tools and supplies for Saturday.



SATURDAY MORNING


# Saturday Morning: Acquire And Stage

*IN THIS APARTMENT*

*Ravi heads to the local hardware store in Pune early Saturday morning, armed with his shopping list and a clear plan to acquire all necessary materials for his alcove.*

## Efficient acquisition saves time and effort.

Follow your shopping map to navigate the store quickly. Many home centers offer sheet cutting services, so ask for straight cuts to reduce your home cutting time. If checkout lines are slow, consider sending a second person to grab hardware while you wait. Organize your cart by category to speed up the loading process.




Adjusting shelf depth based on availability.

Once you have your materials, transport them to a staging area near the alcove. Lay sheets flat on spacers and label the edges with painter's tape according to your cut list names, such as left upright, right upright, rear cleat, and top shelf. Set up a clear waste bin for offcuts to keep your workspace organized.

Be prepared for out-of-stock substitutions. If your preferred 15 inch shelf depth is unavailable, choose 12 inch and adjust your sketch accordingly. Narrow shelves can still accommodate detergent and bins, but you may need to reduce the number of shelves if vertical spacing is tight.

**DO THIS**


1. Follow your shopping map to acquire materials.
2. Transport materials to the staging area and label them.
3. Be ready to adjust your plans for out-of-stock items.

### WHERE THIS GOES WRONG

Not organizing materials can lead to confusion and wasted time during assembly.

### BEFORE YOU MOVE ON

- Acquire all materials according to your shopping list.
- Label materials clearly for easy access.
- Prepare for potential substitutions in your plans.



SATURDAY MIDDAY

# Saturday Midday: Build The Core

*IN THIS APARTMENT*

*After acquiring all materials, Ravi begins the building process in his Pune apartment. He focuses on cutting and assembling the core components of his laundry alcove.*

> **Building the core components is essential for functionality.**

Start by cutting the components. Use a saw to cut uprights, shelves, and cleats according to your measurements. Ensure that you are working in a well-ventilated area and wearing appropriate safety gear. Take your time to make precise cuts, as these will form the backbone of your alcove.

Next, install cleats and uprights. Use a level to ensure that everything is straight and secure. Set the countertop in place and make sure it is stable. This is a critical step, as the countertop will serve as the primary workspace for your laundry tasks. Secure the critical shelves next, ensuring they are positioned correctly and can support the weight of your laundry supplies.

After each component is installed, use decision checkpoints to assess your progress. If any adjustments are needed, make them before moving on to the next step. This will help maintain momentum and ensure that your alcove is functional even if finishing touches take longer than expected.

**DO THIS**

1. Cut components according to your measurements.
2. Install cleats and uprights, ensuring everything is level.
3. Secure the countertop and critical shelves.

**WHERE THIS GOES WRONG**

Rushing through the cutting and installation process can lead to misaligned components.

**BEFORE YOU MOVE ON**

Cut all components accurately according to your plan.

Ensure all installations are level and secure.

Use decision checkpoints to assess progress.



SUNDAY

# Sunday: Finish And Hardware

*IN THIS APARTMENT*

*On Sunday, Ravi focuses on the finishing touches for his laundry alcove, ensuring it is both functional and aesthetically pleasing before the weekend ends.*

> **Finishing touches enhance functionality and appearance.**

Start by caulking joints to ensure a clean finish. Use a caulk gun to apply caulk to any gaps between the countertop and walls or between shelves. This not only improves the appearance but also prevents moisture from seeping into the seams, which is crucial in a laundry area.

Next, prime and paint the alcove. Choose a paint color that complements your existing decor. Apply at least two coats for a durable finish, allowing adequate drying time between coats. This step is essential for protecting the wood and enhancing the overall look of your alcove.

Finally, install hooks or baskets for additional storage. Use wall-mounted hooks for hanging items or baskets for organizing smaller supplies. This will help keep your laundry area tidy and functional, making it easier to manage laundry tasks.

**DO THIS**

1. Caulk joints for a clean finish.
2. Prime and paint the alcove with at least two coats.
3. Install hooks or baskets for additional storage.

**WHERE THIS GOES WRONG**

Neglecting to caulk or paint properly can lead to a less durable and visually appealing alcove.

**BEFORE YOU MOVE ON**

- [ ] Caulk all joints for a clean finish.
- [ ] Apply paint with at least two coats for durability.
- [ ] Install storage solutions like hooks or baskets.



CHAPTER

# Troubleshooting Old Houses And Tight Clearances

Old houses tell stories, and your laundry alcove might be the chapter with the most plot twists. Bowed studs, wavy plaster, out of square corners, and appliances that barely fit can turn a straightforward build into a puzzle. The good news is, you do not need to redesign your project or blow the budget. You just need a small set of fixes and a calm process.



DAY 1

# Understanding Fit Problems

*IN THIS APARTMENT*

*In a 1BHK apartment in Pune, resident Neha found that her new washing machine barely fit into the alcove due to bowed studs and uneven plaster. The shelf above the machine left a noticeable gap on one side, complicating the installation.*

> **Fit problems often arise from uneven walls and misaligned appliances.**

Old houses, and many tight closets, were rarely designed for modern laundry machines. Studs can bow, drywall can wave, and floors can slope toward a drain, leading to fit problems. In Neha's case, the shelf above the washing machine did not meet the wall cleanly, creating an unsightly gap.

To address this, Neha could use a compass-style scribe or a simple tool made from a block of wood and a pencil. By dry fitting the shelf against the wall and tracing the wall's shape onto the shelf, she could cut along the line using a jigsaw or coping saw, ensuring a tight fit without gaps.

Additionally, composite shims could be used behind the cleats to level them out. By stacking shims behind the low sections until the cleat reads level, Neha can secure it with screws, ensuring the shelf sits flush.

> **WHERE THIS GOES WRONG**
>
> Cutting too much during scribing can leave gaps that are hard to hide, so it's essential to take off small amounts and refit.



DAY 2

# Managing Clearance Conflicts

*IN THIS APARTMENT*

*In a Bengaluru rental, Rajesh faced a clearance conflict when his bifold laundry door skimmed the edge of a newly installed shelf, making it difficult to open without catching.*

> **Clearance conflicts can often be resolved with simple adjustments rather than extensive renovations.**

Closet doors, bifolds, and swing doors need room to operate, and Rajesh's situation was a perfect example. To resolve this, he could reduce the shelf depth by half an inch where the door needed to pass. This adjustment would allow the door to swing freely without snagging on the shelf.

Another effective solution is to swap to low-profile pulls on doors or panels to prevent catching. Additionally, adding a soft bumper where the door meets the shelf edge can help prevent scuffs and wear on the paint.

By implementing these small changes, Rajesh can maintain the functionality of his laundry alcove without major alterations, keeping the project within budget and timeline.

> **WHERE THIS GOES WRONG**
>
> Over-shimming a cleat can lead to a spongy feel, so it's important to avoid thick stacks and consider a longer anchor if needed.



DAY 3

# Leveling Appliances and Controlling Vibration

*IN THIS APARTMENT*

*In a Mumbai flat, Aditi noticed her washing machine vibrated excessively during spin cycles, causing noise and movement across the floor.*

> **Proper leveling of appliances is crucial to prevent noise and movement during operation.**

Slope and flex in the flooring can cause appliances to wobble and create noise. Aditi can start by using the built-in adjustable feet of her washing machine. By placing a level across the washer from front to back and side to side, she can adjust the feet until the bubble centers, ensuring stability during operation.

To further test the stability, Aditi can perform the coin test. Placing a coin on top of the washer during the spin cycle will help her determine if the machine is level. If the coin vibrates across the top, she needs to adjust the feet until it stays put.

Additionally, using dense rubber pads under each foot can help control vibration. Aditi should avoid soft foam pads, as they can compress unevenly and worsen vibration issues.

> **WHERE THIS GOES WRONG**
>
> Not leveling the dryer can lead to increased wear on rollers and additional noise, so it's essential to check both appliances for proper leveling.



DAY 4

# Moisture Management Solutions

*IN THIS APARTMENT*

*In a Kolkata apartment, Meera dealt with minor leaks and moisture buildup in her laundry alcove, which posed a risk of damage to the surrounding walls.*

> **Effective moisture management is essential in tight spaces to prevent damage and maintain a clean environment.**

Moisture can be a significant issue in tight spaces, especially in laundry alcoves. Meera can start by placing a drip pan under her washer if the floor slopes away from a drain. Choosing a drip pan that fits and leaves room for leveling feet is crucial to prevent water damage.

Caulking the seam where the countertop meets the wall and along the top edge of side panels with paintable silicone will provide flexibility and easy touch-ups. This step is vital to prevent water from seeping behind panels and causing damage over time.

Adding a splash guide on the wall behind hoses and beside the washer can help deflect small sprays. A strip of vinyl cove base or a painted and sealed board can serve this purpose effectively.

> **WHERE THIS GOES WRONG**
>
> Skipping caulk around splash zones can lead to water damage; always use paintable silicone and allow proper cure time.



CHAPTER

# Printable Measurement Templates And Label Set

paper, tape to your alcove, and capture accurate dimensions and layout marks in minutes. Includes width, depth, and height grids, clearance markers for vents, outlets, and trim, layout overlays for stacked or side by side machines, and a full label set for parts and zones. Also includes a quick measure checklist, inches to fractions conversion chart, and a label legend.



PART 16

# Printable Measurement Templates And Label Set

> **Standardizes labels so every piece and zone is clearly identified during cutting and installation.**


paper, tape to your alcove, and capture accurate dimensions and layout marks in minutes. Includes width, depth, and height grids, clearance markers for vents, outlets, and trim, layout overlays for stacked or side by side machines, and a full label set for parts and zones. Also includes a quick measure checklist, inches to fractions conversion chart, and a label legend.

### Labels Mark Cleat A At 34 Inches

| Parameter | Value |
| --- | --- |
| Spec 1 | **34 in** |
| Spec 2 | **56 in** |

Labels mark Cleat A at 34 inches for folding surface and Cleat B at 56 inches for detergents.

Reduces measurement errors and rework, ideal for a weekend schedule and budget. Standardizes labels so every piece and zone is clearly identified during cutting and installation. Speeds layout decisions for shelves, cleats, and hampers before purchasing. Helps visualize clearances for doors, hoses, and vents for safe operation.




Depth grid records 32 inches at center and 30 inches at right due to trim.

Measure alcove width at floor, mid height, and top. Measure depth at left, center, and right. Measure height at back and front. Mark outlet location and face height. Mark vent center, diameter, and offset. Note trim thickness and any overhangs. Confirm washer and dryer door swing clearances. Identify stud locations for cleats. Plan shelf spacing based on bottle heights.

Photograph the labeled alcove for reference. Measurement Templates Width Grid, one inch squares with left and right datum lines. Depth Grid, one inch squares with front and back datum lines. Height Grid, vertical scale, mark shelf and cleat elevations. Clearance Markers, outlet, vent, hose, and trim tabs. Layout Overlays, stacked pair, side by side pair, and folding surface.

Label Set, use on painter's tape or print labels Left Upright, Right Upright, Cleat A, Cleat B, Cleat C, Shelf 1, Shelf 2, Shelf 3. Detergents, Tall Bottles, Hampers, Folding Surface, Tools, Spare Parts. Stud Here, No Screw, Cut Edge, Face Edge, Sand, Paint, Install. Conversion Chart, inches to common fractions 1 inch equals 16 sixteenths. 1 sixteenth equals 0.0625 inch. 2 sixteenths equals 1 eighth. 4 sixteenths equals 1 quarter. 8 sixteenths equals 1 half.

12 sixteenths equals 3 quarters. Layout Worksheet Alcove width at floor, mid, top: Alcove depth left, center, right: Alcove height back, front: Outlet height and offset: Vent center and diameter: Stud positions: Shelf elevations and spacing: Cleat lengths and positions: Appliance layout, stacked or side by side:

width grid shows a one inch taper on the right. Labels mark Cleat A at 34 inches for folding surface and Cleat B at 56 inches for detergents. Clearance markers reveal an outlet at 42 inches. The side by side overlay confirms door swing needs two inches on the left, so Shelf 3 is shifted one inch right.

and 30 inches at right due to trim. The stacked overlay fits better. Labels set Tall Bottles at 20 inches above the dryer. The vent marker at 5 inches offset drives a three quarter inch notch on the rear cleat.

Always measure twice and mark once. Photograph each template before removing it. Use contrasting marker colors for dimensions versus notes. Keep labels consistent with the legend to avoid confusion.

Ignoring trim thickness, shelves then bind. Skipping outlet and vent markers, leads to interference. Mixing units, inches and centimeters do not match. Forgetting stud locations, cleats miss structure.

shopping map. Match each cut to the labeled positions and zones. Use the worksheet to confirm quantities before purchase, so the weekend makeover stays under budget and on schedule.




CHAPTER

# Aisle-By-Aisle Shopping Maps For Major Home Centers

This guide provides a comprehensive overview of how to navigate major home centers efficiently, ensuring you can find everything you need for your home projects without unnecessary stress.



DAY 1

# Navigating Home Depot

*IN THIS APARTMENT*

*Ravi, a resident of Pune, is planning a laundry alcove makeover in his compact 1BHK apartment. He heads to Home Depot to gather materials.*

> **A clear shopping route saves time and reduces stress.**

At Home Depot, start at the lumber and sheet goods section located at the back wall near the panel saw. Here, you'll find plywood, MDF, and melamine. Measure and record the dimensions you need before selecting your materials.

Next, head to the mid-store hardware bay for fasteners. Look for screws, anchors, and brackets that match your project requirements. It's crucial to check the SKU from the shelf tag to ensure you get the correct items for your build.

After gathering hardware, proceed to the paint wall endcap for adhesives and caulk. You'll find construction adhesive, silicone, and latex caulk here. Make sure to note the SKU for future reference.

**DO THIS**

1. Print the shopping map and list before your visit.
2. Circle your route in the order listed to streamline your shopping experience.
3. At each zone, find your item, record the SKU from the shelf tag, and check off your list.

**WHERE THIS GOES WRONG**

Skipping the kerf measurement can lead to short parts that won't fit your project.

**BEFORE YOU MOVE ON**

Tape measure, verify fit

Moving blankets or cardboard

Tie downs or rope, two minimum

Edge protection and face to face stacking

Door and hatch clearance test



DAY 2

# Shopping at Lowe's

*IN THIS APARTMENT*

*Anjali, living in a small Bengaluru rental with a load-bearing wall, needs to buy materials for a shelving unit. She decides to visit Lowe's.*

> **Knowing store layouts helps in quick access to necessary materials.**

At Lowe's, begin your shopping in the rear panel saw area for lumber and sheet goods. Look for plywood, MDF, and melamine. Be sure to measure your required dimensions accurately before selecting your materials.

Next, navigate to the central hardware aisles for fasteners. Here, you'll find an assortment of screws, nails, and brackets. Always check the SKU from the shelf tag to ensure you're getting the right items.

Proceed to the paint corridor for adhesives and caulk. This is where you can find glue, caulk, and tape. Record the SKU for your purchase to avoid confusion later.

**DO THIS**

1. Choose the store you will visit and plan your arrival during off-peak hours.
2. At each zone, find your item, record the SKU from the shelf tag, and check off your list.
3. Use the cutting service script when buying sheet goods.

**WHERE THIS GOES WRONG**

Buying screws without checking their length can lead to breakthroughs in your project.

**BEFORE YOU MOVE ON**

- Tape measure, verify fit
- Moving blankets or cardboard
- Tie downs or rope, two minimum
- Edge protection and face to face stacking
- Door and hatch clearance test



DAY 3

# Finding Items at Menards

*IN THIS APARTMENT*

*Deepak, residing in a Mumbai flat with a window on only one side, needs to buy materials for a DIY project. He heads to Menards.*

> **Familiarity with store zones enhances shopping efficiency.**

At Menards, start your shopping in the yard or rear saw area for lumber and sheet goods. Look for panels and studs that fit your project specifications. Measure and record the dimensions you need before selecting your materials.

Next, head to the long hardware run for fasteners. You'll find assorted bins and drawers filled with screws, anchors, and brackets. Always check the SKU from the shelf tag to ensure you're getting the correct items for your build.

Finally, visit the paint counter for primers and paint. Make sure to note the SKU for your purchase to avoid confusion later.

**DO THIS**

1. Print the shopping map and list before your visit.
2. Circle your route in the order listed to streamline your shopping experience.
3. Before checkout, run the vehicle load out checklist.

**WHERE THIS GOES WRONG**

Loading panels without padding can lead to edge damage during transport.

**BEFORE YOU MOVE ON**

Tape measure, verify fit

Moving blankets or cardboard

Tie downs or rope, two minimum

Edge protection and face to face stacking

Door and hatch clearance test



CHAPTER

# 48-Hour Weekend Build Checklist

This checklist provides a structured approach to transforming your laundry alcove over a weekend, ensuring you stay on track and within budget.




FRIDAY EVENING

# Purpose and Benefits

*IN THIS APARTMENT*

*Ravi and Priya live in a 1BHK in Pune with a small laundry alcove. They want to maximize storage while keeping the project budget under ₹15,000.*

> **This checklist keeps your project under control and on budget.**

The 48-Hour Weekend Build Checklist is designed to streamline your laundry alcove makeover, ensuring you finish by Sunday night. It minimizes decision fatigue and helps you focus on essential tasks like installing core shelves and a countertop.


By following this checklist, you can anticipate common delays and adjust your plan without sacrificing functionality. This is particularly useful for busy couples like Ravi and Priya, who need to coordinate their efforts efficiently.

The checklist also flags must-do elements, allowing you to prioritize tasks effectively, especially if you find yourself falling behind.

> **WHERE THIS GOES WRONG**
>
> Forgetting to review the checklist can lead to missed steps and delays.

**BEFORE YOU MOVE ON**

- Identify the alcove dimensions: width, depth, height.
- List necessary tools and materials.
- Set a budget not exceeding ₹15,000.




FRIDAY EVENING

# How to Use

*IN THIS APARTMENT*

*Ravi prints the checklist and tapes it next to their laundry alcove, ready to mark off tasks as they complete them.*

> **Review each section before you begin to stay organized and efficient.**

To effectively use the checklist, print it out and tape it next to your alcove. This will serve as a constant reminder of the tasks ahead and keep you organized throughout the weekend.

As you progress, mark checkboxes to track your completion of each task. This visual progress can be motivating and help you stay on schedule.

Utilize decision checkpoints to determine whether to proceed with a task or make adjustments. If you find yourself falling behind, refer to the priority tasks noted in the checklist to stay focused.


> **WHERE THIS GOES WRONG**
>
> Skipping the decision checkpoints can lead to unnecessary delays and budget overruns.

**BEFORE YOU MOVE ON**

Print the checklist and tape it next to your alcove.

Mark checkboxes as you complete each task.

Use decision checkpoints to adjust your plan if needed.



FRIDAY EVENING

# Friday Evening: Prep and Plan

*IN THIS APARTMENT*

*Ravi and Priya clear their alcove, measuring the space in their small Pune apartment to ensure everything fits.*

## Preparation is key to a successful build.

Start by clearing the alcove of any obstacles. This will give you a clean slate to work with and make measuring easier. Measure the width, depth, and height of the alcove, noting any outlets and hoses that may affect your design.

Once you have your measurements, review the main ebook cut lists and shopping map. Highlight affordable options to ensure you stay under ₹15,000. This will help you make informed decisions when purchasing materials.

If the surfaces of your alcove are glossy, plan to apply primer. This will add an additional 30 minutes to your Saturday schedule, so factor that into your timeline.

> **WHERE THIS GOES WRONG**
>
> Neglecting to measure accurately can lead to poor fitting shelves and wasted materials.

**BEFORE YOU MOVE ON**

Clear the alcove of obstacles.

Measure width, depth, and height.

Note any outlets and hoses.



SATURDAY MORNING

# Saturday Morning: Shopping

*IN THIS APARTMENT*

*Ravi and Priya head to a local hardware store in Pune, following their shopping map to gather materials for their project.*

> **Careful shopping ensures you have the right materials for your build.**

Follow your shopping map to buy the necessary materials for your project. This includes lumber for shelves, a budget countertop panel or plywood, brackets, screws, primer, paint, caulk, and pads. Make sure to verify your materials against the cut list to avoid any discrepancies.

When selecting lumber, choose straight boards and avoid warped stock. This will save you time and frustration during the cutting and assembly phases.

If a preferred board size is out of stock, adjust your cut list to the next available size and reduce the shelf count by one to stay within budget.

> **WHERE THIS GOES WRONG**
>
> Purchasing warped boards can lead to structural issues in your build.

**BEFORE YOU MOVE ON**

- Follow the shopping map to gather materials.
- Verify materials against the cut list.
- Choose straight boards and avoid warped stock.



30 DAY SPACES

# Your next room starts here

More room kits, declutter sprints, and measured layouts for Indian apartments — same series language, same clear numbers.

Akarsh Priyadarshan