1.3 RADAR BLOCK DIAGRAM AND OPERATION

The operation of a typical pulse radar may be described with the aid of the block diagram shown in Fig. 1.2. The transmitter may be an oscillator, such as a magnetron, that is "pulsed" (turned on and off) by the modulator to generate a repetitive train of pulses. The magnetron has probably been the most widely used of the various microwave generators for radar. A typical radar for the detection of aircraft at ranges of 100 or 200 nmi might employ a peak power of the order of a megawatt, an average power of several kilowatts, a pulse width of several microseconds, and a pulse repetition frequency of several hundred pulses per second. The waveform generated by the transmitter travels via a transmission line to the antenna, where it is radiated into space. A single antenna is generally used for both transmitting and receiving. The receiver must be protected from damage caused by the high power of the transmitter. This is the function of the duplexer. The duplexer also serves to channel the returned echo signals to the receiver and not to the transmitter. The duplexer might consist of two gas-discharge devices, one known as a TR (transmit-receive) and the other an ATR (anti-transmit-receive). The TR protects the receiver during transmission and the ATR directs the echo signal to the receiver during reception. Solid-state ferrite circulators and receiver protectors with gas-plasma TR devices and/or diode limiters are also employed as duplexers.

The receiver is usually of the superheterodyne type. The first stage might be a low-noise RF amplifier, such as a parametric amplifier or a low-noise transistor. However, it is not always desirable to employ a low-noise first stage in radar. The receiver input can simply be the mixer stage, especially in military radars that must operate in a noisy environment. Although a receiver with a low-noise front-end will be more sensitive, the mixer input can have greater dynamic range, less susceptibility to overload, and less vulnerability to electronic interference.

The mixer and local oscillator (LO) convert the RF signal to an intermediate frequency (IF). A "typical" IF amplifier for an air-surveillance radar might have a center frequency of 30 or 60 MHz and a bandwidth of the order of one megahertz. The IF amplifier should be designed as a matched filter; i.e., its frequency-response function H(f) should maximize the peak-signal-to-mean-noise-power ratio at the output. This occurs when the magnitude of the frequency-response function |H(f)| is equal to the magnitude of the echo signal spectrum |S(f)|, and the phase spectrum of the matched filter is the negative of the phase spectrum of the echo signal (Sec. 10.2). In a radar whose signal waveform approximates a rectangular pulse, the conventional IF filter bandpass characteristic approximates a matched filter when the product of the IF bandwidth B and the pulse width τ is of the order of unity, that is, $B\tau \simeq 1$.

After maximizing the signal-to-noise ratio in the IF amplifier, the pulse modulation is extracted by the second detector and amplified by the video amplifier to a level where it can be




Figure 1.2 Block diagram of a pulse radar.

properly displayed, usually on a cathode-ray tube (CRT). Timing signals are also supplied to the indicator to provide the range zero. Angle information is obtained from the pointing direction of the antenna. The most common form of cathode-ray tube display is the plan position indicator, or PPI (Fig. 1.3a), which maps in polar coordinates the location of the target in azimuth and range. This is an intensity-modulated display in which the amplitude of the receiver output modulates the electron-beam intensity (z axis) as the electron beam is made to sweep outward from the center of the tube. The beam rotates in angle in response to the antenna position. A B-scope display is similar to the PPI except that it utilizes rectangular, rather than polar, coordinates to display range vs. angle. Both the B-scope and the PPI, being intensity modulated, have limited dynamic range. Another form of display is the A-scope, shown in Fig. 1.3b, which plots target amplitude (y axis) vs. range (x axis), for some fixed direction This is a deflection-modulated display. It is more suited for tracking-radar application than for surveillance radar.