





STM32H755 NUCLEO

Audio Peripheral Module



UART -> USB Debug Port

UART debug messages available via a USB port and a 3 pin jumper for TX, RX, and GND UART connections



Sheet: /USB_debug_APM/
File: USB_debug_APM.kicad_sch

Title:


Size: A4

Date:

Rev:


KiCad E.D.A. 10.0.3

Id: 2/5



Power Monitor and Supply

PMS has an INA219 current sensor
for each board/node in the
PCB. Each takes in the 5V from it's
parent board and supplies 5V to said
board's circuit (its peripherals)
thus enabling monitoring



Sheet: /PMS_APM/
File: PMS_APM.kicad_sch

Title:

Size: A4
KiCad E.D.A. 10.0.3

Date:

Rev:
Id: 4/5

