

<MEZW65C_RAM GPIO割り当て>							
GPIO	名前	PIC	ピン	GPIO	名前	PIC	ピン
GP0	D0/BR0	RB0	J3-8,U2-2	GP24	-	-	-
GP1	D1/BR1	RB1	J3-7,U2-3	GP25	LED (※)	-	at poco board
GP2	D2/BR2	RB2	J3-6,U2-4	GP26	CLK	RA3	J2-5
GP3	D3/BR3	RB3	J3-5,U2-5	GP27	R/W	RA4	J2-6
GP4	D4/BR4	RB4	J3-4,U2-6	GP28	RDY	RA5	J2-7
GP5	D5/BR5	RB5	J3-3,U2-7		RUN	RE3	J2-1
GP6	D6/BR6	RB6	J3-2,U2-8		AL0	RC0	U2-19,J2-15
GP7	D7/BR7	RB7	J3-1,U2-9		AL1	RC1	U2-18,J2-16
GP8	RES	RE0	J2-8		AL2	RC2	U2-17,J2-17
GP9	NMI	RE1	J2-9		AL3	RC3	U2-16,J2-18
GP10	FF_CK	-	U1/U2-11		AL4	RC4	U2-15,J3-18
GP11	FF_OE	-	U1/U2-1		AL5	RC5	U2-14,J3-17
GP12	UART TX	RA6	J2-14		AL6	RC6	U2-13,J3-16
GP13	UART RX	RA7	J2-13		AL7	RC7	U2-12,J3-15
GP14	SDA	-	J7-2		AM0	RD0	U1-19,J2-19
GP15	SCL	-	J7-1		AM1	RD1	U1-18,J2-20
GP16	MISO	-	J1-2		AM2	RD2	U1-17,J3-20
GP17	SPI_CS	-	J1-5		AM3	RD3	U1-16,J3-19
GP18	SPI_CK	-	J1-3		AM4	RD4	U1-15,J3-14
GP19	MOSI	-	J1-4		AM5	RD5	U1-14,J3-13
GP20	BE	RA0	J2-2		AM6	RD6	U1-13,J3-12
GP21	DCK	RA1	J2-3		AM7	RD5	U1-12,J3-11
GP22	IRQ	RA2	J2-4		SPI_SS	RE2	J2-10,+5V
GP23	-	-	-				
※ GP25のLEDは、SDカードアクセス時に点滅							