



Procedure for communicate with T-Series ForTest using Bluetooth




Started: 19-06-2018

Last update: 19-06-2018


This procedure describes how to set up communication with ForTest T-Series devices on a PC using Windows 10 as OS equipped with a Bluetooth device. In this example a T8000 Series will be connected to a laptop and using the software [Leak Test Manager](#) will be possible to manage the equipment.

1. From the SET menu of the equipment set the connection type to BT 2.0.


NOTE: Please note that BLE connection is also possible but is not currently supported from the PC software, so in this example will not be taken in consideration.




2. Right clic on the Start icon → “Settings”




3. Select “Devices”




4. Select “Add Bluetooth devices”



5. Select “**Bluetooth**”



6. Select the Bluetooth name of your device (the syntax is “FORTEST-SNxxxxx” where “xxxxx” is the serial number of the equipment associated)




7. Wait connection is completed



8. If connection is ok the device will be associated and 2 new Virtual COM ports will be created



9. Choosing “Others Bluetooth option” from the “Devices” menu, is it possible to detect which virtual COM ports are associated to the ForTest device. In this case for example COM 14 is used as output and COM13 as input. To communicate with a device is it necessary to use always output port, so in this case we have to open COM14.



Attiva il Bluetooth ancora più rapidamente

Per attivare o disattivare il Bluetooth senza aprire Impostazioni, apri il centro notifiche e seleziona l'icona Bluetooth.

Impostazioni correlate

[Dispositivi e stampanti](#)

[Impostazioni audio](#)

[Impostazioni dello schermo](#)

[Altre opzioni Bluetooth](#)

[Invia o ricevi file tramite Bluetooth](#)

Assistenza dal Web

[Risoluzione dei problemi delle connessioni Bluetooth](#)

[Reinstallazione dei driver Bluetooth](#)


[Condivisione di file tramite Bluetooth](#)

 [Informazioni](#)


 [Invia feedback](#)

10. Open “Leak Test Manager” and configure from the tab panel “RS232” the virtual port “COM14” with these settings:

- Baudrate: 115200 bps
- Address: 01
- Timeout: values from 5000 to 10000
- Forces: Yes
- TTY : No



11. Confirm the settings and re-launch the application. The software now is able to get and send data parameters.



NOTE : Is it also possible to use Bluetooth interface to communicate opening the Virtual COM port associated and use the command protocol described in the document “Communication Protocol ForTest for M-Series and T-Series”.

Technical Support

ForTest Italia S.r.l.
Via Sibilla Aleramo, 7
41123 Modena (MO)

Tel. 0039 (0) 059 557250
Fax. 0039 (0) 059 579022

Web – Email :
<https://www.fortest.com>
support@fortest.com