Your first *violin.*

4/4

FULL-SIZE ACOUSTIC

SOLID WOOD / PRACTICE ESSENTIALS / 2-YEAR WARRANTY



VRT-AmiOB / VRT-AmiCS / VRT-MS / VRT-CS

For first lessons and the practice that follows.

Make practice part of life.

Full-size instruments with essentials for learning, practice and carrying.





VRT-MS

4/4 acoustic violin

Pre-fitted bridge / rosin included

VRT-CS

4/4 acoustic violin

Pre-fitted bridge / rosin included

Ready to carry to the next lesson.

The hard case combines a plush interior, secured bow storage and room for accessories. The included carrying strap helps keep the violin and daily practice items together for trips to lessons and rehearsals.

Details you can use.

Details shown on VRT-AmiOB and VRT-MS




Spruce & Canadian maple

Solid spruce and Canadian maple give the acoustic body a warm, clear voice for scales and melodies.



Fingerboard & stickers

A polished surface supports everyday fingering practice. The included stickers can be used as guided by your teacher.



Four fine tuners

One fine tuner per string lets you make small pitch corrections while checking the electronic tuner.



Bridge & alloy strings

The bridge is fitted before shipping. Alloy strings support daily practice; check the instrument and tune after arrival.

A closer look at making.

Workshop photographs reveal the instrument taking shape.



Unfinished scrolls, necks and bodies.



Tracing the outline

An outline is traced with a template, following the curves of the body.



Clamped assembly

Clamps hold curved sections in position as the body is assembled.

A good start, step by step.

The bridge is pre-fitted. Check, tune and prepare the bow before playing.

01 Check the full-size fit

A 4/4 violin is full-size. Check arm reach and playing posture with a teacher before choosing; age alone is not a fit guide.

02 Inspect the pre-fitted bridge

The bridge is fitted before shipping. Check for obvious leaning, looseness or movement in transit; contact support if something looks wrong.

03 Set bow tension, then apply rosin

Adjust the hair to suitable playing tension while keeping the stick curved, then apply rosin evenly. Avoid touching the hair with your fingers.

04 Check pitch one string at a time

Check each string with the tuner and use the fine tuners for small corrections. New strings may need frequent tuning as they settle; ask a teacher for help if needed.

05 Wipe down and put away

Loosen the bow hair, wipe rosin dust and perspiration with a clean, soft dry cloth, then secure the violin and bow in the case.

See the included user manual for full instructions, or contact cs@aklot.com.

Support for your practice

2

YEAR
WARRANTY

cs@aklot.com

Product use, tuning and after-sales support

Help us understand the issue

Include your model, Amazon order number, a description of the issue, and clear photos or a short video so our team can review and follow up.

For specifications, included items and warranty questions, contact our support team.