F28069 USB controlSTICK PIN-OUT TABLE

ADC-A6 COMP3 (+VE)	ADC-A2 COMP1 (+VE)	ADC-A0	4 3V3
5 ADC-A4 COMP2 (+VE)	6 ADC-B1	7 EPWM-4B GPIO-07	8 TZ1 GPIO-12
9 SCL-A GPIO-33	ADC-B6 COMP3 (-VE)	11 EPWM-4A GPIO-06	ADC-A1
SDA-A GPIO-32	14 ADC-B0	15 EPWM-3B GPIO-05	16 5V0 (Disabled by Default)
17 EPWM-1A GPIO-00	ADC-B4 COMP2 (-VE)	19 EPWM-3A GPIO-04	20 SPISOMI-A GPIO-17
21 EPWM-1B GPIO-01	ADC-A5	EPWM-2B GPIO-03	24 SPISIMO-A GPIO-16
25 SPISTE-A GPIO-19	26 ADC-B2 COMP1 (-VE)	27 EPWM-2A GPIO-02	28 GND
29 SPICLK-A GPIO-18	30 GPIO-34 (LED)	31 PWM1A-DAC (Filtered)	32 GND