
VisionBot - ID 10 - ROBOT (top of robot)

Print at 100% ("Actual size") on A4 - NOT "fit to page"

FRONT - this edge points to the FRONT of the robot



cut on the GRAY line - KEEP the white border around the black square




check bar: must measure exactly 8.0 cm (8 ticks = 8 cm)

1. Print at 100% / 'Actual size' on A4 - no 'fit to page', no shrinking.
2. Measure the black square: should be ~8.0 x 8.0 cm - note the real size.
3. Cut on the gray line, KEEPING the white border (the camera needs it).
4. Glue FLAT on thin cardboard, fix it level on top of the robot.
5. FRONT arrow must point towards the robot's front (travel direction).

VisionBot - ID 20 - TARGET (destination card)

Print at 100% ("Actual size") on A4 - NOT "fit to page"

card edge 'up' (any facing is fine)



cut on the GRAY line - KEEP the white border around the black square




check bar: must measure exactly 8.0 cm (8 ticks = 8 cm)

1. Print at 100% / 'Actual size' on A4 - no 'fit to page', no shrinking.
2. Measure the black square: should be ~8.0 x 8.0 cm - note the real size.
3. Cut on the gray line, KEEPING the white border (the camera needs it).
4. Glue FLAT in the middle of a ~12 x 12 cm card (destination card).
5. Any orientation is fine - the robot reaches the card from any side.


VisionBot - ARENA CORNER MARKERS (IDs 30-33)

These let the program correct an angled/tilted camera automatically.


Tape each one FLAT inside its arena corner, named as the CAMERA sees the picture:




ID 30 - TOP-LEFT corner



ID 31 - TOP-RIGHT corner



ID 33 - BOTTOM-LEFT corner



ID 32 - BOTTOM-RIGHT corner

Each corner marker is ~6 x 6 cm and stays fixed for the whole demo.

Check on screen: a robot standing near ID 30 must appear at the TOP-LEFT of the picture.

If corners end up swapped on the arena, the robot will drive mirrored - just re-tape.