

# Short Guidance for Container Candle

**Step 1** Materials: soy wax, paraffin wax, fragrance essential oil, candle wick, candle wick glue, wax cup, wax melting bowl, wax melting furnace, temperature measuring gun, electronic scale, mixing spoon, etc.



**Step 2** Add the prepared soy wax/paraffin wax to the melting pot. A larger pot should be added to the outside of the melting pot to fill with water. Keep stirring until all the wax pieces have melted into a liquid.



**Step 3** Continue to wait for the wax liquid to cool to about 65 degrees Celsius, add a good fragrance essential oil, stir evenly (fragrance adding temperature must be lower than the flash point of the fragrance essential oil, to prevent the essential oil from volatilizing during the production process)



**Step 4** Then stick wick glue on the base of the candle wick, fix the base on the bottom of the container, and fix the cotton thread with a fixer (disposable chopsticks can be used instead), so that the candle wick is always in the middle of the container.



**Step 5** When the wax liquid with fragrance essential oil is cooled to about 55 degrees Celsius, slowly pour the wax liquid into the wax cup and wait for the wax liquid to cool and solidify completely. The first perfusion, you can leave a little wax liquid, to be cooled and solidified for the first time, and then thin on

the second layer, to ensure that the surface is smooth



**Step 6** Finally, after the wax liquid is completely solidified, trim the length of the candle wick and keep about 1-2cm (as you wish).

