



1= LDUR X2[x10, #0]

4: LDUR X5[X10,#0]

2: SUB X4, X2, X3

5 = SUB xb,x5,x3

7: SUBI X10, X10, #16

3: STUR X4[x10, #16]

S: BNZ X10, LOOP

6: STUR X6 [X10, #24]