Freescale MQX RTOS Example Guide Lwevent lite example

This document explains the lwevent_lite example, what to expect from the example and a brief introduction to the API.

The example

The lwevent_lite example code shows how a task waits for an event. This event can be set by any other process or interrupt in the system that can set the variable *lwevent*. The example simulates an ISR event using another simple task.

Running the example

The user only needs to do compilation of MQX libraries, ksdk library and the example without any further step.

Then we compile the project lwevent lite.

In <MQX folder>\rtos\mqx\config\mcu\<board>\mqx sdk config.h please set

1

#define MQX_USE_LOGS

If the platform supports floating point, you have to disable floating point:

#define MQXCFG ENABLE FP 0

And rebuild MQX library.

Connect a serial cable from the UARTO port of the board to the PC.

Start HyperTerminal on the PC (Start menu->Programs->Accessories->Communications).


Make a connection to the serial port that is connected to the board (usually will be COM1).



Set it for 115200 baud, no parity, 8 bits and click OK.



After the board is flashed the HyperTerminal will start printing the "Tick" message every certain time.



Explanation of the example

The example application creates two tasks. The service_task task creates a lwevent_lite group and enters a loop in which it waits for an event bit. When the appropriate lwevent bit is set, it clears it and prints "Tick.". The simulated_ISR_task task periodically sets the corresponding lwevent bit with a delay in between (no connection is opened to a lwevent group).

