### Scope

This document describes how to test USB MSD command example.

## **Preparation**

### Host

A board, i.e. twrk22f120m, which is running host\_msd\_cmd\_twrk22f120m example.

#### Device

A U-disk.

# Steps

Follow the steps to run the MSD cmd demo.

- 1. Run the host msd cmd twrk22f120m and you will see the printed guide note.
- 2. Plug-in the U-disk and you will see some attach information printed out. And then you will see the command test result. Such as:

```
======= START OF A NEW SESSION =========
```

Testing: GET MAX LUN Command...OK Testing: TEST UNIT READY Command...OK Testing: REQUEST SENSE Command...OK

Testing: INQUIRY Command...OK

Testing: REQUEST SENSE Command...OK

Testing: READ FORMAT CAPACITIES Command...OK

Testing: REQUEST SENSE Command...OK Testing: READ CAPACITY Command...OK Testing: REQUEST SENSE Command...OK

Testing: READ(10) Command...OK
Testing: MODE SENSE Command...OK

Testing: PREVENT-ALLOW MEDIUM REMOVAL Command...OK

Testing: REQUEST SENSE Command...OK

Testing: VERIFY Command...OK
Testing: WRITE(10) Command...OK
Testing: REQUEST SENSE Command...OK

Testing: START-STOP UNIT Command...OK

Test done!