Freescale MQX RTOS Example Guide

KLOG_lite example

This document explains the Klog_lite example, what to expect from the example and a brief introduction to the API used.

The example

The example shows the usage of the kernel log component of RTOS MQX. The kernel log allows user's application program to record the information about the context switch as tasks being re-scheduled and interrupt happened in the application program. The kernel log API is used to enable log for specific component and to display log information to terminal.

Running the example

The user only needs to do compilation of MQX libraries, ksdk library and the example without any further step.

Then we compile the project klog lite.

 $\label{local_max_sdk_config_mcu} In $$< MQX_folder>\rows_mqx\config\mcu\\$< mqx_sdk_config.h$ please set $$$

#define	MQX_USE_LOGS	1
#define	MQX_USE_LWLOGS	1
#define	MQX_KERNEL_LOGGING	1
#define	MQXCFG_STATIC_KLOG	0
#define	MQXCFG STATIC LWLOG	0

If the platform supports floating point, you have to disable floating point:

```
#define MQXCFG ENABLE FP 0
```

To run the example the corresponding IDE, compiler, debugger and a terminal program are needed.

Explaining the example

The application example creates only one task called main task.

The main_task creates the kernel log component as it is optional component of RTOS MOX.

The kernel log is then activated over specific components using command _klog_control(), for example

```
_klog_control(KLOG_ENABLED | KLOG_CONTEXT_ENABLED | LOG_INTERRUPTS_ENABLED | KLOG_SYSTEM_CLOCK_INT_ENABLED | KLOG_FUNCTIONS_ENABLED | KLOG_TIME FUNCTIONS | KLOG_INTERRUPT FUNCTIONS, TRUE);
```

The information of function switching, interrupt occurrence, task switching are displayed over the output terminal.

An example of the output is shown in the following figure.

