Scope

This document describes how to test USB Host PHDC example.

Preparation

Host

A board, i.e. twrk22f120m, which is running host_phdc example.

Device

A board, i.e. twrk70f120m, which is running dev_phdc_weighscale example.

Note: The device must be powered separately with the host.

Steps

Follow the steps to run the PHDC host demo.

- 1. Run the host_phdc example.
- 2. Plug-in the PHDC device and you will see some attach information printed out.
- 3. The PHDC device will automatic send reports to host. You can see information of scan report number, time, value and unit of each data field in terminal tool