Scope

This document describes how to use Health Link software to test PHDC device.

Preparation

Host

Personal computer running Windows Xp or Windows 7.

Device

A board, i.e. twrk70f120m, which is running dev_phdc_weighscale example.

Libraries dependency

The libraries dependency for various RTOS lists as following,

BM

Library project path:

- <install_dir>/usb/usb_core/device/lib/bm/<tool_chain>/<soc_name>
- <install dir>/lib/ksdk platform lib/<tool chain>/<platform>

FreeRTOS

Library project path:

- <install_dir>/usb/usb_core/device/lib/freertos/<tool_chain>/<soc_name>
- <install dir>/lib/ksdk freertos lib/<tool chain>/<platform>

MQX

Library project path:

- <install_dir>/rtos/mqx/mqx/build/<tool_chain>/mqx_<board>
- <install dir>/rtos/mqx/mqx stdlib/build/<tool chain>/mqx stdlib <board>
- <install_dir>/usb/usb_core/device/lib/mqx/<tool_chain>/<soc_name>
- <install_dir>/lib/ksdk_mqx_lib/<tool_chain>/<platform>

uCOSii

Library project path:

- <install dir>/usb/usb core/device/lib/ucosii/<tool chain>/<soc name>
- <install_dir>/lib/ksdk_ucosii_lib/<tool_chain>/<platform>

uCOSiii

Library project path:


- <install_dir>/usb/usb_core/device/lib/ucosiii/<tool_chain>/<soc_name>
- <install_dir>/lib/ksdk_ucosiii_lib/<tool_chain>/<platform>

Refer to Integration of the USB Stack and Kinetis SDK_review.pdf(<install_dir>/doc) on how to build the corresponding libraries.

Steps

Follow the steps to install and use Health Link software.

- Download Health Link software at http://www.lnihealth.com
 Contact with support@lnihealth.com to get license.
- 2. Install Health Link software and USB device driver.
- At the first time run Health Link, you should create new account to store data.
 In Edit Menu, choose Advance -> Transport Settings and make sure that Enable USB Connection check box is checked



4. Plug-in PHDC device into PC, you can see state of device and data received

