

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

8 Front brake pad check

1 Loosen the front wheel bolts. Firmly apply the parking brake, then raise the front of the vehicle and support it securely on jackstands. Remove the front wheels.

2 For a quick check, the thickness of friction material remaining on each brake pad can be measured through the top of the <u>caliper</u> body (see illustration) . If any pad's friction material thickness is not within specification, all four pads must be replaced as a set.

8.2 Check the thickness of the brake pad friction material through the hole in the caliper body



3 For a comprehensive check, the <u>brake pads</u> should be removed and cleaned. The operation of the <u>caliper</u> can then also be checked, and the condition of the <u>brake disc</u> itself can be fully examined on both sides. Refer to <u>Chapter 9</u> for further information.

© 2024 Haynes Manuals, Inc. Contact us