

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

## 9 Rear brake caliper - removal and installation

## Note:

Before starting work, refer to the precautions in <u>Section 1</u> and the warnings at the beginning of <u>Section 2</u>.

## Removal

- 1 Chock the front wheels, then jack up the rear of the vehicle and support on jackstands. Remove the relevant rear wheel.
- 2 Minimize fluid loss by first removing the <u>master cylinder</u> reservoir cap, and then tightening it down onto a piece of cellophane, to obtain an airtight seal. Alternatively, use a brake hose clamp, a C-clamp or a similar tool to clamp the flexible hose.
- 3 Clean the area around the fitting, then loosen the brake hose fitting nut.
- 4 Remove the brake pads as described in Section 4.
- 5 Unscrew the caliper from the end of the flexible hose, and remove it from the vehicle.

## Installation

- 6 Screw the caliper fully onto the flexible hose fitting.
- 7 Install the brake pads (refer to Section 4).
- 8 Securely tighten the brake line fitting nut.
- 9 Remove the brake hose clamp or cellophane, as applicable, and bleed the hydraulic system as described in <u>Section 2</u>. Note that, providing the precautions described were taken to minimize brake fluid loss, it should only be necessary to bleed the relevant rear brake.
- 10 Install the wheel, then lower the vehicle to the ground and tighten the wheel bolts to the torque listed in the <a href="Chapter 1 Specifications">Chapter 1 Specifications</a>. On completion, check the brake fluid level as described in <a href="Chapter 1">Chapter 1</a>.

© 2024 Haynes Manuals, Inc. Contact us