

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

8 Front stabilizer bar connecting link - removal and installation

Note:

New connecting link nuts will be required on installation.

- 1 Firmly apply the parking brake, then raise the front of the vehicle and support it securely on jackstands.
- 2 Unscrew the retaining nut, then free the connecting link from the <u>stabilizer bar</u> using a second wrench to counter-hold the link balljoint <u>stud</u>.
- 3 Loosen and remove the nut securing the link to the suspension strut, using a second wrench to counter-hold the link balljoint <u>stud</u> (see illustration 4.8) .
- 4 Check the connecting link <u>balljoints</u> for signs of wear. Check that each balljoint is free to move easily, and that the rubber boots are undamaged. If necessary, replace the connecting link.
- 5 Installation is the reverse of removal, using new nuts and tightening them to the specified torque setting.

© 2024 Haynes Manuals, Inc. Contact us