

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

4 Throttle cable - removal, installation and adjustment

Proceed as described in Part B of this Chapter, but note that it may be necessary to remove the securing screw(s), and fold back or withdraw the cover from the top of the $\underline{\text{throttle}}$ linkage for access to the throttle cable (see illustrations).

4.1a Withdraw the cover from the throttle linkage . . .



4.1b . . . for access to the throttle cable



4.1c Throttle cable adjuster screw (arrow)



© 2024 Haynes Manuals, Inc. Contact us