

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

## 1 General information

Models with an "x" in their designation, such as 325xi, are equipped with All Wheel Drive (AWD). These vehicles have two added components - the <u>transfer case</u> and the front differential. The transfer case is a group of gears in a housing attached to the rear of the transmission. The transfer case splits the power from the transmission to the front differential through a front <u>driveshaft</u>, and a rear driveshaft delivers power to the rear axle. The AWD feature is available with either a manual transmission or an automatic transmission.

The <u>transfer case</u> operates both differentials full-time. Some models are equipped with Active Torque Control (ATC), a traction management function that changes the delivery of torque from the transfer case, using an electronic <u>clutch</u>. Depending on the situation, the system may apply one or more brake calipers if wheelspin occurs, and differential output would go the opposite wheel.

© 2024 Haynes Manuals, Inc. Contact us