

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

24 Transfer case lubricant change (AWD models) (every 60,000 miles or 48 months)

Note:

The manufacturer does not suggest any scheduled changes of the transfer case lubricant.

- 1 Drive the vehicle for at least 15 minutes to warm the lubricant in the case.
- 2 Raise the vehicle and support it securely on jackstands.
- 3 Remove the check/fill plug, then the drain plug and allow the old lubricant to drain completely.
- 4 After the lubricant has drained completely, reinstall the drain plug and tighten it securely.
- 5 Fill the case with the specified lubricant until it is level with the lower edge of the filler hole.
- 6 Install the check/fill plug and tighten it securely.
- 7 Drive the vehicle for a short distance, then check the drain and fill plugs for leakage.

© 2024 Haynes Manuals, Inc. Contact us