

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

4 Accelerator Pedal Position (APP) sensor - replacement

- 1 The APP <u>sensor</u> is located at the upper end of, and is an integral component of, the accelerator pedal assembly. The APP sensor provides the PCM with a variable voltage signal that's proportional to the position (angle) of the accelerator pedal. The PCM uses this and other data to control the position of the <u>throttle</u> plate inside the electronically-controlled <u>throttle body</u>.
- 2 If a diagnostic scan tool test reveals there is a problem with the APP, the accelerator pedal and <u>sensor</u> must be replaced as a unit.
- 3 Remove the bolts securing the <u>throttle</u> pedal assembly, then disconnect the electrical connector (see illustration) .

4.3 Remove the bolts at the top and bottom of the accelerator pedal assembly



4 Lift the <u>throttle</u> pedal assembly upwards, and disconnect the wiring plug. Note that the throttle pedal is only available as a complete assembly, which includes the position <u>sensor</u>. If defective, the complete assembly must be replaced.

5 Installation is the reverse of removal. After replacing the pedal and <u>sensor</u>, check with a scan tool and clear any DTCs.

 $\ensuremath{\text{@}}$ 2024 Haynes Manuals, Inc. Contact us