

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

26 Tie-rod - replacement

Note:

A new tie-rod locking plate and steering boot retaining clip(s) will be required.

- 1 Remove the <u>steering gear</u> boot (see <u>Section 24</u>).
- 2 Using a pair of pliers, bend back the tie-rod locking plate. **Note:** *Do not use a hammer and chisel, as this could damage the <u>steering gear</u>.*
- 3 Unscrew the tie-rod from the end of the steering rack.
- 4 Install the new locking plate to the steering rack, making sure its locating tabs are correctly seated in the steering rack grooves.
- 5 Screw in the tie-rod and tighten it to the specified torque. Secure the tie-rod in position by bending down the locking plate with a pair of pliers.
- 6 Install the steering gear boot (see Section 24).

© 2024 Haynes Manuals, Inc. Contact us