

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

## 23 Active steering control unit - removal and installation

- 1 Disconnect the negative battery cable (see <a href="Chapter 5">Chapter 5</a> ).
- 2 Release the fasteners and remove the rear section of the left front wheelwell liner.
- 3 Remove the bolt securing the ground cable to the bracket, then disconnect the electrical connectors from the control unit.
- 4 Remove the mounting nut and bolt, then maneuver the control unit from the vehicle.
- 5 Installation is the reverse of removal. **Note**: If a new unit is installed, it must be programmed/coded using BMW diagnostic equipment. Entrust this task to a dealer or other qualified shop.

© 2024 Haynes Manuals, Inc. Contact us