

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

11 Engine overhaul - reassembly sequence

1 Before beginning engine reassembly, make sure you have all the necessary new parts, gaskets and seals as well as the following items on hand:

- Common hand tools
- A 1/2-inch drive torque wrench
- New engine oil
- Gasket sealant
- Thread-locking compound

2 If you obtained a short block, it will be necessary to install the <u>cylinder head</u>, the oil pump and pick-up tube, the <u>oil pan</u>, the water pump, the <u>timing chain</u> and timing cover, and the valve cover (see <u>Chapter 2A</u>). In order to save time and avoid problems, the external components must be installed in the following general order:

- Thermostat and housing cover
- Water pump
- Intake and exhaust manifolds
- Fuel injection components
- Emission control components
- Spark plugs
- Ignition coils
- Oil filter
- Turbocharger (if equipped)
- Engine mounts and mount brackets

- <u>Clutch</u> and flywheel (manual transmission)
- Driveplate (automatic transmission)

© 2024 Haynes Manuals, Inc. Contact us