

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

5 Upholstery, carpets and vinyl trim - maintenance

Upholstery and carpets

- 1 Every three months remove the floormats and clean the interior of the vehicle (more frequently if necessary). Use a stiff whiskbroom to brush the carpeting and loosen dirt and dust, then vacuum the upholstery and carpets thoroughly, especially along seams and crevices.
- 2 Dirt and stains can be removed from carpeting with basic household or automotive carpet shampoos available in spray cans. Follow the directions and vacuum again, then use a stiff brush to bring back the "nap" of the carpet.
- 3 Most interiors have cloth or vinyl upholstery, either of which can be cleaned and maintained with a number of material-specific cleaners or shampoos available in auto supply stores. Follow the directions on the product for usage, and always spot-test any upholstery cleaner on an inconspicuous area (bottom edge of a backseat cushion) to ensure that it doesn't cause a color shift in the material.
- 4 After cleaning, vinyl upholstery should be treated with a protectant. **Note**: *Make sure the protectant container indicates the product can be used on seats some products may make a seat too slippery*. **Caution**: *Do not use protectant on vinyl-covered steering wheels.*
- 5 Leather upholstery requires special care. It should be cleaned regularly with saddlesoap or leather cleaner. Never use alcohol, gasoline, nail polish remover or thinner to clean leather upholstery.
- 6 After cleaning, regularly treat leather upholstery with a leather conditioner, rubbed in with a soft cotton cloth. Never use car wax on leather upholstery.
- 7 In areas where the interior of the vehicle is subject to bright sunlight, cover leather seating areas of the seats with a sheet if the vehicle is to be left out for any length of time.

Vinyl trim

8 Don't clean vinyl trim with detergents, caustic soap or petroleum-based cleaners. Plain soap and water works just fine, with a soft brush to clean dirt that may be ingrained. Wash the vinyl as frequently as the rest of the vehicle.

9 After cleaning, application of a high-quality rubber and vinyl protectant will help prevent oxidation and cracks. The protectant can also be applied to weather-stripping, vacuum lines and rubber hoses, which often fail as a result of chemical degradation, and to the tires.

© 2024 Haynes Manuals, Inc. Contact us