

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

8 Front brake caliper - removal and installation

Note:

Before starting work, refer to the precautions in Section 1 and the warnings at the beginning of Section 2.

Removal

- 1 Apply the parking brake, then jack up the front of the vehicle and support it on jackstands. Remove the appropriate wheel.
- 2 Minimize fluid loss by using a brake hose clamp, a C-clamp or a similar tool to clamp the flexible hose.
- 3 Clean the area around the fitting, then loosen the brake hose fitting nut.
- 4 Remove the <u>brake pads</u> (see <u>Section 4</u>).
- 5 Unscrew the caliper from the end of the brake hose and remove it from the vehicle.

Installation

- 6 Screw the caliper fully onto the flexible hose fitting.
- 7 Install the <u>brake pads</u> (see <u>Section 4</u>).
- 8 Securely tighten the brake line fitting nut.
- 9 Remove the brake hose clamp or cellophane, as applicable, and bleed the hydraulic system as described in <u>Section 2</u>. Note that, if the precautions described were taken to minimize brake fluid loss, it should only be necessary to bleed the relevant front brake.
- 10 Install the wheel, then lower the vehicle to the ground and tighten the wheel bolts to the torque listed in the Chapter 1 Specifications. On completion, check the brake fluid level as described in Chapter 1.

© 2024 Haynes Manuals, Inc. Contact us