

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

Specifications

Component location

Air conditioning blower relay Behind passenger's glove box

Air conditioning clutch relay Behind passenger's glove box

Airbag control module Under carpet beneath center console

Airbag crash sensor Front seat crossmember under carpet

Alarm control module Above main fuse box behind glove box

Automatic transmission control module E-box in engine compartment

Engine management ECM E-box in engine compartment

Engine management main relay E-box in engine compartment

Fog light relay Behind passenger's glove box

Fuel injector relay E-box in engine compartment

Fuel pump relay Behind passenger's glove box

General Module (GM V)

Behind passenger's glove box

Headlight dimmer relay

Light switch on light control center

Heated rear window relay Right-hand side of luggage compartment

Horn relay Behind passenger's glove box

Ignition relay E-box in engine compartment

Instrument cluster control unit Instrument cluster

Parking distance control module Right-hand side of trunk near battery

Reversing light relay (automatic transmission) E-box in engine compartment

Seat control module Base of seat cushion

Secondary air injection pump relay

Behind passenger's glove box

Tire pressure control module

Behind passenger's glove box

Windshield washer relay E-box in engine compartment

Note that not all models are equipped with all of the components listed.

Nm

Ft-lbs (unless otherwise indicated)

Torque specifications

Note:

One foot-pound (ft-lb) of torque is equivalent to 12 inch-pounds (in-lbs) of torque. Torque values below approximately 15 foot-pounds are expressed in inch-pounds, because most foot-pound torque wrenches are not accurate at these smaller values.

Airbag system items:		
Door airbag retaining screws	72 in-lbs	9
Driver's airbag retaining screws	71 in-lbs	8
Impact sensor mounting bolts	84 in-lbs	10
Passenger's airbag cover straps screws	72 in-lbs	9
Passenger's airbag retaining nuts	16	22
Head Protection Airbag (HPS) bolts	96 in-lbs	11
Tire pressure transmitter Torx screw	30 in-lbs	4
Wiper arm-to-wiper spindle nut	22	30

© 2024 Haynes Manuals, Inc. Contact us