

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

## 12 Ignition switch - removal and installation

The ignition switch is integral with the steering column lock, and can be removed (see Chapter 10).

© 2024 Haynes Manuals, Inc. Contact us