

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

## 7 Electronic components/sensors - removal and installation

1 The turbine speed <u>sensor</u>, output speed sensor and transmission range switch are all contained within the transmission casing. Replacement of the components involves removal of the <u>oil pan</u> and partial dismantling of the transmission, therefore this should be entrusted to a BMW dealer or suitably-equipped specialist.

2 The transmission electronic control module (ECM) is located in the 'E-box' in the left-hand corner of the engine compartment. Loosen the screws, remove the E-box lid, disconnect the wiring connector and remove the ECM.

© 2024 Haynes Manuals, Inc. Contact us