

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

# 19 Speakers - removal and installation

### Door panel speaker(s)

- 1 Remove the door inner trim panel as described in <a href="Chapter 11">Chapter 11</a>.
- 2 Unscrew the three screws and remove the speaker from the door trim (see illustration) .

19.2 The door speaker is retained by three screws



3 Where present, unscrew the large retaining collar and remove the small speaker from the trim panel (see illustration) .

19.3 Remove the collar and remove the speaker



4 Installation is the reverse of removal.

#### Door upper speaker

5 Carefully unclip the plastic panel from the front inner edge of the door (see illustrations) .

19.5a Note the clips retaining the plastic trim at the front edge of the door . . .



19.5b . . . and the clip at its lower edge



6 Remove the door inner trim panel as described in Chapter 11 .

7 Disconnect the speaker wiring connector, remove the two screws and remove the speaker (see illustration) .

19.7 Remove the door upper speaker bolts



8 Installation is the reverse of removal.

## Luggage area speaker

- 9 Remove the relevant luggage compartment side trim panel as described in Chapter 11, Section 27.
- 10 Remove the retaining screws and remove the speaker, disconnect its wiring connectors as they become accessible (see illustration) .

19.10 Rear speaker - Sport Wagon models



11 Installation is the reverse of removal making sure the speaker is correctly located.

#### Rear speaker

12 Carefully pry the speaker grille out from the rear parcel shelf  $\,$  (see illustration) .





- 13 Remove the retaining screws and lift off the speaker. Disconnect the wiring connector as the speaker is withdrawn.
- 14 Installation is the reverse of removal.

© 2024 Haynes Manuals, Inc. Contact us