

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

## **Specifications**

## Firing order

| Four-cylinder models  | 1-3-4-2   |
|-----------------------|---|
| Six-cylinder models   | 1-5-3-6-2-4   |
| Ignition timing       | Electronically-controlled by DME - no adjustment possible |
|                       | Ft-lbs  |
| Torque specifications |   |
|                       |   |
| Spark plugs           | 22  |

© 2024 Haynes Manuals, Inc. Contact us