

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

Every 50,000 miles

Replace the oxygen sensor(s) (Section 34)

© 2024 Haynes Manuals, Inc. Contact us