

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

12 Seat belt check

- 1 Carefully examine the seat belt webbing for cuts or any signs of serious fraying or deterioration. If the seat belt is of the retractable type, pull the belt all the way out, and examine the full extent of the webbing.
- 2 Fasten and unfasten the belt, ensuring that the locking mechanism holds securely and releases properly when intended. If the belt is of the retractable type, check also that the retracting mechanism operates correctly when the belt is released.
- 3 Check the security of all seat belt mountings and attachments which are accessible, without removing any trim or other components, from inside the car.

© 2024 Haynes Manuals, Inc. Contact us