

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

19 Speakers - removal and installation

Door panel speaker(s)

- 1 Remove the door inner trim panel as described in Chapter 11.
- 2 Unscrew the three screws and remove the speaker from the door trim (see illustration) .

19.2 The door speaker is retained by three screws



3 Where present, unscrew the large retaining collar and remove the small speaker from the trim panel (see illustration) .

19.3 Remove the collar and remove the speaker



4 Installation is the reverse of removal.

Door upper speaker

5 Carefully unclip the plastic panel from the front inner edge of the door (see illustrations) .

19.5a Note the clips retaining the plastic trim at the front edge of the door...



19.5b . . . and the clip at its lower edge



6 Remove the door inner trim panel as described in Chapter 11 .

7 Disconnect the speaker wiring connector, remove the two screws and remove the speaker (see illustration) .

19.7 Remove the door upper speaker bolts



8 Installation is the reverse of removal.

Luggage area speaker

- 9 Remove the relevant luggage compartment side trim panel as described in Chapter 11, Section 27.
- 10 Remove the retaining screws and remove the speaker, disconnect its wiring connectors as they become accessible (see illustration) .

19.10 Rear speaker - Sport Wagon models



11 Installation is the reverse of removal making sure the speaker is correctly located.

Rear speaker

12 Carefully pry the speaker grille out from the rear parcel shelf (see illustration) .





- 13 Remove the retaining screws and lift off the speaker. Disconnect the wiring connector as the speaker is withdrawn.
- 14 Installation is the reverse of removal.

© 2024 Haynes Manuals, Inc. Contact us