

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

## 10 Master cylinder - general information

1 It is not possible for the home mechanic to remove the <u>master cylinder</u>. If the hydraulic lines are disconnected from the master cylinder, air will enter the high-pressure hydraulic system linking the master cylinder and hydraulic unit. <u>Bleeding</u> of the high-pressure system can only be safely carried out by a BMW dealer who has access to the service tester (see <u>Section 2</u>). <u>Master cylinder</u> removal and installation should therefore be entrusted to a BMW dealer or other qualified repair shop.

© 2024 Haynes Manuals, Inc. Contact us