

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

## 31 Clutch check

This check is specified by BMW to check the <u>clutch</u> friction disc for wear. The check involves the use of a special tool, which fits into the clutch slave cylinder aperture in the transmission bellhousing, once the slave cylinder has been unbolted.

It is unlikely that the <u>clutch</u> wear will be significant unless the vehicle has covered a high mileage, or the clutch has been abused.

If in doubt as to the condition of the clutch friction disc, have the check carried out by a BMW dealer.

© 2024 Haynes Manuals, Inc. Contact us