

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

7 Rear brake disc - inspection, removal and installation

Note:

Before starting work, refer to the precautions in Section 1 and the warnings at the beginning of Section 2.

Note:

If either disc requires replacement, BOTH should be replaced at the same time, to ensure even and consistent braking. New brake pads should also be installed.

Inspection

1 Firmly chock the front wheels, then raise the rear of the vehicle and support it securely on jackstands. Remove the appropriate rear wheel. Release the parking brake.

2 Inspect the disc as described in Section 6.

Removal

3 Unscrew the two bolts securing the <u>brake caliper</u> mounting bracket in position, then slide the caliper assembly off the disc. Using a piece of wire or string, tie the caliper to the rear suspension coil spring, to avoid placing any strain on the hydraulic brake hose (see illustration) . If necessary unclip the brake hose from the lower mounting bracket to provide enough slack to maneuver the <u>caliper</u> and bracket.

7.3 Slide the rear caliper assembly off the disc



4 Remove the <u>brake disc</u> retaining screw (see illustration) .

7.4 Remove the retaining screw and slide the rear disc off the hub



5 It should now be possible to withdraw the <u>brake disc</u> from the hub by hand. If it is tight, lightly tap its rear face with a hide or plastic mallet. If the parking brake shoes are binding, first check that the parking brake is fully released, then continue as follows.

6 Referring to Section 14 for further details, fully loosen the parking brake adjustment to obtain maximum free play in the cable.

7 Insert a screwdriver through one of the wheel bolt holes in the <u>brake disc</u>, and rotate the adjuster knurled wheel on the upper pivot to retract the shoes (see illustrations 14.5a and 14.5b) . The <u>brake disc</u> can then be withdrawn.

Installation

8 If a new disc is been installed, use a suitable solvent to wipe any preservative coating from the disc.

9 Position the disc on the hub, install the disc retaining screw and tighten it to the specified torque.

- 10 Slide the <u>caliper</u> into position over the disc, making sure the pads pass either side of the disc. Tighten the caliper bracket mounting bolts to the specified torque setting.
- 11 Adjust the parking brake shoes and cable as described in Section 14.
- 12 Install the wheel, then lower the car to the ground, and tighten the wheel bolts to the torque listed in the Chapter 1 Specifications. On completion, repeatedly depress the brake pedal until normal (non-power assisted) pedal pressure returns. Recheck the parking brake adjustment.

© 2024 Haynes Manuals, Inc. Contact us